



Wired remote controller

BRC1H Series

DAIKIN APP

Ver.1.0.1

Support manual for
Administrator

English

Français

Español



CONTENTS

Cautions for use

App startup

Basic usage

Manual setting mode

Work history

App menu

Troubleshooting

About display messages

About trademarks and copyright



CONTENTS

Cautions for use

Cautions for use	1
App startup	
Basic usage	
Manual setting mode	
Work history	
App menu	
Troubleshooting	
About display messages	
About trademarks and copyright	



CONTENTS

Cautions for use

App startup

About devices that can be used	3
Language setting	5
User selection	6
Bluetooth and camera setting	7
Terms of service	8
Usage limitations	9

Basic usage

Manual setting mode

Work history

App menu

Troubleshooting

About display messages

About trademarks and copyright



CONTENTS

Cautions for use

App startup

Basic usage

How to read this operation manual 10

Remote controller preparation 10

Pairing with the remote controller 13

How to use the app 16

Manual setting mode

Work history

App menu

Troubleshooting

About display messages

About trademarks and copyright



CONTENTS

Cautions for use

App startup

Basic usage

Manual setting mode

Manual setting mode 18

Filter auto clean 19

Auto draft prevention 21

Sensor settings 23

Setpoint configuration 27

Setpoint range limitation 30

Setback 32

Function lock 35

Date & time/DST 38

Celsius/Fahrenheit 41

Brightness control 43

Scale view setting 46

Work history

App menu

Troubleshooting

About display messages

About trademarks and copyright



CONTENTS

Cautions for use

App startup

Basic usage

Manual setting mode

Work history

Setting log confirmation procedure

58

App menu

Troubleshooting

About display messages

About trademarks and copyright



CONTENTS

Cautions for use

App startup

Basic usage

Manual setting mode

Work history

App menu

Application version 60

Terms of use 61

Open source licenses 62

Application language 63

Application time 64

Troubleshooting

About display messages

About trademarks and copyright



CONTENTS

Cautions for use

App startup

Basic usage

Manual setting mode

Work history

App menu

Troubleshooting

The app cannot be found 65

The app cannot be used 66

Communication with the remote controller is not possible 67

About display messages

About trademarks and copyright



CONTENTS

Cautions for use

App startup

Basic usage

Manual setting mode

Work history

App menu

Troubleshooting

About display messages

App screen (dialog displayed when writing to the remote controller)

71

About trademarks and copyright



CONTENTS

Cautions for use

App startup

Basic usage

Manual setting mode

Work history

App menu

Troubleshooting

About display messages

About trademarks and copyright

About trademarks and copyright

74



Cautions for use

- ▶ DAIKIN APP (hereafter referred to as “app”) is an application provided by Daikin Industries, Ltd. which makes it simple to carry out RC settings of remote controllers made for industrial air conditioners.
- ▶ Communication fees which result from the download, update, or use of this app are the responsibility of the user.
(This includes additional communication fees which result from updates of this app, re-setting of this app if not functioning correctly, etc.)



Cautions for use

- ▶ App user should be in close proximity to the remote controller.
Do not use Bluetooth low energy connection around wireless LAN or other wireless equipment, around equipment which produces radio waves, or in environments with poor signal conditions.
There is a possibility that connection will be interrupted frequently, communication speed may be significantly reduced and errors may occur.
- ▶ Do not turn off the Bluetooth function of your smartphone while using this app.
- ▶ If worried about your smartphone being infected by a computer virus, we recommend that you install separate anti-virus software.



App startup

About devices that can be used

Please use this app on a device compatible with Bluetooth low energy communication, as this app uses Bluetooth low energy communication to write setting information to the remote controller.

Also, please use a device with a rear-facing camera, as this app scans QR codes after startup depending on usage.

- Compatible OS versions:
iOS 12.0 or higher
Android 9.0 or higher
- Equipped with rear-facing camera
- Please use a smartphone compatible with BLE 4.2 or higher.




App startup

- This app can only connect with “BRC1H7” series wired remote controllers.
- This app is compatible with iOS Dark Mode.
iOS 13 or higher is required to use Dark Mode.

App startup

Language setting

Select the language to display when using this app.




The screenshot shows a mobile app interface for language selection. At the top left, there is a blue back arrow. The title "Language" is centered at the top. Below the title, a light gray box contains the instruction "Please select a language for this app." Below this box, there are three list items: "English" with a blue checkmark to its right, "Español", and "Le français". At the bottom of the screen, there are four small gray dots, with the first one being filled. Below the dots is a white rounded rectangular button with the text "Next" in blue.

App startup

User selection

Select “Owner/Administrator”.



<

User authentication

Please select the one that applies

Owner/Administrator ✓

Installer

• • • • •

Next

App startup

Bluetooth and camera setting

Set the device Bluetooth function to available.

If not set to available, this app cannot be used.






App startup

Terms of service

After initial startup and setting, upon reaching the end of initial setting, the terms of use of this app are displayed. Please read the terms of use to the end. You must agree to the terms of use to proceed with use of this app.





App startup

Usage limitations

Every time this app starts up, it performs a version check, so as a rule, please use it in an environment where internet connection is possible. If there is a newer version of this app, please update this app.

If this app is not updated to the latest version, this app cannot be used.

Also, if the app is being used in an environment where internet connection is not possible and the app has been started more than 31 times since the last version check, the app cannot be used until a version check is performed again.



Basic usage

How to read this operation manual

Main : Represents the Main RC

Sub : Represents the Sub RC

Remote controller preparation

For details on remote controller usage, refer to the installation manual included with the remote controller.

■ Display the owner/administrator menu screen


When using this app, it is necessary to display the owner/administrator menu screen on the remote controller.

1. Display the basic screen on the remote controller.



Basic usage

2. Press the center button on the remote controller for 5 seconds or more, and display the information screen.



3. While the information screen is displayed, press the center  and left  button (in that order), and keep them both pressed for 5 seconds or more to display the owner password input screen.

* If a password has been set, the password input screen will be displayed. If a password has not been set, this screen will not be displayed, and continue to step 4.





Basic usage

4. After the owner/administrator menu screen is displayed, select the Bluetooth setting icon.




Basic usage

Pairing with the remote controller


1. After the Bluetooth setting screen is displayed on the remote controller*, use this app to select the remote controller you want to connect to.

* The last 6 digits of the Bluetooth device address are displayed on the remote controller, select the same 6 digits that are also displayed on the app.



Basic usage

2. A 6 digit number is displayed on the screens of both the remote controller and this app, so confirm that the displayed numbers are the same, then press “Pairing” on the remote controller side and press “Pairing” on the app side.





Basic usage

3. After pairing is complete, the Administrator mode menu is displayed on the app.





Basic usage

How to use the app

CAUTION

Once this app writes setting contents to the remote controller, the previous setting contents are overwritten.

From the app Installer Mode Menu, select one of the option below:

- 1. Manual setting mode**
Select any remote controller and carry out setting.
- 2. Work history**
Review settings log for the remote controller.
- 3. App menu**
 - ▶ Application version**
You can confirm the software version of the app.



Basic usage

▶ **Terms of use**

You can confirm the terms of use of the app.

▶ **Open source licenses**

You can confirm the open-source software license this app uses.

▶ **Application language**

You can change the language displayed by the app.


▶ **Application time**

You can change whether the app displays time in 24-hour or 12-hour style.



Manual setting mode

Select the remote controller to perform settings on.





Manual setting mode

- Installer setting

- RC settings

- Indoor unit settings

Filter auto clean

Main

Set the time when you want to start the filter auto clean function.

After all settings are complete, press the “Send to RC” button.

The screenshot shows a mobile application interface for setting the filter auto clean function. At the top, there is a back arrow on the left, the title "Filter auto clean" in the center, and a help icon (question mark in a circle) on the right. Below the title, there is a "Time span" field with a dropdown menu showing "00:00am-03:00am". Underneath this is a horizontal separator line. At the bottom, there is a "Forbid filter auto clean" toggle switch, which is currently turned off.



Manual setting mode

- Installer setting

- RC settings

- Indoor unit settings

▶ Time span

Set the time when you want the filter auto clean function to operate.

▶ Forbid filter auto clean

Set the filter auto clean function to enable/disable.



Manual setting mode

- Installer setting

- RC settings

- Indoor unit settings

Auto draft prevention

Main

Set the auto draft prevention function, so that people are not directly hit by indoor unit discharge air.

After all settings are complete, press the “Send to RC” button.




Manual setting mode

- Installer setting

- RC settings

- Indoor unit settings



▶ Auto draft prevention

Set the auto draft prevention function to enable/disable.



Manual setting mode

- Installer setting

- RC settings

- Indoor unit settings

Sensor settings

Main

Set the sensing sensor low mode function, which controls power consumption by gradually changing the internal set temperature after it detects that no people are present, or set the sensing sensor stop mode function, which stops operation of the air conditioner after it detects that no people are present and a fixed amount of time has elapsed.

After all settings are complete, press the “Send to RC” button.

Manual setting mode

- Installer setting

- RC settings

- Indoor unit settings

Sensing sensor	
Sensing sensor low mode	<input checked="" type="checkbox"/>
Cool	
Setpoint increment	1°F
Increment time	30 minutes
Setpoint high limited	82°F
Heat	
Setpoint increment	1°F
Decrement time	30 minutes
Setpoint low limited	68°F
Sensing sensor stop mode	<input checked="" type="checkbox"/>
Auto off timer	1 hour

Send to RC

► Sensing sensor low mode

Set the sensing sensor low mode function to enable/disable.



Manual setting mode

- Installer setting

- RC settings

- Indoor unit settings

► Cool/Heat

Setpoint increment or decrement

Set the setpoint increase or decrease of the cool/heat temperature.

Increment or Decrement time

Set the number of minutes after which the sensing sensor low mode function will begin if no people are detected and the air conditioner is in Cool/Heat mode.

Setpoint high or low limit

Set limits on the correction value (a setpoint high limit for cool and a setpoint low limit for heat).

► Sensing sensor stop mode

Set the sensing sensor stop mode function to enable/disable.



Manual setting mode

- Installer setting

- RC settings

- Indoor unit settings

▶ Auto off timer

Set the number of hours after which the sensing sensor stop mode function will turn off the indoor unit if no people are detected.



Manual setting mode

- Installer setting

- RC settings

- RC settings

Setpoint configuration

Main

Setpoint mode and differential can be set when changeover is available. After all settings are complete, press the “Send to RC” button.

The image shows a mobile application screen titled "Setpoint configuration". At the top left is a back arrow, and at the top right is a help icon (a question mark in a circle). Below the title, there are three rows of settings:

Changeover	Available
Setpoint mode	Dual ▼
Setpoint minimum differential	1°F ▼

At the bottom of the screen, there is a rounded rectangular button labeled "Send to RC".



Manual setting mode

- Installer setting

- RC settings

- RC settings

► Setpoint mode

Set the setpoint mode.

- Single
The cool setpoint and heat setpoint will be made the same, and the room temperature will be kept close to this setpoint.
- Dual
The cool setpoint and heat setpoint will be made different, and the room temperature will be kept between the cool or heat setpoints.



Manual setting mode

- Installer setting

- RC settings

- RC settings

- None

Set the cool temperature and heat temperature so that they do not restrict each other.

When set to None, automatic cooling/heating changeover (Changeover) is unavailable.

▶ **Setpoint minimum differential**

Set the setpoint minimum differential between the cool and heat setpoints.

Manual setting mode

- Installer setting

- RC settings

- RC settings

Setpoint range limitation

Main

Limit the range of setpoints which can be set from the remote controller.

After all settings are complete, press the “Send to RC” button.

< Setpoint range limitation ?

Cool setpoint range

60°F 68°F - 90°F 90°F

Heat setpoint range

60°F 60°F - 86°F 90°F

Send to RC



Manual setting mode

- Installer setting

- RC settings

- RC settings

▶ Cool setpoint range

Set the cool setpoint range.

* The displayed upper and lower limit values are values from the connected MAIN indoor unit.

▶ Heat setpoint range

Set the heat setpoint range.

* The displayed upper and lower limit values are values from the connected MAIN indoor unit.



Manual setting mode

- Installer setting

- RC settings

- RC settings

Setback

Main

To prevent the room temperature from becoming extremely high or low while the air conditioner operation is turned off, if the room temperature exceeds the setback setpoint or falls below it, operation is set to start automatically. After all settings are complete, press the “Send to RC” button.

Manual setting mode

- Installer setting

- RC settings

- RC settings

The screenshot displays the 'Setback' configuration screen. At the top, there is a back arrow, the title 'Setback', and a help icon. The settings are organized into sections:

- Setback:** A toggle switch is turned on (green).
- Cool setback:** A toggle switch is turned on (green).
- Cool setback setpoint:** A slider is positioned at 95°F, with 95°F marked at both ends.
- Cool recovery differential:** A dropdown menu is set to 4 °F.
- Heat setback:** A toggle switch is turned on (green).
- Heat setback setpoint:** A slider is positioned at 41°F, with 41°F and 57°F marked.
- Heat recovery differential:** A dropdown menu is set to 4 °F.

At the bottom of the screen, there is a button labeled 'Send to RC'.

► Setback

Set the setback function to enable/disable.



Manual setting mode

- Installer setting

- RC settings

- RC settings

▶ Cool setback

Set the cool setback to enable/disable.

▶ Cool setback setpoint

Set the cool setback setpoint.

▶ Cool recovery differential

Set the cool recovery differential.

▶ Heat setback

Set the heat setback function to enable/disable.

▶ Heat setback setpoint

Set the heat setback setpoint.

▶ Heat recovery differential

Set the heat recovery differential.



Manual setting mode

- Installer setting

- RC settings

- RC settings

Function lock

Main Sub

Partially limit the operation from the remote controller.

After all settings are complete, press the “Send to RC” button.

The image shows a mobile application screen titled "Function lock" with a back arrow on the left and a help icon on the right. The screen contains a list of settings, each with a toggle switch. The settings are: RC Button, User menu item, Operation mode, Fan speed, Airflow direction, Change setpoint, and another Operation mode section with sub-items: Auto, Cool, Heat, Fan, and Dry. At the bottom of the screen is a button labeled "Send to RC".

Setting	Toggle
RC Button	Off
User menu item	
Operation mode	Off
Fan speed	Off
Airflow direction	Off
Change setpoint	Off
Operation mode	
Auto	Off
Cool	Off
Heat	Off
Fan	Off
Dry	Off

Send to RC



Manual setting mode

- Installer setting

- RC settings

- RC settings

▶ RC button

Set the remote controller button operation to enable/disable.

▶ User menu item

Operation mode

Set the ability to change operation modes to enable/disable.

Fan speed

Set the ability to change Fan speed to enable/disable.

Airflow direction

Set the ability to change airflow direction to enable/disable.

Change setpoint

Set the ability to change the setpoint to enable/disable.



Manual setting mode

- Installer setting

- RC settings

- RC settings

▶ Operation mode

Auto

Set operation mode Auto to enable/disable.

Cool

Set operation mode Cool to enable/disable.

Heat

Set operation mode Heat to enable/disable.

Fan

Set operation mode Fan to enable/disable.

Dry

Set operation mode Dry to enable/disable.

Manual setting mode

- Installer setting

- RC settings

- RC display settings

Date & time/DST

Main

Sub

Set the remote controller clock and daylight saving time.

After all settings are complete, press the “Send to RC” button.

< Date and time/DST ?

Automatic clock setting

Read the date and time from your smartphone.

Date and time 02/26/2020 11:31 am ▾

Daylight saving time

DST start March 1st Sunday ▾

DST end October 1st Sunday ▾

Send to RC



Manual setting mode

- Installer setting

- RC settings

- RC display settings

▶ Automatic clock setting

Set automatic clock setting to enable/disable.

Not displayed when daylight saving time is displayed, or when connected to a centralized device.

Not displayed and function not available if the daylight saving time setting is able to be changed.

▶ Date and time

Manually set the day and time.

* If Auto clock setting is set to unavailable, this setting is possible.

▶ Daylight saving time

Set the ability to change the daylight saving time setting to enable/disable.



Manual setting mode

- Installer setting

- RC settings

- RC display settings

▶ DST start

Set the date and time at which daylight saving time will start.

▶ DST end

Set the date and time at which daylight saving time will finish.



Manual setting mode

- Installer setting

- RC settings

- RC display settings

Celsius/Fahrenheit

Main Sub

Set the unit type with which the temperature is displayed on the app screen.

After all settings are complete, press the “Send to RC” button.




Manual setting mode

- Installer setting

- RC settings

- RC display settings



► Celsius/Fahrenheit

Set the Celsius/Fahrenheit display.



Manual setting mode

- Installer setting

- RC settings

- RC display settings

Brightness control

Main Sub

Set the brightness level of the status indicator and remote controller LCD backlight.

After all settings are complete, press the “Send to RC” button.



Manual setting mode

- Installer setting

- RC settings

- RC display settings



► Back light brightness

Set the remote controller LCD brightness level.



Manual setting mode

- Installer setting

- RC settings

- RC display settings

▶ **Status indicator brightness (Back light on)**

Set the status indicator brightness level when the backlight is ON.

▶ **Status indicator brightness (Back light off)**

Set the status indicator brightness level when the backlight is OFF.



Manual setting mode

- Installer setting

- RC settings

- RC display settings

Scale view setting

Main

Set the function to enable operation only by how high or low it is from the reference temperature without displaying the setpoint on the remote controller.

Manual setting mode

- Installer setting

- RC settings

- RC display settings

< Scale view setting ?

Scale view setting

Cool reference setpoint	78 °F ▼
Heat reference setpoint	72 °F ▼

Send to RC

► Cool reference setpoint

Set the reference setpoint when the operation mode is Cool.



Manual setting mode

- Installer setting

- RC settings


- RC display settings

► Heat reference setpoint

Set the reference setpoint when the operation mode is Heat.

Manual setting mode

- Service menu



▶ Error code reset

After resolving the error, tap “Reset” to clear it from the error history display of the remote controller.



Manual setting mode

- Service menu

- Error history

Main

Display the error history saved in the remote controller and indoor unit.

By selecting from the menu in the upper portion of the screen, you can switch between displaying the error history of the remote controller and indoor unit.

By specifying the unit number of an indoor unit, you can confirm the error history of each indoor unit.

- * For indoor unit error history, a maximum of 5 issues are displayed.
- * For remote controller error history, a maximum of 10 issues are displayed.



Manual setting mode

- Service menu

- Error history

Error history		Clear
Type	Indoor unit	▼
Unit No.	00	▼
06 : Unit 00 12/05/1999 04:10 am		
04 : Unit 00 04/08/2000 10:00 am		



Manual setting mode

- Service menu

- Error history

Error history	
Type	RC ▼
A3 : Unit 01 02/21/2020 04:59 pm	
U4 : Unit 01 02/21/2020 04:57 pm	
C4 : Unit 01 02/21/2020 04:56 pm	



Manual setting mode

- RC security

- Owner password

Main

Sub

Set the password for the owner/
administrator.

It is possible to make password entry
required if the user wants to change
functions that can be changed with
owner/administrator authority.

[When password input is unavailable]

If the toggle switch is available, the
password setting screen will be
displayed, so enter a 4 digit password.

* Be sure to make a memo of your password
and keep it in a safe place.


Please understand that, in case you forget
your password, there is a possibility that we
may not be able to help you.



Manual setting mode

- RC security

- Owner password



Manual setting mode

- RC security

- Owner password

The screenshot shows a mobile application interface for changing a password. At the top, there are two buttons: 'Cancel' on the left and 'Change password' on the right. Below the buttons is a large white rectangular area with the text 'Enter new owner password.' centered inside. Underneath this text are four small, empty circles representing a 4-digit password input field. At the bottom of the screen is a numeric keypad with a light gray background. The keypad has a 'Done' button in the top right corner. The keys are arranged in a grid: the first row has '1', '2 ABC', and '3 DEF'; the second row has '4 GHI', '5 JKL', and '6 MNO'; the third row has '7 PQRS', '8 TUV', and '9 WXYZ'; the bottom row has '+ * #', '0', and a backspace icon (a square with an 'X').

[When password input is available]
If “Change Password” is tapped,
the password setting screen will be
displayed, so enter a 4 digit password.




Manual setting mode

- RC security

- Owner password

- * After changing your password, be sure to make a memo of your new password and keep it in a safe place.
Please understand that, in case you forget your password, there is a possibility that we may not be able to help you.



Manual setting mode

- RC security

- Owner password

Cancel Change password

Enter old owner password.

○ ○ ○ ○

^ v Done

1	2 ABC	3 DEF
4 GHI	5 JKL	6 MNO
7 PQRS	8 TUV	9 WXYZ
+ * #	0	⌫



Work history

Setting log confirmation procedure

You can confirm the setting log of the remote controller on which setting has been done.

Date information is also displayed.

- * A maximum of 50 historical data items are stored.
- * It is not possible to re-edit historical data.
- * Items other than those upon which setting had been carried out cannot be viewed.



Work history


<	Work history	>
	02212020202900_964C1E_J	>
	02212020202303_964C1E_J	>
	02212020200601_964C1E_J	>
	02212020200600_964C1E_J	>
	02212020200558_964C1E_J	>
	02212020200557_964C1E_J	>
	02212020200556_964C1E_J	>
	02212020200555_964C1E_J	>
	02212020200554_964C1E_J	>
	02212020200501_964C1E_J	>



App menu

Application version

You can confirm the software version of this app.

A screenshot of the 'App menu' screen. The title bar shows a back arrow and the text 'App menu'. The menu items are: 'Application version' with the value '1.0.0', 'Terms of use' with a right arrow, 'Open source licenses' with a right arrow, 'Application language' with the value 'English' and a dropdown arrow, and 'Application time' with the value 'AM/PM' and a dropdown arrow.


App menu	
Application version	1.0.0
Terms of use	>
Open source licenses	>
Application language	English ▾
Application time	AM/PM ▾



App menu

Terms of use

You can confirm the terms of use of this app.



App menu

Open source licenses

You can confirm the open-source software license which this app uses.



Open source licenses

@angular/animations

The MIT License

Copyright (c) 2010-2019 Google LLC.
<http://angular.io/license>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:


The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

App menu

Application language

You can change the language displayed by this app.

After language selection is complete, press the “<” button.




App menu

Application time

You can change whether this app displays time in 24-hour or 12-hour style.

After time display selection is complete, press the “<” button.





Troubleshooting

The app cannot be found

- Is the Android device you are using equipped with Bluetooth and a rear-facing camera?
 - ▶ Unequipped Android devices will not display the app in the Google Play store list of apps.
 - Is the OS version of the Android device you are using correct?
 - ▶ If using an Android device with an OS older than 9.0.0, the app will not be displayed in the Google Play store list of apps.
-



Troubleshooting

The app cannot be used

- Has the app been started more than 31 times since a version check was performed?
 - * A version check is carried out when connecting to the App Store.
 - ▶ Please use in an environment where internet connection is possible.
-



Troubleshooting

Communication with the remote controller is not possible

-
- Are you carrying out settings in a location close to the remote controller?
 - ▶ Though Bluetooth low energy communication is possible even from distant locations, as a basic rule, please carry out work close to the operating remote controller.
-
- Are the Bluetooth function and camera function of the device set to ON?
 - ▶ Set the device Bluetooth function and camera function to ON.
-



Troubleshooting

- Is the Bluetooth setting screen displayed within the installer menu screen?
 - ▶ On the remote controller, display the Bluetooth setting screen within the installer screen.
-
- Is the clock on the device correct?
 - ▶ Set the clock on the device correctly to the current time.
-



Troubleshooting

- Is the Bluetooth prohibition setting in the remote controller set to “Allow”?
 - ▶ Set to “Allow” in the Bluetooth prohibition setting area of the remote controller field setting menu.
-



Troubleshooting

- Is the device you are using charged?
 - ▶ Please charge it. If the battery power is insufficient, there is a possibility that communication cannot be carried out well.
 - Connection to the remote controller was possible before, but now connection is not possible.
 - ▶ Unregister the device on your smartphone.
 1. Startup the settings application.
 2. Select Bluetooth.
 3. From the list of your devices, press the “i” button of the “UE878 RF MODULE”.
 4. Select “Unregister this device”.
-

About display messages

App screen (dialog displayed when writing to the remote controller)

Contents	Error code	Message	Correction method
▶ Device error			
The Bluetooth function of the device is OFF	A-0001	The Bluetooth function of the device is unavailable.	From the setting screen of the device, please make the Bluetooth function available.
The app is prohibited from giving its location information (Android only)	A-0002	To use this app, access to location information needs to be granted.	Please grant access to location information from the app information.
This device does not support Bluetooth	A-0004	This device does not support Bluetooth.	Please use a recommended device.
This device does not support camera usage.	A-0005	This device does not support camera usage.	Please use a recommended device.
▶ Communication error			
Communication timed out	B-0001	Communication timed out.	Move close to the remote controller and perform settings again.
The length of the frame is not within range	B-0002	Communication failed.	Move close to the remote controller and perform settings again.
A nonexistent command was received	B-0003	Communication failed.	Move close to the remote controller and perform settings again.
Inconsistent frame number	B-0004	Communication failed.	Move close to the remote controller and perform settings again.
Cannot receive due to communication volume exceeding the allotted memory area	B-0005	Communication failed.	Move close to the remote controller and perform settings again.
Pairing was interrupted	B-0006	Communication with the remote controller was interrupted.	Make the advertisement function on the remote controller available, perform pairing again, and then perform settings.

About display messages

Contents	Error code	Message	Correction method
There was a failure at CRC check	B-0007	Communication failed.	Move close to the remote controller and perform settings again.
Received data is missing	B-0008	Reception failed.	Move close to the remote controller and perform settings again.
Connected to a non-supported device	B-0009	It is a non-supported device.	This app can only connect to the Daikin Industries, Ltd. "BRC1H7" wired remote controller series.
The amount of schedule data is excessive	B-0010	The amount of data is in error.	—
An error occurred in part of the header	B-0011	Communication failed.	This app can only connect to the Daikin Industries, Ltd. "BRC1H7" wired remote controller series.
Processing sequence error	B-0012	Communication failed.	—
▶ Setting failure			
There was a setting failure due to an error on the device side	C-0001	Some kind of error occurred between the remote controller and the indoor unit.	Move close to the remote controller and perform settings again. If the same message is displayed, confirm the contents of the setting.



About display messages

Contents	Error code	Message	Correction method
Setting failed because the batch sending function sent a value that cannot be set on the device side.	C-0002	<p>Contains a value that cannot be set. Check the settings for the following functions.</p> <ul style="list-style-type: none"> • Field setting • Setpoint range limitation <p>Enumerates functions that tried to set values which cannot be set, such as above.</p>	Confirm the contents of the setting.

- 1 If this app is not updated to the latest version, this app cannot be used. Also, if the app is being used in an environment where internet connection is not possible and the app has been started more than 31 times since the last version check, the app cannot be used until a version check is performed again.
- 2 Has the app been started more than 31 times since a version check was performed?
- 3 Though Bluetooth low energy communication is possible even from distant locations, as a basic rule, please carry out work close to the operating remote controller.



About trademarks and copyright

- “QR Code” is a trademark or registered trademark of DENSO WAVE INCORPORATED.
- “iOS” and “Apple Store” are trademarks or registered trademarks of Apple Inc.
- “Android” and “Google Play Store” are trademarks or registered trademarks of Google Inc.
- Bluetooth low energy and the Bluetooth low energy logo are trademarks of Bluetooth SIG, Inc.
- The contents of this manual are subject to change without prior notice.
- Other company names, product names, etc. noted here are trademarks or registered trademarks of other companies, or trademarks of this company. It should be noted that ® and ™ marks are not specified in the text.

