

DAIKIN

SiUS342003E

R-410A

Service Manual

VRV



**RXYQ72-408XATJA
RXYQ72-408XAYDA**

Heat Pump 60 Hz



RXYQ-XA Series Heat Pump R-410A 60 Hz

1. Safety Cautions	vii
1.1 Warnings and Cautions Regarding Safety of Workers	vii
1.2 Warnings and Cautions Regarding Safety of Users	ix
2. Icons Used	xii

Part 1 General Information 1

1. Model Names	2
1.1 Indoor Unit	2
1.2 Outdoor Unit	2
1.3 Air Treatment Equipment	3
2. External Appearance	4
2.1 Indoor Unit	4
2.2 Outdoor Unit	5
2.3 Air Treatment Equipment	5
3. Combination of Outdoor Units	6
4. Capacity Range	7
4.1 Combination Ratio	7
4.2 Outdoor Unit Combinations	7
5. Specifications	8
5.1 RXYQ-XATJA	8
5.2 RXYQ-XAYDA	23

Part 2 Refrigerant Circuit 38

1. Refrigerant Circuit	39
1.1 Outdoor Unit	39
1.2 Indoor Unit	45
1.3 Outdoor-Air Processing Unit	47
2. Functional Parts Layout	48
2.1 RXYQ72XATJA	48
2.2 RXYQ96/120XATJA	49
2.3 RXYQ144/168XATJA	50
2.4 RXYQ72XAYDA	51
2.5 RXYQ96/120XAYDA	52
2.6 RXYQ144/168XAYDA	53

3. Refrigerant Flow for Each Operation Mode.....	54
3.1 RXYQ72XATJA, RXYQ72XAYDA.....	54
3.2 RXYQ96/120XATJA, RXYQ96/120XAYDA.....	58
3.3 RXYQ144/168XATJA, RXYQ144/168XAYDA.....	62

Part 3 Remote Controller 66

1. Applicable Models	67
2. Names and Functions	68
2.1 BRC1E73	68
2.2 Wireless Remote Controller	71
3. Main/Sub Setting.....	72
3.1 BRC1E73	72
3.2 When Wireless Remote Controller is Used Together.....	73
4. Address Setting for Wireless Remote Controller.....	74
5. Centralized Control Group No. Setting.....	76
5.1 BRC1E73	76
5.2 Wireless Remote Controller	78
5.3 Group No. Setting Example.....	79
6. Service Settings Menu, Maintenance Menu.....	80
6.1 BRC1E73	80

Part 4 Functions and Control 84

1. Operation Flowchart (Outdoor Unit)	86
2. Stop Control	87
2.1 Stop due to Error	87
2.2 When System is in Stop Control.....	87
2.3 Slave Unit Stops during Master Unit Operation.....	87
3. Standby Control	88
3.1 Restart Standby.....	88
3.2 Crankcase Heater Control.....	88
4. Startup Control	89
4.1 Startup Control in Cooling	89
4.2 Startup Control in Heating	90
5. Basic Control.....	91
5.1 Normal Control	91
5.2 Compressor Capacity Control	92
5.3 Operating Priority and Rotation of Compressors.....	93
5.4 Compressor Step Control.....	94
5.5 Electronic Expansion Valve Control	94
5.6 Step Control of Outdoor Fans	95
6. Protection Control	96
6.1 High Pressure Protection Control.....	96
6.2 Low Pressure Protection Control.....	97
6.3 Discharge Pipe Protection Control	98
6.4 Compressor Body Protection Control.....	98

6.5	Inverter Protection Control	99
6.6	Heating Operation Prohibition	100
7.	Special Control	101
7.1	Pump Down Residual Operation	101
7.2	Outdoor Unit Rotation.....	101
7.3	Oil Return Operation	103
7.4	Defrost Operation	104
7.5	Drain Pan Heater (Option).....	104
8.	Outline of Control (Indoor Unit)	105
8.1	Operation Flowchart.....	105
8.2	Set Temperature and Control Temperature	109
8.3	Remote Controller Thermistor	111
8.4	Thermostat Control.....	113
8.5	Drain Pump Control.....	116
8.6	Control of Electronic Expansion Valve	118
8.7	Freeze-up Prevention.....	119
8.8	List of Swing Flap Operations	121
8.9	Hot Start Control (In Heating Only)	122
8.10	Louver Control for Preventing Ceiling Dirt.....	123
8.11	Heater Control (Except FXTQ-TA Models).....	124
8.12	Heater Control (FXTQ-TA Models).....	125
8.13	Gas Furnace Control (CXTQ-TA Models)	128
8.14	3-Step Thermostat Processing (FXTQ-TA Models)	129
8.15	Fan Control (Heater Residual) (FXTQ-TA Models)	130
8.16	Interlocked with External Equipment (FXTQ-TA and CXTQ-TA Models)	130

Part 5 Field Settings and Test Operation..... 132

1.	Field Settings for Indoor Unit.....	133
1.1	Field Settings with Remote Controller	133
1.2	Wireless Remote Controller	135
1.3	Simplified Remote Controller.....	136
1.4	List of Field Settings for Indoor Unit	137
1.5	Gas Furnace Set Up.....	156
1.6	List of Field Settings for Outdoor-Air Processing Unit	157
1.7	Setting of Operation Control Mode.....	157
2.	Field Settings for Outdoor Unit	159
2.1	Function Setting	159
2.2	Settings by DIP Switches	161
2.3	Accessing the BS Buttons on the PCB.....	164
2.4	Settings by BS Buttons.....	165
2.5	Normal Mode	167
2.6	Monitor Mode (Mode 1)	168
2.7	Setting Mode (Mode 2).....	172
3.	Test Operation	190
3.1	Checks before Test Operation	190
3.2	Checkpoints.....	190

3.3	Check Work Prior to Turn Power Supply ON	191
3.4	Turn Power ON	192
3.5	Gas Furnace Test Operation	193

Part 6 Service Diagnosis..... 194


1.	Symptom-based Troubleshooting	197
1.1	Indoor Unit Overall	197
1.2	With Gas Furnace	200
1.3	Gas Furnace Lockout Reset.....	200
1.4	With Optional Infrared Presence/Floor Sensor.....	201
2.	Troubleshooting with Remote Controller	202
2.1	Wired Remote Controller.....	202
2.2	Wireless Remote Controller	203
3.	Troubleshooting by Error Code	205
3.1	Error Codes and Descriptions	205
3.2	Error Codes - Sub Codes	207
3.3	External Protection Device Abnormality	219
3.4	Indoor Unit PCB Abnormality	221
3.5	Drain Level Control System Abnormality.....	222
3.6	Fan Motor Lock, Overload.....	224
3.7	Indoor Fan Motor Abnormality.....	226
3.8	Overload/Overcurrent/Lock of Indoor Fan Motor.....	230
3.9	Blower Motor Not Running	231
3.10	Indoor Fan Motor Status Abnormality.....	232
3.11	Low Indoor Airflow.....	233
3.12	Swing Flap Motor Abnormality	234
3.13	Power Supply Voltage Abnormality	236
3.14	Blower Motor Stops for Over/Under Voltage.....	237
3.15	Electronic Expansion Valve Coil Abnormality, Dust Clogging	238
3.16	Gas Furnace Abnormality.....	239
3.17	Drain Level above Limit.....	240
3.18	Capacity Determination Device Abnormality	241
3.19	Transmission Abnormality between Indoor Unit PCB and Fan PCB.....	242
3.20	Blower Motor Communication Error	244
3.21	Climate Talk Communication Error	245
3.22	Thermistor Abnormality	246
3.23	Combination Error between Indoor Unit Control PCB and Fan PCB	247
3.24	Blower Motor HP Mismatch.....	248
3.25	Indoor Blower Does Not Have Required Parameters to Function.....	249
3.26	Remote Sensor Abnormality	250
3.27	Humidity Sensor System Abnormality	251
3.28	Infrared Presence/Floor Sensor Error	252
3.29	Remote Controller Thermistor Abnormality	257
3.30	Outdoor Unit Main PCB Abnormality	258
3.31	Current Leakage Detection	259
3.32	Missing of Leakage Detection Core	260
3.33	Activation of High Pressure Switch	261

3.34	Activation of Low Pressure Sensor	263
3.35	Compressor Motor Lock.....	264
3.36	Compressor Damage Alarm.....	266
3.37	Outdoor Fan Motor Abnormality	268
3.38	Electronic Expansion Valve Coil Abnormality.....	271
3.39	Discharge Pipe Temperature Abnormality	273
3.40	Wet Alarm.....	275
3.41	Refrigerant Overcharged.....	277
3.42	Harness Abnormality (between Outdoor Unit Main PCB and Inverter PCB)	278
3.43	Outdoor Fan Motor Signal Abnormality	279
3.44	Thermistor Abnormality	280
3.45	High Pressure Sensor Abnormality	282
3.46	Low Pressure Sensor Abnormality	284
3.47	Inverter PCB Abnormality.....	286
3.48	Reactor Temperature Rise Abnormality	288
3.49	Inverter Radiation Fin Temperature Rise Abnormality	289
3.50	Compressor Instantaneous Overcurrent	290
3.51	Compressor Overcurrent.....	292
3.52	Compressor Startup Abnormality	294
3.53	Transmission Error between Inverter PCB and Outdoor Unit Main PCB.....	297
3.54	Power Supply Voltage Imbalance	299
3.55	Reactor Temperature Abnormality	301
3.56	Inverter Radiation Fin Temperature Abnormality	302
3.57	Field Setting after Replacing Outdoor Unit Main PCB Abnormality or Combination of PCB Abnormality.....	304
3.58	Refrigerant Shortage	305
3.59	Reverse Phase, Open Phase.....	306
3.60	Power Supply Insufficient or Instantaneous Abnormality	307
3.61	Check Operation not Executed	310
3.62	Transmission Error between Indoor Units and Outdoor Units.....	311
3.63	Transmission Error between Remote Controller and Indoor Unit.....	314
3.64	Transmission Error between Outdoor Units	315
3.65	Transmission Error between Main and Sub Remote Controllers	321
3.66	Transmission Error between Indoor Unit and Outdoor Unit in the Same System.....	322
3.67	Improper Combination of Indoor Unit and Outdoor Unit, Indoor Unit and Remote Controller.....	323
3.68	Incorrect Gas Furnace Connecting Number.....	328
3.69	Incorrect Electric Heater Capacity Setting.....	329
3.70	Address Duplication of Centralized Controller.....	330
3.71	Transmission Error between Centralized Controller and Indoor Unit	331
3.72	System Not Set Yet.....	334
3.73	System Abnormality, Refrigerant System Address Undefined	335
3.74	Climate Talk Communication System Combination Error (Before Initial Setting for Communication Completes)	337

3.75 Climate Talk Communication System Combination Error (After Initial Setting for Communication Completes)	338
4. Check	339
4.1 High Pressure Check	339
4.2 Low Pressure Check	340
4.3 Superheat Operation Check	342
4.4 Power Transistor Check	344
4.5 Refrigerant Overcharge Check	345
4.6 Refrigerant Shortage Check	346
4.7 Vacuuming and Dehydration Procedure	347
4.8 Thermistor Check	348
4.9 Pressure Sensor Check	351
4.10 Broken Wire Check of the Relay Wires	352
4.11 Fan Motor Connector Check (Power Supply Cable)	353
4.12 Fan Motor Connector Check (Signal Cable)	354
4.13 Electronic Expansion Valve Coil Check	356
4.14 Fan Motor Connector Check for FXTQ-TA	358
Part 7 Appendix	362
1. Wiring Diagrams	363
1.1 Outdoor Unit	363
1.2 Indoor Unit	369
1.3 Air Treatment Equipment	383

1. Safety Cautions

Be sure to read the following safety cautions before conducting repair work. After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.









Caution Items







The caution items are classified into **Warning** and **Caution**. The **Warning** items are especially important since death or serious injury can result if they are not followed closely. The **Caution** items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.






Pictograms





- △ This symbol indicates the item for which caution must be exercised.
The pictogram shows the item to which attention must be paid.
- This symbol indicates the prohibited action.
The prohibited item or action is shown in the illustration or near the symbol.
- This symbol indicates the action that must be taken, or the instruction.
The instruction is shown in the illustration or near the symbol.

1.1 Warnings and Cautions Regarding Safety of Workers







 Warning	
<p>Do not store the equipment in a room with fire sources (e.g. naked flames, gas appliances, electric heaters).</p>	
<p>Be sure to disconnect the power cable from the socket before disassembling equipment for repair. Working on equipment that is connected to the power supply may cause an electrical shock. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.</p>	
<p>If refrigerant gas is discharged during repair work, do not touch the discharged refrigerant gas. Refrigerant gas may cause frostbite.</p>	
<p>When disconnecting the suction or discharge pipe of the compressor at the welded section, evacuate the refrigerant gas completely at a well-ventilated place first. If there is gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it may cause injury.</p>	
<p>If refrigerant gas leaks during repair work, ventilate the area. Refrigerant gas may generate toxic gases when it contacts flames.</p>	










 Warning	
<p>Be sure to discharge the capacitor completely before conducting repair work. The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. A charged capacitor may cause an electrical shock.</p>	
<p>Do not turn the air conditioner on or off by plugging in or unplugging the power cable. Plugging or unplugging the power cable to operate the equipment may cause an electrical shock or fire.</p>	
<p>Be sure to wear a safety helmet, gloves, and a safety belt when working in a high place (more than 2 m (6.5 ft)). Insufficient safety measures may cause a fall.</p>	
<p>In case of R-410A refrigerant models, be sure to use pipes, flare nuts and tools intended for exclusive use with the R-410A refrigerant. The use of materials for other refrigerant models may cause a serious accident, such as damage to the refrigerant cycle or equipment failure.</p>	
<p>Do not mix air or gas other than the specified refrigerant (R-410A) in the refrigerant system. If air enters the refrigerating system, excessively high pressure results, causing equipment damage and injury.</p>	










 Caution	
<p>Do not repair electrical components with wet hands. Working on the equipment with wet hands may cause an electrical shock.</p>	
<p>Do not clean the air conditioner with water. Washing the unit with water may cause an electrical shock.</p>	
<p>Be sure to provide an earth/grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.</p>	
<p>Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and may cause injury.</p>	

 Caution	
Be sure to conduct repair work with appropriate tools. The use of inappropriate tools may cause injury.	
Be sure to check that the refrigerating cycle section has cooled down enough before conducting repair work. Working on the unit when the refrigerating cycle section is hot may cause burns.	
Conduct welding work in a well-ventilated place. Using a welder in an enclosed room may cause oxygen deficiency.	

1.2 Warnings and Cautions Regarding Safety of Users





 Warning	
Do not store the equipment in a room with fire sources (e.g. naked flames, gas appliances, electric heaters).	
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools may cause an electrical shock, excessive heat generation or fire.	
If the power cable and lead wires are scratched or have deteriorated, be sure to replace them. Damaged cable and wires may cause an electrical shock, excessive heat generation or fire.	
Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it may cause an electrical shock, excessive heat generation or fire.	
Be sure to use an exclusive power circuit for the equipment, and follow the local technical standards related to the electrical equipment, the internal wiring regulations, and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work may cause an electrical shock or fire.	

 Warning	
<p>Be sure to use the specified cable for wiring between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections may cause excessive heat generation or fire.</p>	
<p>When wiring between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Do not damage or modify the power cable. Damaged or modified power cables may cause an electrical shock or fire. Placing heavy items on the power cable, or heating or pulling the power cable may damage it.</p>	
<p>Do not mix air or gas other than the specified refrigerant (R-410A) in the refrigerant system. If air enters the refrigerating system, excessively high pressure results, causing equipment damage and injury.</p>	
<p>If the refrigerant gas leaks, be sure to locate the leakage and repair it before charging the refrigerant. After charging the refrigerant, make sure that there is no leakage. If the leakage cannot be located and the repair work must be stopped, be sure to pump-down, and close the service valve, to prevent refrigerant gas from leaking into the room. Refrigerant gas itself is harmless, but it may generate toxic gases when it contacts flames, such as those from fan type and other heaters, stoves and ranges.</p>	
<p>When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength or if the installation work is not conducted securely, the equipment may fall and cause injury.</p>	
<p>Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet securely. If the plug is dusty or has a loose connection, it may cause an electrical shock or fire.</p>	
<p>When replacing the coin battery in the remote controller, be sure to dispose of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.</p>	

 Caution	
<p>Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.</p>	
<p>Do not install the equipment in a place where there is a possibility of combustible gas leaks. If combustible gas leaks and remains around the unit, it may cause a fire.</p>	
<p>Check to see if parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections may cause excessive heat generation, fire or an electrical shock.</p>	
<p>If the installation platform or frame has corroded, replace it. A corroded installation platform or frame may cause the unit to fall, resulting in injury.</p>	
<p>Check the earth/grounding, and repair it if the equipment is not properly earthed/grounded. Improper earth/grounding may cause an electrical shock.</p>	
<p>Be sure to measure insulation resistance after the repair, and make sure that the resistance is 1 MΩ or greater. Faulty insulation may cause an electrical shock.</p>	
<p>Be sure to check the drainage of the indoor unit after the repair. Faulty drainage may cause water to enter the room and wet the furniture and floor.</p>	
<p>Do not tilt the unit when removing it. The water inside the unit may spill and wet the furniture and floor.</p>	

2. Icons Used

The following icons are used to attract the attention of the reader to specific information.

Icon	Type of Information	Description
 Warning	Warning	A Warning is used when there is danger of personal injury.
 Caution	Caution	A Caution is used when there is danger that the reader, through incorrect manipulation, may damage equipment, loose data, get an unexpected result or has to restart (part of) a procedure.
 Note:	Note	A Note provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
	Reference	A Reference guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

Part 1

General Information

1. Model Names	2
1.1 Indoor Unit.....	2
1.2 Outdoor Unit	2
1.3 Air Treatment Equipment	3
2. External Appearance.....	4
2.1 Indoor Unit.....	4
2.2 Outdoor Unit	5
2.3 Air Treatment Equipment	5
3. Combination of Outdoor Units	6
4. Capacity Range.....	7
4.1 Combination Ratio	7
4.2 Outdoor Unit Combinations	7
5. Specifications	8
5.1 RXYQ-XATJA.....	8
5.2 RXYQ-XAYDA.....	23

1. Model Names

1.1 Indoor Unit

Capacity range (ton)		0.5	0.6	0.8	1	1.25	1.5	2	2.5	3	3.5	4	4.5	5	6	8	Power supply, Standard
Capacity index		5.8	7.5	9.5	12	15	18	20	24	30	36	42	48	54	60	72	
Ceiling mounted cassette (Round flow with sensing) type	FXFQ	—	07T	09T	12T	15T	18T	—	24T	30T	36T	—	48T	—	—	—	VJU*
VISTA™ 2'x2' cassette type	FXZQ	05TA	07TA	09TA	12TA	15TA	18TA	—	—	—	—	—	—	—	—	—	
4 way blow ceiling suspended type	FXUQ	—	—	—	—	—	—	18P	24P	30P	36P	—	—	—	—	—	
One way blow cassette type	FXEQ	—	07P	09P	12P	15P	18P	—	24P	—	—	—	—	—	—	—	
Slim ceiling mounted duct type	FXDQ	—	07M	09M	12M	—	18M	—	24M	—	—	—	—	—	—	—	
MSP concealed ducted type	FXSQ	05TA	07TA	09TA	12TA	15TA	18TA	—	24TA	30TA	36TA	—	48TA	54TA	—	—	
Ceiling mounted duct type (Middle and high static pressure)	FXMQ	—	07PB	09PB	12PB	15PB	18PB	—	24PB	30PB	36PB	—	48PB	54PB	—	—	
Ceiling mounted duct type	FXMQ	—	—	—	—	—	—	—	—	—	—	—	—	—	72M	96M	
Ceiling suspended type	FXHQ	—	—	—	12M	—	—	—	24M	—	36M	—	—	—	—	—	
Wall mounted type	FXAQ	—	07P	09P	12P	—	18P	—	24P	—	—	—	—	—	—	—	
Floor standing type	FXLQ	—	07M	09M	12M	—	18M	—	24M	—	—	—	—	—	—	—	
Concealed floor standing type	FXNQ	—	07M	09M	12M	—	18M	—	24M	—	—	—	—	—	—	—	
Air handling unit	FXTQ	—	—	09TA	12TA	—	18TA	—	24TA	30TA	36TA	42TA	48TA	54TA	60TA	—	
		—	—	09TA	12TA	—	18TA	—	24TA	30TA	36TA	42TA	48TA	54TA	60TA	—	VJUD*
Cased Coil Unit	CXTQ	—	—	—	—	—	—	—	24TA	—	36TA	—	48TA	—	60TA	—	SBLU*

VJ : 1 phase, 208/230 V, 60 Hz

SBL : 1 phase, 115 V, 60 Hz

U : Standard Symbol

1.2 Outdoor Unit

Capacity Range (ton)		6	8	10	12	14	16	18	20	Power Supply, Standard	
Capacity Index		72	96	120	144	168	192	216	240		
Heat Pump	208/230 V	RXYQ	72XA	96XA	120XA	144XA	168XA	192XA	216XA	240XA	TJA
	460 V	RXYQ	72XA	96XA	120XA	144XA	168XA	192XA	216XA	240XA	YDA
Capacity Range (ton)		22	24	26	28	30	32	34	Power Supply, Standard		
Capacity Index		264	288	312	336	360	384	408			
Heat Pump	208/230 V	RXYQ	264XA	288XA	312XA	336XA	360XA	384XA	408XA	TJA	
	460 V	RXYQ	264XA	288XA	312XA	336XA	360XA	384XA	408XA	YDA	

TJ : 3 phase, 208/230 V, 60 Hz

YD : 3 phase, 460 V, 60 Hz

A : Minor Revision

Combination of RXYQ-XATJA

Model name	RXYQ72XATJA	RXYQ96XATJA	RXYQ120XATJA	RXYQ144XATJA	RXYQ168XATJA
Outdoor unit 1	RXYQ72XATJA	RXYQ96XATJA	RXYQ120XATJA	RXYQ144XATJA	RXYQ168XATJA
Model name	RXYQ192XATJA	RXYQ216XATJA	RXYQ240XATJA	RXYQ264XATJA	RXYQ288XATJA
Outdoor unit 1	RXYQ72XATJA	RXYQ96XATJA	RXYQ120XATJA	RXYQ120XATJA	RXYQ144XATJA
Outdoor unit 2	RXYQ120XATJA	RXYQ120XATJA	RXYQ120XATJA	RXYQ144XATJA	RXYQ144XATJA
Model name	RXYQ312XATJA	RXYQ336XATJA	RXYQ360XATJA	RXYQ384XATJA	RXYQ408XATJA
Outdoor unit 1	RXYQ144XATJA	RXYQ168XATJA	RXYQ120XATJA	RXYQ96XATJA	RXYQ96XATJA
Outdoor unit 2	RXYQ168XATJA	RXYQ168XATJA	RXYQ120XATJA	RXYQ120XATJA	RXYQ144XATJA
Outdoor unit 3	—	—	RXYQ120XATJA	RXYQ168XATJA	RXYQ168XATJA

Combination of RXYQ-XAYDA

Model name	RXYQ72XAYDA	RXYQ96XAYDA	RXYQ120XAYDA	RXYQ144XAYDA	RXYQ168XAYDA
Outdoor unit 1	RXYQ72XAYDA	RXYQ96XAYDA	RXYQ120XAYDA	RXYQ144XAYDA	RXYQ168XAYDA
Model name	RXYQ192XAYDA	RXYQ216XAYDA	RXYQ240XAYDA	RXYQ264XAYDA	RXYQ288XAYDA
Outdoor unit 1	RXYQ72XAYDA	RXYQ96XAYDA	RXYQ120XAYDA	RXYQ120XAYDA	RXYQ144XAYDA
Outdoor unit 2	RXYQ120XAYDA	RXYQ120XAYDA	RXYQ120XAYDA	RXYQ144XAYDA	RXYQ144XAYDA
Model name	RXYQ312XAYDA	RXYQ336XAYDA	RXYQ360XAYDA	RXYQ384XAYDA	RXYQ408XAYDA
Outdoor unit 1	RXYQ144XAYDA	RXYQ168XAYDA	RXYQ120XAYDA	RXYQ96XAYDA	RXYQ96XAYDA
Outdoor unit 2	RXYQ168XAYDA	RXYQ168XAYDA	RXYQ120XAYDA	RXYQ120XAYDA	RXYQ144XAYDA
Outdoor unit 3	—	—	RXYQ120XAYDA	RXYQ168XAYDA	RXYQ168XAYDA

1.3 Air Treatment Equipment

Outdoor-Air Processing Unit

Series	Model Name			Power Supply, Standard
FXMQ	48MF	72MF	96MF	VJU*

Energy Recovery Ventilator (VAM Series)
















Series	Model Name				Power Supply, Standard
VAM	300G	470G	600G	1200G	VJU*

VJ : 1 phase, 208/230 V, 60 Hz

U : Standard Symbol


2. External Appearance

2.1 Indoor Unit


<p>Ceiling mounted cassette (Round flow with sensing) type</p> <p>FXFQ-T</p>  <p>Shown with BYCQ125B-W1</p>	<p>Ceiling mounted duct type</p> <p>FXMQ-M</p> 
<p>VISTA™ 2'x2' cassette type</p> <p>FXZQ-TA</p>   <p>Shown with BYFQ60C3W1W Shown with BYFQ60C3W1S</p>	<p>Ceiling suspended type</p> <p>FXHQ-M</p> 
<p>4 way blow ceiling suspended type</p> <p>FXUQ-P</p> 	<p>Wall mounted type</p> <p>FXAQ-P</p> 
<p>One way blow cassette type</p> <p>FXEQ-P</p> 	<p>Floor standing type</p> <p>FXLQ-M</p> 
<p>Slim ceiling mounted duct type</p> <p>FXDQ-M</p> 	<p>Concealed floor standing type</p> <p>FXNQ-M</p> 
<p>MSP concealed ducted type</p> <p>FXSQ-TA</p> 	<p>Air handling unit</p> <p>FXTQ-TA</p> 
<p>Ceiling mounted duct type (Middle and high static pressure)</p> <p>FXMQ-PB</p> 	<p>Cased coil unit</p> <p>CXTQ-TA</p> 

2.2 Outdoor Unit


Single Outdoor Unit




Double Outdoor Unit



Triple Outdoor Unit



2.3 Air Treatment Equipment



3. Combination of Outdoor Units

System capacity ton	Number of units	Module					Outdoor Unit Multi Connection Piping Kit ★1
		72	96	120	144	168	
6	1	●					—
8	1		●				
10	1			●			
12	1				●		
14	1					●	
16	2	●		●			BHFP22P100U BHFP22P100UA
18	2		●	●			
20	2			●●			
22	2			●	●		
24	2				●●		
26	2				●	●	
28	2					●●	
30	3			●●●			BHFP22P151U BHFP22P151UA
32	3		●	●		●	
34	3		●		●	●	

Note: ★1 For multiple connection, the outdoor unit multi connection piping kit (separately sold) is required.

4. Capacity Range

4.1 Combination Ratio

$$\text{Combination ratio} = \frac{\text{Total capacity index of the indoor units}}{\text{Capacity index of the outdoor units}}$$

Type	Min. combination ratio	Max. combination ratio				
		Types of connected indoor units			Type of connected air treatment equipments	
		When using only FXDQ-M, FXSQ07-54TA, FXMQ-PB, FXAQ-P	When using at least one FXFQ07/09T, FXZQ05TA, FXSQ05TA	Other indoor unit models	FXMQ-MF	
					When FXMQ-MF is only connected	When FXMQ-MF and indoor units are connected
Single outdoor units	50%	200% *1	180% *1	200% *1	100%	100% *2
Double outdoor units			160% *1	160% *1		
Triple outdoor units			130%	130%		

- Notes:** *1. If the operational capacity of indoor units is more than 130%, low airflow operation is enforced in all the indoor units. This limitation can be deactivated through field setting. Refer to page 184 for detail.
*2. When outdoor-air processing units (FXMQ-MF) and standard indoor units are connected, the total connection capacity of the outdoor-air processing units (FXMQ-MF) must not exceed 30% of the capacity index of the outdoor units. And the connection ratio must not exceed 100%.

4.2 Outdoor Unit Combinations

Capacity Range	6 ton	8 ton	10 ton	12 ton	14 ton	16 ton	18 ton	20 ton
RXYQ	72XATJA 72XAYDA	96XATJA 96XAYDA	120XATJA 120XAYDA	144XATJA 144XAYDA	168XATJA 168XAYDA	192XATJA 192XAYDA	216XATJA 216XAYDA	240XATJA 240XAYDA
Max. Number of Connectable Indoor Units	12	16	20	25	29	33	37	41
Total Capacity Index of Indoor Units to be Connected *1	36~93 (144)	48~124 (192)	60~156 (240)	72~187 (288)	84~218 (336)	96~249 (307)	108~280 (345)	120~312 (384)
Capacity Range	22 ton	24 ton	26 ton	28 ton	30 ton	32 ton	34 ton	
RXYQ	264XATJA 264XAYDA	288XATJA 288XAYDA	312XATJA 312XAYDA	336XATJA 336XAYDA	360XATJA 360XAYDA	384XATJA 384XAYDA	408XATJA 408XAYDA	
Max. Number of Connectable Indoor Units	45	49	54	58	62	64	64	
Total Capacity Index of Indoor Units to be Connected *1	132~343 (422)	144~374 (460)	156~405 (499)	168~436 (537)	180~468 (468)	192~499 (499)	204~530 (530)	

- Note:** *1. Values inside brackets are based on connection of indoor units rated at maximum capacity, 200% for single outdoor units, 160% for double outdoor units, and 130% for triple outdoor units.

5. Specifications

5.1 RXYQ-XATJA

Model name			RXYQ72XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	72,000 (21.1)
	Rated		69,000 (20.2)
★2 Heating capacity	Nominal	Btu/h (kW)	81,000 (23.7)
	Rated		73,000 (21.4)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 36-11/16 × 30-3/16 (1,694 × 932 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	14.7
	Number of revolutions	r/min	6,954
	Motor output × Number of units	kW	4.2 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.75 × 1
	Airflow rate	cfm (m ³ /min)	5,544 (157)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/8 (9.5) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
Weight		lbs (kg)	435 (198)
Sound pressure level (Reference data)		dB (A)	58
Sound power level (Reference data)		dB	78
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	20-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	13.0 (5.9)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122720

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
 ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name			RXYQ96XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	96,000 (28.1)
	Rated		92,000 (27.0)
★2 Heating capacity	Nominal	Btu/h (kW)	108,000 (31.7)
	Rated		103,000 (30.2)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H x W x D)		in (mm)	66-11/16 x 48-7/8 x 30-3/16 (1,694 x 1,242 x 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	19.3
	Number of revolutions	r/min	6,072
	Motor output x Number of units	kW	6.3 x 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.35 x 2
	Airflow rate	cfm (m ³ /min)	5,827 (165)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ3/8 (9.5) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ7/8 (22.2) C1220T (Brazing connection)
Weight		lbs (kg)	525 (238)
Sound pressure level (Reference data)		dB (A)	61
Sound power level (Reference data)		dB	81
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	16-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.7 (10.3)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122720

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name			RXYQ120XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	120,000 (35.2)
	Rated		114,000 (33.4)
★2 Heating capacity	Nominal	Btu/h (kW)	135,000 (39.6)
	Rated		129,000 (37.8)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	26.6
	Number of revolutions	r/min	8,346
	Motor output × Number of units	kW	8.7 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.35 × 2
	Airflow rate	cfm (m ³ /min)	6,286 (178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ1/2 (12.7) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	528 (239)
Sound pressure level (Reference data)		dB (A)	61
Sound power level (Reference data)		dB	81
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	15-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.9 (10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122720

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name			RXYQ144XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	144,000 (42.2)
	Rated		138,000 (40.4)
★2 Heating capacity	Nominal	Btu/h (kW)	162,000 (47.5)
	Rated		154,000 (45.1)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	15.2 + 15.2
	Number of revolutions	r/min	7,158 + 7,158
	Motor output × Number of units	kW	(4.4 × 1) + (4.4 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.75 × 2
	Airflow rate	cfm (m ³ /min)	8,228 (233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ1/2 (12.7) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	695 (315)
Sound pressure level (Reference data)		dB (A)	64
Sound power level (Reference data)		dB	86
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	11-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	18.1 (8.2)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122720

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name			RXYQ168XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	164,000 (48.1)
	Rated		158,000 (46.3)
★2 Heating capacity	Nominal	Btu/h (kW)	188,000 (55.1)
	Rated		174,000 (51.0)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	17.6 + 17.6
	Number of revolutions	r/min	8,304 + 8,304
	Motor output × Number of units	kW	(5.1 × 1) + (5.1 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.75 × 2
	Airflow rate	cfm (m ³ /min)	8,228 (233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ5/8 (15.9) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	695 (315)
Sound pressure level (Reference data)		dB (A)	65
Sound power level (Reference data)		dB	86
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	10-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	17.2 (7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122720

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ192XATJA
Model name (Independent unit)			RXYQ72XATJA RXYQ120XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	192,000 (56.3)
	Rated		184,000 (53.9)
★2 Heating capacity	Nominal	Btu/h (kW)	216,000 (63.3)
	Rated		206,000 (60.4)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 36-11/16 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 932 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	17.7 + 21.9
	Number of revolutions	r/min	8,334 + 6,864
	Motor output × Number of units	kW	5.1 × 1 + 7.2 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.75 × 1 + 0.35 × 2
	Airflow rate	cfm (m ³ /min)	5,544 + 6,286 (157 + 178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ5/8 (15.9) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	435 + 528 (198 + 239)
Sound pressure level (Reference data)		dB (A)	63
Sound power level (Reference data)		dB	83
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	17-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	13.0 + 22.9 (5.9 + 10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122721A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ216XATJA
Model name (Independent unit)			RXYQ96XATJA RXYQ120XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	216,000 (63.3)
	Rated		206,000 (60.4)
★2 Heating capacity	Nominal	Btu/h (kW)	243,000 (71.2)
	Rated		230,000 (67.4)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	21.1 + 21.1
	Number of revolutions	r/min	6,630 + 6,630
	Motor output × Number of units	kW	6.9 × 1 + 6.9 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.35 × 2 + 0.35 × 2
	Airflow rate	cfm (m ³ /min)	5,827 + 6,286 (165 + 178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ5/8 (15.9) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	525 + 528 (238 + 239)
Sound pressure level (Reference data)		dB (A)	64
Sound power level (Reference data)		dB	84
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	15-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.7 + 22.9 (10.3 + 10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122721A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ240XATJA
Model name (Independent unit)			RXYQ120XATJA RXYQ120XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	240,000 (70.3)
	Rated		228,000 (66.8)
★2 Heating capacity	Nominal	Btu/h (kW)	270,000 (79.1)
	Rated		256,000 (75.0)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	24.1 + 24.1
	Number of revolutions	r/min	7,572 + 7,572
	Motor output × Number of units	kW	7.9 × 1 + 7.9 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.35 × 2 + 0.35 × 2
	Airflow rate	cfm (m ³ /min)	6,286 + 6,286 (178 + 178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ5/8 (15.9) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	528 + 528 (239 + 239)
Sound pressure level (Reference data)		dB (A)	64
Sound power level (Reference data)		dB	84
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	15-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.9 + 22.9 (10.4 + 10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122721A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ264XATJA
Model name (Independent unit)			RXYQ120XATJA RXYQ144XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	264,000 (77.4)
	Rated		252,000 (73.9)
★2 Heating capacity	Nominal	Btu/h (kW)	297,000 (87.0)
	Rated		282,000 (82.6)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	22.6 + (14.9 + 14.9)
	Number of revolutions	r/min	7,098 + (7,026 + 7,026)
	Motor output × Number of units	kW	7.4 × 1 + (4.3 × 1 + 4.3 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.35 × 2 + 0.75 × 2
	Airflow rate	cfm (m ³ /min)	6,286 + 8,228 (178 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	528 + 695 (239 + 315)
Sound pressure level (Reference data)		dB (A)	66
Sound power level (Reference data)		dB	87
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	13-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.9 + 18.1 (10.4 + 8.2)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122721A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ288XATJA
Model name (Independent unit)			RXYQ144XATJA RXYQ144XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	288,000 (84.4)
	Rated		274,000 (80.3)
★2 Heating capacity	Nominal	Btu/h (kW)	324,000 (95.0)
	Rated		308,000 (90.3)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	(14.1 + 14.1) + (14.1 + 14.1)
	Number of revolutions	r/min	(6,648 + 6,648) + (6,648 + 6,648)
	Motor output × Number of units	kW	(4.1 × 1 + 4.1 × 1) + (4.1 × 1 + 4.1 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.75 × 2) × 2
	Airflow rate	cfm (m ³ /min)	8,228 + 8,228 (233 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	695 + 695 (315 + 315)
Sound pressure level (Reference data)		dB (A)	67
Sound power level (Reference data)		dB	89
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	11-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	18.1 + 18.1 (8.2 + 8.2)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122721A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ312XATJA
Model name (Independent unit)			RXYQ144XATJA RXYQ168XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	312,000 (91.4)
	Rated		296,000 (86.7)
★2 Heating capacity	Nominal	Btu/h (kW)	351,000 (102.9)
	Rated		334,000 (97.9)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	(15.5 + 15.5) + (15.5 + 15.5)
	Number of revolutions	r/min	(7,326 + 7,326) + (7,326 + 7,326)
	Motor output × Number of units	kW	(4.5 × 1 + 4.5 × 1) + (4.5 × 1 + 4.5 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.75 × 2) × 2
	Airflow rate	cfm (m ³ /min)	8,228 + 8,228 (233 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	695 + 695 (315 + 315)
Sound pressure level (Reference data)		dB (A)	67.5
Sound power level (Reference data)		dB	89
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	10-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	18.1 + 17.2 (8.2 + 7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122721A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ336XATJA
Model name (Independent unit)			RXYQ168XATJA RXYQ168XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	326,000 (95.5)
	Rated		312,000 (91.4)
★2 Heating capacity	Nominal	Btu/h (kW)	378,000 (110.8)
	Rated		342,000 (100.2)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	(16.0 + 16.0) + (16.0 + 16.0)
	Number of revolutions	r/min	(7,542 + 7,542) + (7,542 + 7,542)
	Motor output × Number of units	kW	(4.6 × 1 + 4.6 × 1) + (4.6 × 1 + 4.6 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.75 × 2) × 2
	Airflow rate	cfm (m ³ /min)	8,228 + 8,228 (233 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	695 + 695 (315 + 315)
Sound pressure level (Reference data)		dB (A)	68
Sound power level (Reference data)		dB	89
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	10-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	17.2 + 17.2 (7.8 + 7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122721A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ360XATJA
Model name (Independent unit)			RXYQ120XATJA RXYQ120XATJA RXYQ120XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	360,000 (105.5)
	Rated		342,000 (100.2)
★2 Heating capacity	Nominal	Btu/h (kW)	405,000 (118.7)
	Rated		372,000 (109.0)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	23.4 + 23.4 + 23.4
	Number of revolutions	r/min	7,338 + 7,338 + 7,338
	Motor output × Number of units	kW	7.6 × 1 + 7.6 × 1 + 7.6 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.35 × 2) × 3
	Airflow rate	cfm (m ³ /min)	6,286 + 6,286 + 6,286 (178 + 178 + 178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-5/8 (41.3) C1220T (Brazing connection)
Weight		lbs (kg)	528 + 528 + 528 (239 + 239 + 239)
Sound pressure level (Reference data)		dB (A)	66
Sound power level (Reference data)		dB	86
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	15-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.9 + 22.9 + 22.9 (10.4 + 10.4 + 10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122722A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ384XATJA	
Model name (Independent unit)			RXYQ96XATJA RXYQ120XATJA RXYQ168XATJA	
Power supply			3 phase, 208/230 V, 60 Hz	
★1 Cooling capacity	Nominal	Btu/h (kW)	368,000 (107.9)	
	Rated		356,000 (104.3)	
★2 Heating capacity	Nominal	Btu/h (kW)	432,000 (126.6)	
	Rated		396,000 (116.1)	
Casing color			Ivory white (5Y7.5/1)	
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)	
Heat exchanger			Cross fin coil	
Compressor	Type		Hermetically sealed scroll type	
	Displacement	m ³ /h	22.7 + 22.7 + (14.6 + 14.6)	
	Number of revolutions		r/min	7,134 + 7,134 + (6,900 + 6,900)
	Motor output × Number of units		kW	7.4 × 1 + 7.4 × 1 + (4.2 × 1 + 4.2 × 1)
	Starting method			Soft start
Fan	Type		Propeller fan	
	Motor output	kW	0.35 × 2 + 0.35 × 2 + 0.75 × 2	
	Airflow rate	cfm (m ³ /min)	5,827 + 6,286 + 8,228 (165 + 178 + 233)	
	Drive			Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)	
	Gas pipe	in (mm)	φ1-5/8 (41.3) C1220T (Brazing connection)	
Weight		lbs (kg)	525 + 528 + 695 (238 + 239 + 315)	
Sound pressure level (Reference data)		dB (A)	67.5	
Sound power level (Reference data)		dB	88	
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device	
Defrost method			Deicer	
Capacity control		%	13-100	
Refrigerant	Refrigerant name		R-410A	
	Charge	lbs (kg)	22.7 + 22.9 + 17.2 (10.3 + 10.4 + 7.8)	
	Control			Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps	
Drawing No.	Specification		C: 3D122722A	

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ408XATJA
Model name (Independent unit)			RXYQ96XATJA RXYQ144XATJA RXYQ168XATJA
Power supply			3 phase, 208/230 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h	390,000 (114.3)
	Rated	(kW)	372,000 (109.0)
★2 Heating capacity	Nominal	Btu/h	459,000 (134.5)
	Rated	(kW)	424,000 (124.3)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	22.4 + (14.2 + 14.2) + (14.2 + 14.2)
	Number of revolutions	r/min	7,038 + (6,684 + 6,684) + (6,684 + 6,684)
	Motor output × Number of units	kW	7.3 × 1 + (4.1 × 1 + 4.1 × 1) + (4.1 × 1 + 4.1 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.35 × 2 + 0.75 × 2 + 0.75 × 2
	Airflow rate	cfm (m ³ /min)	5,827 + 8,228 + 8,228 (165 + 233 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-5/8 (41.3) C1220T (Brazing connection)
Weight		lbs (kg)	525 + 695 + 695 (238 + 315 + 315)
Sound pressure level (Reference data)		dB (A)	68.5
Sound power level (Reference data)		dB	89.5
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	12-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.7 + 18.1 + 17.2 (10.3 + 8.2 + 7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122722A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

5.2 RXYQ-XAYDA

Model name			RXYQ72XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	72,000 (21.1)
	Rated		69,000 (20.2)
★2 Heating capacity	Nominal	Btu/h (kW)	81,000 (23.7)
	Rated		73,000 (21.4)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 36-11/16 × 30-3/16 (1,694 × 932 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	14.7
	Number of revolutions	r/min	6,954
	Motor output × Number of units	kW	4.2 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.5 × 1
	Airflow rate	cfm (m ³ /min)	5,544 (157)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/8 (9.5) C1220T (Braze connection)
	Gas pipe	in (mm)	φ3/4 (19.1) C1220T (Braze connection)
Weight		lbs (kg)	451 (205)
Sound pressure level (Reference data)		dB (A)	58
Sound power level (Reference data)		dB	78
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	20-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	13.0 (5.9)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122723

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
 ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name			RXYQ96XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	96,000 (28.1)
	Rated		92,000 (27.0)
★2 Heating capacity	Nominal	Btu/h (kW)	108,000 (31.7)
	Rated		103,000 (30.2)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	19.3
	Number of revolutions	r/min	6,072
	Motor output × Number of units	kW	6.3 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.6 × 2
	Airflow rate	cfm (m ³ /min)	5,827 (165)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ3/8 (9.5) C1220T (Braze connection)
	Gas pipe	in (mm)	ϕ7/8 (22.2) C1220T (Braze connection)
Weight		lbs (kg)	553 (251)
Sound pressure level (Reference data)		dB (A)	61
Sound power level (Reference data)		dB	81
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	16-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.7 (10.3)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122723

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name			RXYQ120XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	120,000 (35.2)
	Rated		114,000 (33.4)
★2 Heating capacity	Nominal	Btu/h (kW)	135,000 (39.6)
	Rated		129,000 (37.8)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H x W x D)		in (mm)	66-11/16 x 48-7/8 x 30-3/16 (1,694 x 1,242 x 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	26.6
	Number of revolutions	r/min	8,346
	Motor output x Number of units	kW	8.7 x 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.6 x 2
	Airflow rate	cfm (m ³ /min)	6,286 (178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ1/2 (12.7) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	556 (252)
Sound pressure level (Reference data)		dB (A)	61
Sound power level (Reference data)		dB	81
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	15-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.9 (10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122723

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name			RXYQ144XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	144,000 (42.2)
	Rated		138,000 (40.4)
★2 Heating capacity	Nominal	Btu/h (kW)	162,000 (47.5)
	Rated		154,000 (45.1)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	15.2 + 15.2
	Number of revolutions	r/min	7,158 + 7,158
	Motor output × Number of units	kW	(4.4 × 1) + (4.4 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.6 × 2
	Airflow rate	cfm (m ³ /min)	8,228 (233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ1/2 (12.7) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	709 (322)
Sound pressure level (Reference data)		dB (A)	64
Sound power level (Reference data)		dB	86
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	11-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	18.1 (8.2)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122723

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name			RXYQ168XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	164,000 (48.1)
	Rated		158,000 (46.3)
★2 Heating capacity	Nominal	Btu/h (kW)	188,000 (55.1)
	Rated		174,000 (51.0)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H x W x D)		in (mm)	66-11/16 x 48-7/8 x 30-3/16 (1,694 x 1,242 x 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	17.6 + 17.6
	Number of revolutions	r/min	8,304 + 8,304
	Motor output x Number of units	kW	(5.1 x 1) + (5.1 x 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.6 x 2
	Airflow rate	cfm (m ³ /min)	8,228 (233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ5/8 (15.9) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	709 (322)
Sound pressure level (Reference data)		dB (A)	65
Sound power level (Reference data)		dB	86
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	10-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	17.2 (7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122723

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ192XAYDA
Model name (Independent unit)			RXYQ72XAYDA RXYQ120XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	192,000 (56.3)
	Rated		184,000 (53.9)
★2 Heating capacity	Nominal	Btu/h (kW)	216,000 (63.3)
	Rated		206,000 (60.4)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 36-11/16 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 932 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	17.7 + 21.9
	Number of revolutions	r/min	8,334 + 6,864
	Motor output × Number of units	kW	5.1 × 1 + 7.2 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	0.5 × 1 + 0.6 × 2
	Airflow rate	cfm (m ³ /min)	5,544 + 6,286 (157 + 178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ5/8 (15.9) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	451 + 556 (205 + 252)
Sound pressure level (Reference data)		dB (A)	63
Sound power level (Reference data)		dB	83
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	17-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	13.0 + 22.9 (5.9 + 10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122724A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ216XAYDA
Model name (Independent unit)			RXYQ96XAYDA RXYQ120XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	216,000 (63.3)
	Rated		206,000 (60.4)
★2 Heating capacity	Nominal	Btu/h (kW)	243,000 (71.2)
	Rated		230,000 (67.4)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	21.1 + 21.1
	Number of revolutions	r/min	6,630 + 6,630
	Motor output × Number of units	kW	6.9 × 1 + 6.9 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 2
	Airflow rate	cfm (m ³ /min)	5,827 + 6,286 (165 + 178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ5/8 (15.9) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-1/8 (28.6) C1220T (Brazing connection)
Weight		lbs (kg)	553 + 556 (251 + 252)
Sound pressure level (Reference data)		dB (A)	64
Sound power level (Reference data)		dB	84
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	15-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.7 + 22.9 (10.3 + 10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122724A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ240XAYDA
Model name (Independent unit)			RXYQ120XAYDA RXYQ120XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	240,000 (70.3)
	Rated		228,000 (66.8)
★2 Heating capacity	Nominal	Btu/h (kW)	270,000 (79.1)
	Rated		256,000 (75.0)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	24.1 + 24.1
	Number of revolutions	r/min	7,572 + 7,572
	Motor output × Number of units	kW	7.9 × 1 + 7.9 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 2
	Airflow rate	cfm (m ³ /min)	6,286 + 6,286 (178 + 178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ5/8 (15.9) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	556 + 556 (252 + 252)
Sound pressure level (Reference data)		dB (A)	64
Sound power level (Reference data)		dB	84
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	15-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.9 + 22.9 (10.4 + 10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122724A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ264XAYDA
Model name (Independent unit)			RXYQ120XAYDA RXYQ144XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	264,000 (77.4)
	Rated		252,000 (73.9)
★2 Heating capacity	Nominal	Btu/h (kW)	297,000 (87.0)
	Rated		282,000 (82.6)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	22.6 + (14.9 + 14.9)
	Number of revolutions	r/min	7,098 + (7,026 + 7,026)
	Motor output × Number of units	kW	7.4 × 1 + (4.3 × 1 + 4.3 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 2
	Airflow rate	cfm (m ³ /min)	6,286 + 8,228 (178 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	556 + 709 (252 + 322)
Sound pressure level (Reference data)		dB (A)	66
Sound power level (Reference data)		dB	87
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	13-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.9 + 18.1 (10.4 + 8.2)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122724A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ288XAYDA
Model name (Independent unit)			RXYQ144XAYDA RXYQ144XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	288,000 (84.4)
	Rated		274,000 (80.3)
★2 Heating capacity	Nominal	Btu/h (kW)	324,000 (95.0)
	Rated		308,000 (90.3)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	(14.1 + 14.1) + (14.1 + 14.1)
	Number of revolutions	r/min	(6,648 + 6,648) + (6,648 + 6,648)
	Motor output × Number of units	kW	(4.1 × 1 + 4.1 × 1) + (4.1 × 1 + 4.1 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 2
	Airflow rate	cfm (m ³ /min)	8,228 + 8,228 (233 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	709 + 709 (322 + 322)
Sound pressure level (Reference data)		dB (A)	67
Sound power level (Reference data)		dB	89
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	11-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	18.1 + 18.1 (8.2 + 8.2)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122724A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ312XAYDA
Model name (Independent unit)			RXYQ144XAYDA RXYQ168XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	312,000 (91.4)
	Rated		296,000 (86.7)
★2 Heating capacity	Nominal	Btu/h (kW)	351,000 (102.9)
	Rated		334,000 (97.9)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	(15.5 + 15.5) + (15.5 + 15.5)
	Number of revolutions	r/min	(7,326 + 7,326) + (7,326 + 7,326)
	Motor output × Number of units	kW	(4.5 × 1 + 4.5 × 1) + (4.5 × 1 + 4.5 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 2
	Airflow rate	cfm (m ³ /min)	8,228 + 8,228 (233 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	ϕ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	ϕ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	709 + 709 (322 + 322)
Sound pressure level (Reference data)		dB (A)	67.5
Sound power level (Reference data)		dB	89
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	10-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	18.1 + 17.2 (8.2 + 7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122724A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ336XAYDA
Model name (Independent unit)			RXYQ168XAYDA RXYQ168XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	326,000 (95.5)
	Rated		312,000 (91.4)
★2 Heating capacity	Nominal	Btu/h (kW)	378,000 (110.8)
	Rated		342,000 (100.2)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	(16.0 + 16.0) + (16.0 + 16.0)
	Number of revolutions	r/min	(7,542 + 7,542) + (7,542 + 7,542)
	Motor output × Number of units	kW	(4.6 × 1 + 4.6 × 1) + (4.6 × 1 + 4.6 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 2
	Airflow rate	cfm (m ³ /min)	8,228 + 8,228 (233 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-3/8 (34.9) C1220T (Brazing connection)
Weight		lbs (kg)	709 + 709 (322 + 322)
Sound pressure level (Reference data)		dB (A)	68
Sound power level (Reference data)		dB	89
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	10-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	17.2 + 17.2 (7.8 + 7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122724A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ360XAYDA
Model name (Independent unit)			RXYQ120XAYDA RXYQ120XAYDA RXYQ120XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	360,000 (105.5)
	Rated		342,000 (100.2)
★2 Heating capacity	Nominal	Btu/h (kW)	405,000 (118.7)
	Rated		372,000 (109.0)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	23.4 + 23.4 + 23.4
	Number of revolutions	r/min	7,338 + 7,338 + 7,338
	Motor output × Number of units	kW	7.6 × 1 + 7.6 × 1 + 7.6 × 1
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 3
	Airflow rate	cfm (m ³ /min)	6,286 + 6,286 + 6,286 (178 + 178 + 178)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-5/8 (41.3) C1220T (Brazing connection)
Weight		lbs (kg)	556 + 556 + 556 (252 + 252 + 252)
Sound pressure level (Reference data)		dB (A)	66
Sound power level (Reference data)		dB	86
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	15-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.9 + 22.9 + 22.9 (10.4 + 10.4 + 10.4)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122725A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ384XAYDA
Model name (Independent unit)			RXYQ96XAYDA RXYQ120XAYDA RXYQ168XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	368,000 (107.9)
	Rated		356,000 (104.3)
★2 Heating capacity	Nominal	Btu/h (kW)	432,000 (126.6)
	Rated		396,000 (116.1)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	22.7 + 22.7 + (14.6 + 14.6)
	Number of revolutions	r/min	7,134 + 7,134 + (6,900 + 6,900)
	Motor output × Number of units	kW	7.4 × 1 + 7.4 × 1 + (4.2 × 1 + 4.2 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 3
	Airflow rate	cfm (m ³ /min)	5,827 + 6,286 + 8,228 (165 + 178 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-5/8 (41.3) C1220T (Brazing connection)
Weight		lbs (kg)	553 + 556 + 709 (251 + 252 + 322)
Sound pressure level (Reference data)		dB (A)	67.5
Sound power level (Reference data)		dB	88
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	13-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.7 + 22.9 + 17.2 (10.3 + 10.4 + 7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122725A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Model name (Combination unit)			RXYQ408XAYDA
Model name (Independent unit)			RXYQ96XAYDA RXYQ144XAYDA RXYQ168XAYDA
Power supply			3 phase, 460 V, 60 Hz
★1 Cooling capacity	Nominal	Btu/h (kW)	390,000 (114.3)
	Rated		372,000 (109.0)
★2 Heating capacity	Nominal	Btu/h (kW)	459,000 (134.5)
	Rated		424,000 (124.3)
Casing color			Ivory white (5Y7.5/1)
Dimensions: (H × W × D)		in (mm)	66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 + 66-11/16 × 48-7/8 × 30-3/16 (1,694 × 1,242 × 767 + 1,694 × 1,242 × 767 + 1,694 × 1,242 × 767)
Heat exchanger			Cross fin coil
Compressor	Type		Hermetically sealed scroll type
	Displacement	m ³ /h	22.4 + (14.2 + 14.2) + (14.2 + 14.2)
	Number of revolutions	r/min	7,038 + (6,684 + 6,684) + (6,684 + 6,684)
	Motor output × Number of units	kW	7.3 × 1 + (4.1 × 1 + 4.1 × 1) + (4.1 × 1 + 4.1 × 1)
	Starting method		Soft start
Fan	Type		Propeller fan
	Motor output	kW	(0.6 × 2) × 3
	Airflow rate	cfm (m ³ /min)	5,827 + 8,228 + 8,228 (165 + 233 + 233)
	Drive		Direct drive
Connecting pipes	Liquid pipe	in (mm)	φ3/4 (19.1) C1220T (Brazing connection)
	Gas pipe	in (mm)	φ1-5/8 (41.3) C1220T (Brazing connection)
Weight		lbs (kg)	553 + 709 + 709 (251 + 322 + 322)
Sound pressure level (Reference data)		dB (A)	68.5
Sound power level (Reference data)		dB	89.5
Safety devices			High pressure switch, Fan driver overload protector, Overcurrent relay, Inverter overload protector, Leak detecting device
Defrost method			Deicer
Capacity control		%	12-100
Refrigerant	Refrigerant name		R-410A
	Charge	lbs (kg)	22.7 + 18.1 + 17.2 (10.3 + 8.2 + 7.8)
	Control		Electronic expansion valve
Standard accessories			Installation manual, Operation manual, Connection pipes, Clamps
Drawing No.	Specification		C: 3D122725A

Notes:

- ★1 Indoor temp.: 80°FDB (26.7°CDB), 67°FWB (19.4°CWB)/Outdoor temp.: 95°FDB (35.0°CDB)/Rated capacity is certified under AHRI standard 1230.
- ★2 Indoor temp.: 70°FDB (21.1°CDB)/Outdoor temp.: 47°FDB (8.3°CDB), 43°FWB (6.1°CWB)/Rated capacity is certified under AHRI standard 1230.

Part 2

Refrigerant Circuit


- 1. Refrigerant Circuit 39
 - 1.1 Outdoor Unit 39
 - 1.2 Indoor Unit 45
 - 1.3 Outdoor-Air Processing Unit 47
- 2. Functional Parts Layout 48
 - 2.1 RXYQ72XATJA 48
 - 2.2 RXYQ96/120XATJA 49
 - 2.3 RXYQ144/168XATJA 50
 - 2.4 RXYQ72XAYDA 51
 - 2.5 RXYQ96/120XAYDA 52
 - 2.6 RXYQ144/168XAYDA 53
- 3. Refrigerant Flow for Each Operation Mode 54
 - 3.1 RXYQ72XATJA, RXYQ72XAYDA 54
 - 3.2 RXYQ96/120XATJA, RXYQ96/120XAYDA 58
 - 3.3 RXYQ144/168XATJA, RXYQ144/168XAYDA 62

1. Refrigerant Circuit

1.1 Outdoor Unit

1.1.1 RXYQ72XATJA, RXYQ72XAYDA


No. in piping diagram	Electric symbol	Name	Function
(1)	M1C	Compressor	Inverter driven compressor is operated in multi-steps according to Te.
(2)	M1F	Inverter fan	Because the system is an air heat exchange type, the fan is operated at 10-step rotation speed by using the inverter.
(3)	Y1E	Electronic expansion valve (Main)	Fully open during cooling operation.
(4)	Y2E	Electronic expansion valve (Injection)	PI control is applied to keep the outlet superheating degree of subcooling heat exchanger constant.
(5)	Y1S	Solenoid valve (Four way valve)	Used to switch the operation mode between cooling and heating.
(6)	Y2S	Solenoid valve (Accumulator oil return)	Used to return oil from the accumulator to the compressor.
(7)	Y3S	Solenoid valve (Oil return)	Used to control the amount of oil from the oil separator to the compressor.
(8)	S1NPH	High pressure sensor	Used to detect high pressure.
(9)	S1NPL	Low pressure sensor	Used to detect low pressure.
(10)	S1PH	High pressure switch	In order to prevent the increase of high pressure when an error occurs, this switch is activated at high pressure of 4.0 MPa (580 psi) or more to stop the compressor operation.
(11)	—	Pressure regulating valve	This valve opens at a pressure of 4.0 MPa (580 psi) for prevention of pressure increase, thus resulting in no damage of functional parts due to the increase of pressure in transportation or storage.
(12)	—	Subcooling heat exchanger	Used to subcooling liquid refrigerant from the electronic expansion valve.
(13)	—	Capillary tube	Used to return the refrigerating oil separated through the oil separator to the compressor.
(14)	R1T	Thermistor (Outdoor air)	Used to detect outdoor air temperature, correct discharge pipe temperature, and others.
(15)	R21T	Thermistor (Discharge pipe)	Used to detect discharge pipe temperature, make the temperature protection control of compressor, and others.
(16)	R3T	Thermistor (Accumulator inlet)	Used to detect gas pipe temperature at the accumulator inlet.
(17)	R4T	Thermistor (Heat exchanger liquid pipe)	This detects temperature of liquid pipe between the air heat exchanger and main electronic expansion valve. Used to make judgements on the recover or discharge refrigerants to the refrigerant regulator.
(18)	R5T	Thermistor (Subcooling heat exchanger liquid pipe)	This detects temperature of liquid pipe between the main electronic expansion valve and subcooling heat exchanger.
(19)	R6T	Thermistor (Subcooling heat exchanger gas pipe)	This detects temperature of gas pipe on the evaporation side of subcooling heat exchanger. Used to exercise the constant control of superheating degree at the outlet of subcooling heat exchanger.
(20)	R7T	Thermistor (Heat exchanger deicer)	Used to detect liquid pipe temperature of air heat exchanger.



C: 3D122249

1.1.2 RXYQ96/120XATJA, RXYQ96/120XAYDA


No. in piping diagram	Electric symbol	Name	Function
(1)	M1C	Compressor	Compressor is operated in multi-steps according to Te.
(2)	M1F	Inverter fan	Because the system is an air heat exchange type, the fan is operated at 10-step rotation speed by using the inverter.
(3)	M2F		
(4)	Y1E	Electronic expansion valve (Main)	Fully open during cooling operation.
(5)	Y2E	Electronic expansion valve (Injection)	PI control is applied to keep the outlet superheating degree of subcooling heat exchanger constant.
(6)	Y1S	Solenoid valve (Four way valve)	Used to switch the operation mode between cooling and heating.
(7)	Y2S	Solenoid valve (Accumulator oil return)	Used to return oil from the accumulator to the compressor.
(8)	Y3S	Solenoid valve (Oil return)	Used to control the amount of oil from the oil separator to the compressor.
(9)	S1NPH	High pressure sensor	Used to detect high pressure.
(10)	S1NPL	Low pressure sensor	Used to detect low pressure.
(11)	S1PH	High pressure switch	In order to prevent the increase of high pressure when an error occurs, this switch is activated at high pressure of 4.0 MPa (580 psi) or more to stop the compressor operation.
(12)	—	Pressure regulating valve	This valve opens at a pressure of 4.0 MPa (580 psi) for prevention of pressure increase, thus resulting in no damage of functional parts due to the increase of pressure in transportation or storage.
(13)	—	Subcooling heat exchanger	Used to subcooling liquid refrigerant from the electronic expansion valve.
(14)	—	Capillary tube	Used to return the refrigerating oil separated through the oil separator to the compressor.
(15)	R1T	Thermistor (Outdoor air)	Used to detect outdoor air temperature, correct discharge pipe temperature, and others.
(16)	R21T	Thermistor (Discharge pipe)	Used to detect discharge pipe temperature, make the temperature protection control of compressor, and others.
(17)	R3T	Thermistor (Accumulator inlet)	Used to detect gas pipe temperature at the accumulator inlet.
(18)	R4T	Thermistor (Heat exchanger liquid pipe)	This detects temperature of liquid pipe between the air heat exchanger and main electronic expansion valve. Used to make judgements on the recover or discharge refrigerants to the refrigerant regulator.
(19)	R5T	Thermistor (Subcooling heat exchanger liquid pipe)	This detects temperature of liquid pipe between the main electronic expansion valve and subcooling heat exchanger.
(20)	R6T	Thermistor (Subcooling heat exchanger gas pipe)	This detects temperature of gas pipe on the evaporation side of subcooling heat exchanger. Used to exercise the constant control of superheating degree at the outlet of subcooling heat exchanger.
(21)	R7T	Thermistor (Heat exchanger deicer)	Used to detect liquid pipe temperature of air heat exchanger.
(22)	R8T	Thermistor (Compressor body)	Detects compressor surface temperature, this switch is activated at surface temperature of 120°C (248°F) or more to stop the compressor operation.



C: 3D122250

1.1.3 RXYQ144/168XATJA, RXYQ144/168XAYDA

No. in piping diagram	Electric symbol	Name	Function
(1)	M1C	Compressor	Compressor is operated in multi-steps according to Te.
(2)	M2C		
(3)	M1F	Inverter fan	Because the system is an air heat exchange type, the fan is operated at 10-step rotation speed by using the inverter.
(4)	M2F		
(5)	Y1E	Electronic expansion valve (Main)	Fully open during cooling operation.
(6)	Y2E	Electronic expansion valve (Injection)	PI control is applied to keep the outlet superheating degree of subcooling heat exchanger constant.
(7)	Y1S	Solenoid valve (Four way valve)	Used to switch the operation mode between cooling and heating.
(8)	Y2S	Solenoid valve (Accumulator oil return)	Used to return oil from the accumulator to the compressor.
(9)	Y3S	Solenoid valve (Oil return 1)	Used to control the amount of oil from the oil separator to the compressor.
(10)	Y4S	Solenoid valve (Oil return 2)	
(11)	S1NPH	High pressure sensor	Used to detect high pressure.
(12)	S1NPL	Low pressure sensor	Used to detect low pressure.
(13)	S1PH	High pressure switch (For M1C compressor)	In order to prevent the increase of high pressure when an error occurs, this switch is activated at high pressure of 4.0 MPa (580 psi) or more to stop the compressor operation.
(14)	S2PH	High pressure switch (For M2C compressor)	
(15)	—	Pressure regulating valve	This valve opens at a pressure of 4.0 MPa (580 psi) for prevention of pressure increase, thus resulting in no damage of functional parts due to the increase of pressure in transportation or storage.
(16)	—	Subcooling heat exchanger	Used to subcooling liquid refrigerant from the electronic expansion valve.
(17)	—	Capillary tube	Used to return the refrigerating oil separated through the oil separator to the compressor.
(18)	—		
(19)	R1T	Thermistor (Outdoor air) (A1P)	Used to detect outdoor air temperature, correct discharge pipe temperature, and others.
(20)	R1T	Thermistor (Radiation fin) (A3P)	RXYQ144/168XATJA only <ul style="list-style-type: none"> • Used for outdoor unit fan speed control. • Used for inverter radiation fin temperature control. • Used for pressure difference control.
(21)	R21T	Thermistor (M1C discharge pipe)	Used to detect discharge pipe temperature, make the temperature protection control of compressor, and others.
(22)	R22T	Thermistor (M2C discharge pipe)	
(23)	R3T	Thermistor (Accumulator inlet)	Used to detect gas pipe temperature at the accumulator inlet.
(24)	R4T	Thermistor (Heat exchanger liquid pipe)	This detects temperature of liquid pipe between the air heat exchanger and main electronic expansion valve. Used to make judgements on the recover or discharge refrigerants to the refrigerant regulator.
(25)	R5T	Thermistor (Subcooling heat exchanger liquid pipe)	This detects temperature of liquid pipe between the main electronic expansion valve and subcooling heat exchanger.
(26)	R6T	Thermistor (Subcooling heat exchanger gas pipe)	This detects temperature of gas pipe on the evaporation side of subcooling heat exchanger. Used to exercise the constant control of superheating degree at the outlet of subcooling heat exchanger.
(27)	R7T	Thermistor (Heat exchanger deicer)	Used to detect liquid pipe temperature of air heat exchanger.



* The radiation fin thermistor (20) is located near the electrical component box.


C: 3D122251

1.2 Indoor Unit


No. in piping diagram	Name	Symbol			Function
		Except FXMQ-PB, FXTQ-TA, CXTQ-TA	FXMQ-PB	FXTQ-TA, CXTQ-TA	
(1)	Electronic expansion valve	Y1E	Y1E	Y1E	Used for gas superheating degree control while in cooling or subcooling degree control while in heating.
(2)	Suction air thermistor	R1T	R1T	R1T (*1)	Used for thermostat control.
(3)	Liquid pipe thermistor	R2T	R2T	R2T	Used for gas superheating degree control while in cooling or subcooling degree control while in heating.
(4)	Gas pipe thermistor	R3T	R3T	R3T	Used for gas superheating degree control while in cooling.
(5)	Discharge air thermistor	—	R4T	—	Used for discharge air temperature control.

*1. R1T is for remote controller thermistor or optional remote sensor.


■ FXFQ-T, FXHQ-M




■ FXZQ-TA




■ FXUQ-P, FXEQ-P, FXSQ-TA, FXMQ-M, FXAQ-P, FXLQ-M, FXNQ-M




■ FXDQ-M




■ FXMQ-PB




■ FXTQ-TA



■ CXTQ-TA



1.3 Outdoor-Air Processing Unit



C: 4D018650D

No. in piping diagram	Electric symbol	Name	Function
(1)	Y1E	Electronic expansion valve	Used to control the flow rate of refrigerant, and make the SH control (*1) while in cooling.
(2)	Y1S	Solenoid valve	Used to bypass hot gas while in heating with thermostat OFF. Closed while in cooling.
(3)	—	Capillary tube	Used to reduce pressure from high to low in bypassing hot gas.
(4)	R1T	Suction air thermistor	Used to turn ON or OFF the thermostat.
(5)	R2T	Liquid pipe thermistor	Used to control the opening degree of electronic expansion valve under the SC control (*2).
(6)	R3T	Gas pipe thermistor	Used to control the opening degree of electronic expansion valve under the SH control.
(7)	R4T	Discharge air thermistor	Used to control the electronic expansion valve opening and thermostat ON/OFF so as to keep the discharge air temperature at the set temperature.




Notes: *1. SH control: Superheated control of heat exchanger outlet
*2. SC control: Subcooling control of heat exchanger outlet


2. Functional Parts Layout

2.1 RXYQ72XATJA

Top View




Front View




C: 1P578147

2.2 RXYQ96/120XATJA

Top View




Front View




C: 1P578148

2.3 RXYQ144/168XATJA

Top View




Front View




C: 1P578149

2.4 RXYQ72XAYDA

Top View




Front View




C:1P578150

2.5 RXYQ96/120XAYDA

Top View




Front View




C: 1P578151

2.6 RXYQ144/168XAYDA

Top View



Front View




C: 1P578152

3. Refrigerant Flow for Each Operation Mode

3.1 RXYQ72XATJA, RXYQ72XAYDA

3.1.1 Cooling Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122249

3.1.2 Cooling Oil Return Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122249

3.1.3 Defrost Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122249

3.1.4 Heating operation

- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure




C: 3D122249

3.2 RXYQ96/120XATJA, RXYQ96/120XAYDA

3.2.1 Cooling Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122250

3.2.2 Cooling Oil Return Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122250

3.2.3 Defrost Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122250

3.2.4 Heating Operation

- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure




C: 3D12250

3.3 RXYQ144/168XATJA, RXYQ144/168XAYDA

3.3.1 Cooling Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122251

3.3.2 Cooling Oil Return Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122251

3.3.3 Defrost Operation


- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D122251

3.3.4 Heating Operation

- High temperature, high pressure, gas
- High temperature, high pressure, liquid
- Low temperature, low pressure



C: 3D12251

Part 3

Remote Controller


1. Applicable Models	67
2. Names and Functions	68
2.1 BRC1E73	68
2.2 Wireless Remote Controller	71
3. Main/Sub Setting	72
3.1 BRC1E73	72
3.2 When Wireless Remote Controller is Used Together.....	73
4. Address Setting for Wireless Remote Controller.....	74
5. Centralized Control Group No. Setting.....	76
5.1 BRC1E73	76
5.2 Wireless Remote Controller	78
5.3 Group No. Setting Example.....	79
6. Service Settings Menu, Maintenance Menu.....	80
6.1 BRC1E73	80

1. Applicable Models

Series	Wired remote controller	Wireless remote controller
	Navigation	
FXFQ-T	BRC1E73	–
FXZQ-TA		BRC082A42W (for BYFQ60C3W1W)
		BRC082A42S (for BYFQ60C3W1S)
		BRC082A41W (for BYFQ60B3W1)
FXUQ-P		–
FXEQ-P		
FXDQ-M		BRC4C82
FXSQ-TA		BRC082A43
FXMQ-PB		BRC4C82 (Fan: 2 steps) BRC082A43 (Fan: 3 steps)
FXMQ-M		BRC4C82
FXHQ-M		BRC7E83
FXAQ-P		BRC7E818
FXLQ-M		–
FXNQ-M		
FXTQ-TA		
CXTQ-TA		BRC4C82

2. Names and Functions

2.1 BRC1E73



Functions other than basic operation items (i.e., On/Off, Operation Mode, Fan Speed, and Setpoint) are set from the menu screen.



Note:

- Do not install the remote controller in places exposed to direct sunlight, the LCD will be damaged.
- Do not pull or twist the remote controller cord, the remote controller may be damaged.
- Do not use objects with sharp ends to press the buttons on the remote controller damage may result.

1. Operation mode selector button

- Press this button to select the operation mode of your preference.
- * Available modes vary with the indoor unit model.

2. Fan speed control button

- Press this button to select the fan speed of your preference.
- * Available fan speeds vary with the indoor unit model.

3. Menu/OK button

- Used to enter the main menu.
- Used to enter the selected item.

4. Up button ▲

- Used to raise the setpoint.
- The item above the current selection will be highlighted.
(The highlighted items will be scrolled continuously when the button is continuously pressed.)
- Used to change the selected item.

5. Down button ▼

- Used to lower the setpoint.
- The item below the current selection will be highlighted.
(The highlighted items will be scrolled continuously when the button is continuously pressed.)
- Used to change the selected item.

6. Right button ►

- Used to highlight the next items on the right-hand side.
- Each screen is scrolled in the right-hand direction.

7. Left button ◀

- Used to highlight the next items on the left-hand side.
- Each screen is scrolled in the left-hand direction.

8. On/Off button

- Press this button and system will start.
- Press this button again to stop the system.

9. Operation lamp

- This lamp illuminates solid green during normal operation.
- This lamp blinks if an error occurs.


10. Cancel button

- Used to return to the previous screen.


11. LCD (with backlight)

- The backlight will be illuminated for approximately 30 seconds by pressing any button.
- If two remote controllers are used to control a single indoor unit, only the controller accessed first will have backlight functionality.

Service Check Function



2.2 Wireless Remote Controller



1	DISPLAY ▲ (SIGNAL TRANSMISSION) This lights up when a signal is being transmitted.
2	DISPLAY (OPERATION MODE) This display shows the current OPERATION MODE.
3	DISPLAY (SET TEMPERATURE) This display shows the set temperature.
4	DISPLAY hr. hr. (PROGRAMMED TIME) This display shows programmed time of the system start or stop.
5	DISPLAY (AIRFLOW FLAP)
6	DISPLAY (FAN SPEED) The display shows the set fan speed.
7	DISPLAY TEST (INSPECTION/TEST) When the INSPECTION/TEST button is pressed, the display shows the system mode is in.
8	ON/OFF BUTTON Press the button and the system will start. Press the button again and the system will stop.

9	FAN SPEED CONTROL BUTTON Press this button to select the fan speed, HIGH or LOW, of your choice.
10	TEMPERATURE SETTING BUTTON Use this button for setting temperature (Operates with the front cover of the remote controller closed.)
11	PROGRAMMING TIMER BUTTON Use this button for programming start and/or stop time. (Operates with the front cover of the remote controller opened.)
12	TIMER MODE START/STOP BUTTON
13	TIMER RESERVE/CANCEL BUTTON
14	AIRFLOW DIRECTION ADJUST BUTTON
15	OPERATION MODE SELECTOR BUTTON Press this button to select operation mode.
16	FILTER SIGN RESET BUTTON
17	INSPECTION/TEST BUTTON This button is used only by qualified service persons for maintenance purposes.

3. Main/Sub Setting

3.1 BRC1E73

Situation


The Main/Sub setting is necessary when 1 indoor unit is controlled by 2 remote controllers. When you use 2 remote controllers (control panel and separate remote controller), set one to Main and the other to Sub.

Setting

The remote controllers are factory setting to Main, so you only have to change one remote controller from Main to Sub. To change a remote controller from Main to Sub, proceed as follows:

3.1.1 Field Settings

The designation of the main and sub remote controllers can be swapped. Note that this change requires turning the power OFF and then ON again.



3.1.2 When an error occurred

U5: there are 2 main remote controllers when power is turned ON


→Change the setting from Main to Sub on the remote controller you want to be Sub.

U8: there are 2 sub remote controller when power is turned ON

→Change the setting from Sub to Main on the remote controller you want to be Main.


How to confirm Main/Sub setting

The Main/Sub setting of the remote controller is displayed on the bottom of the screen while **Checking the connection. Please stand by.** is displayed.



How to change Main/Sub setting

You may change the Main/Sub setting of the remote controller while **Checking the connection. Please stand by.** is displayed by pressing and holding the **Mode Selector** button for 4 seconds or longer.





i Notes:

1. It is not possible to change the Main/Sub setting from Main to Sub when only one remote controller is connected.
2. When 2 remote controllers are being used, it is not possible to change the setting from Main to Sub if one of the remote controllers is already set as Main.

3.2 When Wireless Remote Controller is Used Together

When using both a wired and a wireless remote controller for 1 indoor unit, the wired controller should be set to Main. Therefore, the Main/Sub switch (SS1) of the signal receiver PCB must be set to Sub.

Main/Sub	Main	Sub
Main/Sub switch (SS1)		



4. Address Setting for Wireless Remote Controller




If setting multiple wireless remote controllers to operate in one room, perform address setting for the receiver and the wireless remote controller.



(This includes an individual remote controller control using the group operation.)

(For the wiring for the group operation, please refer to the installation manual attached to the indoor unit and technical guide.)

Setting for signal receiver PCB

The address for the receiver is set to 1 at the factory. To change the setting, set the wireless address switch (SS2) on the signal receiver PCB according to the table below.


Unit No.	No. 1	No. 2	No. 3
Wireless address switch (SS2)			



Setting for wireless remote controller

The address for the wireless remote controller is set to 1 at the factory. To change the setting, proceed as follows:

1. Press **FILTER SIGN RESET** button and **INSPECTION/TEST** button at the same time for 4 seconds to enter field setting mode. (**SETTING** is indicated on the display.)
 2. Press **FAN** button and select **A** or **b**. Each time the button is pressed, the display switches between **A** and **b**.
 3. Press **UP** button or **DOWN** button to select an address from 1-3 as same as the receiver.
Address can be set from 1-6, but the receiver does not work with addresses 4-6.
- 1 → 2 → 3 → 4 → 5 → 6
4. Press **RESERVE** button to confirm the setting.
 5. Press **INSPECTION/TEST** button for 1 second to return to normal mode.



Multiple Settings A/b

The command such as operation mode or temperature setting by this remote controller will be rejected when the target indoor unit operation is restricted as by an external control such as centralized control. Since the setting acceptance is hard to discriminate with such circumstances there are two setting options provided to enable discriminating by a beeping sound according to the operation: "A: Standard" or "b: Multi System". Set the setting according to the customer's intention.

Remote Controller		Indoor Unit	
Multiple setting	Display on remote controller	Behavior to the remote controller operation when the functions are restricted as by an external control.	Other than the left
A: Standard (factory set)	All items displayed.	Accepts the functions except restricted. (Sounds one long beep or three short beeps) There may be a difference from the indoor unit status with remote controller display.	Accepts all items transmitted (Sounds two short beeps) The remote controller display agrees with the indoor unit status.
b: Multi System	Display only items transmitted for a while.	<p><When some restricted functions are included in the transmitted items> Accepts the functions except restricted. (Sounds one long beep or three short beeps) There may be a difference from the indoor unit status with remote controller display.</p> <p><When no restricted function is included> Accepts all items transmitted (Sounds two short beeps) The remote controller display agrees with the indoor unit status.</p>	


5. Centralized Control Group No. Setting

5.1 BRC1E73

In order to conduct the centralized remote control using the central remote controller and the unified ON/OFF controller, Group No. settings should be made by group using the operating remote controller.

Make Group No. settings for centralized remote control using the operating remote controller.

When initializing Group Address



Service settings menu	Item 2
Group Address	Group Address (Group)
	Group Address (Unit)

■ Description
 This menu is used to make group address setting for centralized control.
 It is also used to make group address setting by indoor unit.




Note:

- For setting group No. of Energy recovery ventilator and wiring adaptor for other air conditioners, etc., refer to the instruction manual.

NOTICE

Enter the group No. and installation place of the indoor unit into the installation table. Be sure to keep the installation table with the operation manual for maintenance.


Group Address (Group)




5.2 Wireless Remote Controller

Group No. setting by wireless remote controller for centralized control


1. When in the normal mode, press **INSPECTION/TEST** button for 4 seconds or more to enter field setting mode.
2. Set mode No. 03 with **MODE** button.
3. Set the group No. for each group with **UP** button or **DOWN** button.
4. Enter the selected group numbers by pressing **RESERVE** button.
5. Press **INSPECTION/TEST** button and return to the normal mode.



5.3 Group No. Setting Example




Caution

When turning the power supply on, the unit may often not accept any operation while  is displaying after all indications were displayed once for about 1 minute on the liquid crystal display. This is not an operative fault.

6. Service Settings Menu, Maintenance Menu

6.1 BRC1E73

Operating the remote controller allows service data to be acquired and various services to be set.



6.1.1 Service Settings Menu

Service settings menu	Item 2	Item 3
Test Operation	—	—
Maintenance Contact	None	—
	Maintenance Contact	—, 0 to 9 (in order)
Field Settings	Indoor Unit No.	—
	Mode No.	—
	First Code No.	—
	Second Code No.	—
Energy Saving Options	Setpoint Range Limitation	Temperature
	Setback Configuration	Recovery Differential
	Auto-setback by Sensor	Enable/Disable, Settings
	Auto-off by Sensor	Enable/Disable, Auto-off in (hours)
Prohibit Function	Prohibit Buttons	Up/Down, Left, Right, On/Off, Mode, Fan Speed
	Prohibit Mode	Fan, Cool, Heat, Auto, Dry, Vent Clean
Min Setpoints Differential	None, Single SP, 0 to 8°F	—
Group Address	Group Address (Group)	Gr Addr. Set
	Group Address (Unit)	Unit No., Gr Addr. Set
Indoor unit AirNet Address	Unit No., Address Set	—
Outdoor unit AirNet Address	Unit No., Address Set	—
Error History	RC Error History	Unit No., Error, Date, Time (Up to 10 errors received by the remote controller can be displayed.)
	Indoor unit Error History	Unit No., Error, Date, Time (Up to 5 errors from the indoor unit error record can be displayed.)
Indoor Unit Status	Unit No.	—
	Th1	Suction air thermistor
	Th2	Heat exchanger liquid pipe thermistor
	Th3	Heat exchanger gas pipe thermistor
	Th4	Discharge air thermistor
	Th5	Remote controller thermistor (FXSQ-TA, FXTQ-TA, CXTQ-TA) Floor temperature thermistor (FXZQ-TA, FXUQ-P, FXEQ-P)
	Th6	Control temperature (FXZQ-TA, FXUQ-P, FXEQ-P, FXSQ-TA, FXTQ-TA, CXTQ-TA)
Outdoor Unit Status	Unit No.	—
	Th1	—
	Th2	—
	Th3	—
	Th4	—
	Th5	—
	Th6	—
Forced Fan ON	Unit No.	—
Switch Main Sub Controller	—	—
Filter Indicator	—	—
Test Filter Auto Clean	—	—
Brush/Filter Ind.	—	—
Disable Filter Auto Clean	No, Yes	—

6.1.2 Maintenance Menu

Maintenance Menu	Item 2	Remarks
Model Name	Unit No.	Select the unit number you want to check.
	Indoor unit	The model names are displayed. (A model code may be displayed instead, depending on the particular model.)
	Outdoor unit	
Operation Hours	Unit No.	Select the unit number you want to check.
	Indoor unit operation hours	All of these are displayed in hours.
	Indoor fan operation hours	
	Indoor unit energized hours	
	Outdoor unit operation hours	
	Outdoor fan 1 operation hours	
	Outdoor fan 2 operation hours	
	Outdoor compressor 1 operation hours	
	Outdoor compressor 2 operation hours	
Indoor Unit Status	Unit No.	
	FAN	Fan tap (*1)
	Speed	Fan speed (rpm) (*2)
	FLAP	Swing, fixed
	EV	Degree that electronic expansion valve is open (pulse)
	MP	Drain pump ON/OFF
	EH	Electric heater ON/OFF
	Hu	Humidifier ON/OFF (*3)
	TBF	Anti-freezing control ON/OFF
	FLOAT	Float switch OPEN/CLOSE
	T1/T2	T1/T2 external input OPEN/CLOSE
	Th1	Suction air thermistor
	Th2	Heat exchanger liquid pipe thermistor
	Th3	Heat exchanger gas pipe thermistor
	Th4	Discharge air thermistor
	Th5	Remote controller thermistor (FXSQ-TA, FXTQ-TA, CXTQ-TA) Floor temperature thermistor (FXZQ-TA, FXUQ-P, FXEQ-P)
Th6	Control temperature (FXZQ-TA, FXUQ-P, FXEQ-P, FXSQ-TA, FXTQ-TA, CXTQ-TA)	
Outdoor Unit Status	Unit No.	Select the Unit No. you want to check.
	FAN step	Fan tap
	COMP	Compressor power supply frequency (Hz)
	EV1	Degree that electronic expansion valve is open (pulse)
	SV1	Solenoid valve ON/OFF
	Th1	—
	Th2	—
	Th3	—
	Th4	—
	Th5	—
	Th6	—

Maintenance Menu	Item 2	Remarks
Forced Defrost	Forced defrost ON	Enables the forced defrost operation.
	Forced defrost OFF	Disables the forced defrost operation.
Error Display	Display error ON	Displays the error on the screen.
	Display error OFF	Displays neither errors nor warnings.
	Display warning ON	Displays a warning on the screen if an error occurs.
	Display warning OFF	No warning is displayed.
Swap Unit No.	Current Unit No.	A unit No. can be transferred to another.
	Transfer Unit No.	
Addressed Sensor Value	Unit No.: 0 - 15	Select the unit number you want to check.
	Code	
	00 :	Remote controller thermistor (°F)
	01 :	Suction air thermistor (°F)
	02 :	Heat exchanger liquid pipe thermistor (°F)
	03 :	Heat exchanger gas pipe thermistor (°F)
	04 :	Indoor unit address No.
	05 :	Outdoor unit address No.
	06 :	Branch Selector unit address No.
	07 :	Zone control address No.
08 :	Cooling/Heating batch address No.	
09 :	Demand/low-noise address No.	
30: (*4)	Displays thermostat step 1 ON/OFF. Thermostat step 1 OFF: 00 Thermostat step 1 ON: 01	
31: (*4)(*5)	Displays the heat demand that CXTQ-TA is currently sending to the gas furnace (%).	
32: (*4)(*5)	Displays the fan demand that CXTQ-TA is currently sending to the gas furnace (%).	
33: (*4)	Current status of heat pump ON/OFF for CXTQ-TA HP OFF: 00 HP ON: 01	
34: (*4)(*5)	Current status of gas combustion heating Displays current heat actual status (%).	
35: (*4)(*6)	Current airflow of the fan Displays current airflow (CFM).	
Data	The corresponding data will be displayed, based on the unit number and Code selected.	

*1. (For FXTQ-TA, CXTQ-TA models)

The actual fan speed is converted into the fan tap to be displayed. Therefore, if the fan speed is changed by controls or external factors, the airflow rate set with the remote controller may differ from the fan tap display.

*2. (For FXTQ-TA models)

0 rpm is displayed even if the fan is rotating.

(For CXTQ-TA models)

- rpm is displayed even if the fan is rotating.

*3. (For FXTQ-TA, CXTQ-TA models)

The ON/OFF status of the humidifier connected to HUMIDIFIER on the X1M terminal of the indoor unit PCB is not displayed. The ON/OFF status of the humidifier connected to the wiring adaptor is displayed.

*4. Only for CXTQ-TA

*5. Displays **99** when it is more than 100%.

*6. Display unit is by 100 CFM.

(ex. Displays **19** for 1850 CFM. Displays **18** for 1849 CFM.)


Part 4

Functions and Control

1. Operation Flowchart (Outdoor Unit)	86
2. Stop Control	87
2.1 Stop due to Error	87
2.2 When System is in Stop Control.....	87
2.3 Slave Unit Stops during Master Unit Operation.....	87
3. Standby Control	88
3.1 Restart Standby.....	88
3.2 Crankcase Heater Control.....	88
4. Startup Control	89
4.1 Startup Control in Cooling	89
4.2 Startup Control in Heating	90
5. Basic Control.....	91
5.1 Normal Control	91
5.2 Compressor Capacity Control	92
5.3 Operating Priority and Rotation of Compressors.....	93
5.4 Compressor Step Control.....	94
5.5 Electronic Expansion Valve Control	94
5.6 Step Control of Outdoor Fans	95
6. Protection Control	96
6.1 High Pressure Protection Control.....	96
6.2 Low Pressure Protection Control.....	97
6.3 Discharge Pipe Protection Control	98
6.4 Compressor Body Protection Control.....	98
6.5 Inverter Protection Control	99
6.6 Heating Operation Prohibition	100
7. Special Control.....	101
7.1 Pump Down Residual Operation	101
7.2 Outdoor Unit Rotation.....	101
7.3 Oil Return Operation	103
7.4 Defrost Operation	104
7.5 Drain Pan Heater (Option).....	104
8. Outline of Control (Indoor Unit)	105
8.1 Operation Flowchart.....	105
8.2 Set Temperature and Control Temperature	109
8.3 Remote Controller Thermistor	111
8.4 Thermostat Control.....	113
8.5 Drain Pump Control.....	116
8.6 Control of Electronic Expansion Valve	118
8.7 Freeze-up Prevention.....	119
8.8 List of Swing Flap Operations	121

8.9 Hot Start Control (In Heating Only)	122
8.10 Louver Control for Preventing Ceiling Dirt.....	123
8.11 Heater Control (Except FXTQ-TA Models).....	124
8.12 Heater Control (FXTQ-TA Models).....	125
8.13 Gas Furnace Control (CXTQ-TA Models)	128
8.14 3-Step Thermostat Processing (FXTQ-TA Models)	129
8.15 Fan Control (Heater Residual) (FXTQ-TA Models)	130
8.16 Interlocked with External Equipment (FXTQ-TA and CXTQ-TA Models)	130

1. Operation Flowchart (Outdoor Unit)


Notes:

1. If the indoor unit stops or the thermostat turns OFF while in oil return operation or defrost operation, pump down residual operation is performed on completion of the oil return operation or defrost operation.
2. Not performed during cooling mode.

2. Stop Control

2.1 Stop due to Error

In order to protect compressors, if any of the abnormal state occurs, the system will stop with thermostat OFF and the error will be determined when the retry times reaches certain number.
(Refer to "Error Code and Description" (page 205~) of the troubleshooting for the items to determine the error.)

2.2 When System is in Stop Control

The four way valve for heat exchanger retains the condition before they were stopped.

2.3 Slave Unit Stops during Master Unit Operation

When slave unit is stopped (because of low demand), conditions for this unit is set same as system stop. System stops until this unit is required to operate (increase of load).

3. Standby Control


3.1 Restart Standby

Used to forcedly stop the compressor for a period of 3 minutes, in order to prevent the frequent ON/OFF of the compressor and equalize the pressure within the refrigerant system.

In addition, the outdoor fan carry out the residual operation for a while to accelerate pressure equalizing and to suppress melting of the refrigerant to the evaporator.

3.2 Crankcase Heater Control


In order to prevent the refrigerant from melting in the compressor oil in the stopped mode, this mode is used to control the crankcase heater.



4. Startup Control


This control is used to equalize the pressure in the front and back of the compressor prior to the startup of the compressor, thus reducing startup loads. Furthermore, the inverter is turned ON to charge the capacitor. To avoid stresses to the compressor due to oil return or else after the startup, the following control is made and the position of the four way valve is also determined. Start both the master and the slave units simultaneously to position the four way valve.

4.1 Startup Control in Cooling



P_c : High pressure sensor detection value
 P_e : Low pressure sensor detection value
 T_a : Outdoor air temperature
 T_e : Low pressure equivalent saturation temperature

4.2 Startup Control in Heating



P_c : High pressure sensor detection value
P_e : Low pressure sensor detection value
T_a : Outdoor air temperature
T_e : Low pressure equivalent saturation temperature

5. Basic Control

5.1 Normal Control

Tc : High pressure equivalent saturation temperature

Te : Low pressure equivalent saturation temperature

DSH: Discharge pipe superheating degree

Cooling

Part Name	Electric Symbol	RXYQ72-120XA	RXYQ144/168XA	Function of Functional Part
Compressor 1	M1C	●	●	PI control, High pressure protection, Low pressure protection, Td protection, Inverter protection
Compressor 2	M2C	–	●	
Inverter fan 1	M1F	●	●	Cooling fan control
Inverter fan 2	M2F	(●)* ¹	●	
Electronic expansion valve (Main)	Y1E	●	●	Thermostat OFF: 0 pulse Thermostat ON: 3,000 pulses
Electronic expansion valve (Injection)	Y2E	●	●	Superheating degree control
Four way valve	Y1S	●	●	OFF
Solenoid valve (Accumulator oil return)	Y2S	●	●	ON
Solenoid valve (Oil return 1)	Y3S	●	●	ON
Solenoid valve (Oil return 2)	Y4S	–	●	

●: equipped

–: not equipped

*1: RXYQ96/120XA only

Heating

Part Name	Electric Symbol	RXYQ72-120XA	RXYQ144/168XA	Function of Functional Part
Compressor 1	M1C	●	●	PI control, High pressure protection, Low pressure protection, Td protection, Inverter protection
Compressor 2	M2C	–	●	
Inverter fan 1	M1F	●	●	Fan step 7 or Fan step 8
Inverter fan 2	M2F	(●)* ¹	●	
Electronic expansion valve (Main)	Y1E	●	●	Thermostat OFF: 0 pulse Thermostat ON: 120-3,000 pulses
Electronic expansion valve (Injection)	Y2E	●	●	Superheating degree control
Four way valve	Y1S	●	●	ON
Solenoid valve (Accumulator oil return)	Y2S	●	●	ON
Solenoid valve (Oil return 1)	Y3S	●	●	ON
Solenoid valve (Oil return 2)	Y4S	–	●	

●: equipped

–: not equipped

*1: RXYQ96/120XA only

5.2 Compressor Capacity Control

T_c : High pressure equivalent saturation temperature

T_e : Low pressure equivalent saturation temperature

Capacity steps

The compressor rotation speed is changed according to the control pressure.

- Cooling: suction pressure sensor value is converted into evaporating saturated temperature (relation between pressure and evaporating temperature based on characteristics of refrigerant R-410A). For detailed explanation refer to chapter field settings (Description field settings (mode 2: m2) on outdoor unit main PCB on page 177 and installation manual outdoor chapter “Energy saving and optimum operation”).
 - Initial selection is made between Automatic, Fixed, or High sensible.
 - During operation, the outdoor target evaporating temperature can be changed based on the selected sub function, taking indoor load into account.
- Heating: discharge pressure sensor value is converted into condensing saturation temperature.
 - Initial selection is made between Automatic, Fixed, or High sensible.
 - During operation, the outdoor target condensing temperature can be changed based on the selected sub function, taking indoor load into account.
- The initial target saturated temperature can be changed. For details refer to Description field settings (mode 2: m2) on outdoor unit main PCB on page 177: for Cooling: T_e set based on field setting 2-8, for heating: T_c set based on field setting 2-9.
- During operation, outdoor control will take into account the pressure drop so that at indoor units, the pre-set target temperature is reached (average). The estimated pressure drop is calculated based on:
 - Pressure drop characteristics found during test-operation outdoor (step 7). At several evaporating temperature, outdoor control stores difference between outdoor evaporating temperature and average of indoor heat exchanger (indoor evaporating temperature).
 - To have judgment of gas speed in main suction pipe, control takes the capacity step of the outdoor unit into account. In function of pressure drop characteristics at the different compressor capacity steps, control concludes the category of system pipe lay out (long, medium, short).
- Target T_e outdoor (cooling) = T_e set – estimated pressure drop – A.
- Target T_c outdoor (heating) = T_c set + estimated pressure drop + A.
- Correction factor A depends on the absolute value of the difference between indoor air inlet temperature and a set temperature after startup period.


5.3 Operating Priority and Rotation of Compressors

Each compressor operates in the following order of priority.

In the case of multi-outdoor-unit system, each compressor operates in Pattern 1 to Pattern 3 according to the rotation of outdoor units.


M1C: Compressor 1

M2C: Compressor 2



Single Outdoor Unit

RXYQ72-120XA




RXYQ144-168XA




Double Outdoor Units


RXYQ192-240XA



RXYQ264XA




RXYQ288-336XA




Triple Outdoor Units


RXYQ360XA



RXYQ384XA



RXYQ408XA



Notes:

1. In the case of combination of triple outdoor units, the above diagram shows master unit, slave unit 1, and slave unit 2 from left to right.
2. Compressors may operate in any pattern other than those mentioned above according to the operating status.

5.4 Compressor Step Control


- The actual rotation speed per second of the compressor (rps) depends on the type of compressor:

Compressor	Actual rotation speed	XATJA			XAYDA		
		72	96/120	144/168	72	96/120	144/168
JT100GCVDKW	rps = frequency/2	●	–	●●	–	–	–
JT150JBVDW	rps = frequency/3	–	●	–	–	–	–
JT1GCVDWYR	rps = frequency/2	–	–	–	●	–	●●
JT15JBVDWYR	rps = frequency/3	–	–	–	–	●	–


5.5 Electronic Expansion Valve Control

Electronic expansion valve Y1E

- Cooling: electronic expansion valve is used only at fully closed or fully open condition:
 - Compressor(s) OFF: fully closed (0 pulse)
 - Compressor ON:
 - Fully open (3,000 pulses): if level difference outdoor above indoor units within 50 m (164 ft) (field setting 2-49-0).
 - Limited open: if level difference outdoor maximum 90 m (295 ft) above indoor units (field setting 2-49-1).



- Heating: electronic expansion valve is used in PID control suction superheat:
 - Compressor(s) OFF: fully closed (0 pulse)
 - Compressor ON:
 - At startup: closed (check suction pressure drops)
 - Modulated opening by:
 - Suction superheat = accumulator inlet temperature – evaporating temperature.
 - Discharge superheat = discharge pipe temperature – condensing temperature.
 - Preventive change when compressor capacity step changes.
 - Limited opening when condensing temperature exceeds target condensing.



5.6 Step Control of Outdoor Fans

Used to control the revolutions of outdoor unit fans in the steps listed in table below, according to condition changes.

Step	Fan revolutions (rpm)				
	RXYQ72XA	RXYQ96/120XA		RXYQ144/168XA	
		M1F	M2F	M1F	M2F
0	0	0	0	0	0
1	350	360	0	380	0
2	370	470	0	470	0
3	400	570	0	570	0
4	460	360	360	380	380
5	560	550	520	550	520
6	710	865	665	865	665
7Y	750	940	910	940	910
7X	Cooling: 821 Heating: 800	963	933	1136	1106
8	Cooling: 821 Heating: 800	1097	1067	1360	1180



Note: Figures listed above are for standard mode. Values may differ when the system is set to high static pressure mode or capacity priority mode.


6. Protection Control

6.1 High Pressure Protection Control

This high pressure protection control is used to prevent the activation of protection devices due to abnormal increase of high pressure and to protect compressors against the transient increase of high pressure.


Cooling

The following control is performed in the entire system.



Heating

The following control is performed in the entire system.




6.2 Low Pressure Protection Control

This low pressure protection control is used to protect compressors against the transient decrease of low pressure.


Cooling

Because of common low pressure, the following control is performed in the system.



Heating


The following control is performed in the system.



6.3 Discharge Pipe Protection Control

This discharge pipe protection control is used to protect the compressor internal temperature against an error or transient increase of discharge pipe temperature.


The following control is performed for each compressor of single unit as well as multi units.



6.4 Compressor Body Protection Control

This compressor body protection control is used to protect the compressor internal temperature against an error or transient increase of compressor body temperature.

The following control is performed for each compressor of single unit as well as multi units.




6.5 Inverter Protection Control

Inverter current protection control and radiation fin temperature control are performed to prevent tripping due to an abnormality, or transient inverter overcurrent, and fin temperature increase.

In the case of multi-outdoor-unit system, each compressor performs these controls in the following sequence.

Inverter overcurrent protection control


This control is performed for each compressor.



Model	Condition	RXYQ72XA	RXYQ96/120XA	RXYQ144/168XA	
		M1C	M1C	M1C	M2C
XATJA	A	> 27.6 A	> 33.8 A	> 27.6 A	> 27.6 A
	B	< 26.5 A	< 32.5 A	< 26.5 A	< 26.5 A
	C	> 33.5 A	> 45.0 A	> 33.5 A	> 33.5 A
XAYDA	A	> 11.0 A	> 18.0 A	> 11.5 A	> 11.5 A
	B	< 11.0 A	< 18.0 A	< 11.5 A	< 11.5 A
	C	> 13.0 A	> 21.5 A	> 13.0 A	> 13.0 A

Radiation fin temperature control

This control performed for each compressor.



Model	Condition	RXYQ72XA	RXYQ96/120XA	RXYQ144/168XA	
		M1C	M1C	M1C	M2C
XATJA	A	≥ 83°C (181°F)	≥ 83°C (181°F)	≥ 82°C (180°F)	≥ 82°C (180°F)
	B	< 80°C (176°F)	< 80°C (176°F)	< 79°C (174°F)	< 79°C (174°F)
	C	≥ 105°C (221°F)	≥ 85°C (185°F)	≥ 85°C (185°F)	≥ 85°C (185°F)
XAYDA	A	≥ 100°C (212°F)	≥ 82°C (180°F)	≥ 98°C (208°F)	≥ 98°C (208°F)
	B	< 97°C (207°F)	< 79°C (174°F)	< 95°C (203°F)	< 95°C (203°F)
	C	≥ 105°C (221°F)	≥ 86°C (187°F)	≥ 105°C (221°F)	≥ 105°C (221°F)

6.6 Heating Operation Prohibition

- When outdoor air temperature becomes high, outdoor unit cannot perform heating because:
 - Low pressure sensor can give pressure value above upper limit of sensor: error **JC**.
 - Mechanical internal load on compressor increases.
 - Low compression ratio can result in insufficient compressor internal oil lubrication.
- Heating is disabled when outdoor air temperature raises above 26°C (78.8°F).
 - Forced thermostat-OFF indoor units.
 - Outdoor fan operates at step 1.
- Heating returns available when outdoor air temperature drops below 24°C (75.2°F).

7. Special Control

7.1 Pump Down Residual Operation

Pc : High pressure sensor detection value

Pe : Low pressure sensor detection value

- To avoid refrigerant emigration when outdoor unit stops operation (thermostat or safety), all electronic expansion valves are closed.

7.2 Outdoor Unit Rotation

In the case of multi-outdoor-unit system, this outdoor unit rotation is used to prevent the compressor from breaking down due to unbalanced oil level between outdoor units.

Details of outdoor unit rotation

In the case of multi-outdoor-unit system, each outdoor unit is given an operating priority for the control.


Outdoor unit rotation makes it possible to change the operating priority of outdoor units.

Thus, the system becomes free of compressors that stop over an extended period of time at the time of partial loading, preventing unbalanced oil level.

Timing of outdoor unit rotation

- OR
- After oil return operation
 - After defrost operation
 - At the beginning of the startup control
 - When any of outdoor unit stops for a period of 20 minutes or more (in heating).
 - There are outdoor units that stop operation (in cooling).
 - Low pressure of all outdoor units in operation is less than 0.25 MPa (36.3 psi) (in cooling).

Example) The following diagram shows outdoor unit rotation in combination of 3 outdoor units.



Note:

1. "Master unit", "slave unit 1" and "slave unit 2" in this section are the names for installation. They are determined in installation work, and not changed thereafter. (These names are different from "master unit" and "slave unit" for control.)
The outdoor unit connected the control wires (F1 and F2) for the indoor unit should be designated as master unit.
Consequently, The LED display on the main PCB for "master unit", "slave unit 1" and "slave unit 2" do not change.

7.3 Oil Return Operation

In order to prevent the compressor from running out of oil, the oil return operation is conducted to recover oil that has flowed out from the compressor to the system side.

Tc : High pressure equivalent saturation temperature

Te : Low pressure equivalent saturation temperature

Ts1: Suction pipe temperature detected by thermistor R3T

7.3.1 Oil Return Operation in Cooling

- Oil return operation is not conducted before 2 hours have elapsed from the activation of power supply.
- After 2 hours have elapsed, oil return operation starts when the following item meets the reference value.
 - Total amount of oil discharged from the compressor
(The total amount of oil discharged from the compressor is computed from Tc, Te, and compressor loads.)
- Oil return operation starts every 8 hours of cumulative operation of the compressor, even if the reference value is not met.

Part Name	Electric Symbol	RXYQ72-120XA	RXYQ144/168XA	Function of Functional Part
Compressor 1	M1C	●	●	Capacity step PI control
Compressor 2	M2C	—	●	
Inverter fan 1	M1F	●	●	TC control
Inverter fan 2	M2F	(●)*1	●	
Electronic expansion valve (Main)	Y1E	●	●	3,000 pulses
Electronic expansion valve (Injection)	Y2E	●	●	0 pulse
Four way valve	Y1S	●	●	OFF
Solenoid valve (Accumulator oil return)	Y2S	●	●	ON
Solenoid valve (Oil return 1)	Y3S	●	●	ON
Solenoid valve (Oil return 2)	Y4S	—	●	
Ending conditions				& { <ul style="list-style-type: none"> · A lapse of 3 minutes. OR · Ts1-Te < 3°C (5.4°F) · A lapse of 6 minutes while the frequency is more than that of oil return operation.

●: equipped

—: not equipped

*1: RXYQ96/120XA only

Indoor unit actuator		Cooling oil return operation
Fan	Thermostat ON unit	Remote controller setting
	Non-operating unit	OFF
	Thermostat OFF unit	Remote controller setting
Electronic expansion valve	Thermostat ON unit	Normal control
	Non-operating unit	224 pulses
	Thermostat OFF unit	Normal control with forced thermostat ON

7.4 Defrost Operation

To defrost the outdoor heat exchanger while in evaporator, the defrost operation is conducted to recover the heating capacity.

Tc : High pressure equivalent saturation temperature

Te : Low pressure equivalent saturation temperature

Starting Conditions

- Defrost operation is not conducted before 40 minutes have elapsed from the start of heating operation.
- After 40 minutes have elapsed, defrost operation starts when the following items meet the reference values.
 - Heat transfer coefficient of the outdoor heat exchanger
(The heat transfer coefficient of the outdoor heat exchanger is computed from Tc, Te, and compressor loads.)
 - Outdoor heat exchanger deicer temperature (Tb)
- Defrost operation starts every 2 hours, even if the reference values are not met.

Part Name	Electric Symbol	RXYQ72-120XA	RXYQ144/168XA	Operation
Compressor 1	M1C	●	●	RXYQ72XA: 266 Hz RXYQ96/120XA: 188 Hz RXYQ144/168XA: 252 Hz + 252 Hz
Compressor 2	M2C	—	●	
Inverter fan 1	M1F	●	●	With high pressure OFF ↔ Step 4 ↔ Step 6
Inverter fan 2	M2F	(●)*1	●	
Electronic expansion valve (Main)	Y1E	●	●	RXYQ72XA: 480 pulses RXYQ96-168XA: 3,000 pulses
Electronic expansion valve (Injection)	Y2E	●	●	0 pulse
Four way valve	Y1S	●	●	OFF
Solenoid valve (Accumulator oil return)	Y2S	●	●	ON
Solenoid valve (Oil return 1)	Y3S	●	●	ON
Solenoid valve (Oil return 2)	Y4S	—	●	
Ending conditions				OR (<ul style="list-style-type: none"> • A lapse of 15 min. • Tb > 11°C (51.8°F) continues for 30 sec. or more

●: equipped

—: not equipped

*1: RXYQ96/120XA only

Indoor unit actuator		During defrost
Fan	Thermostat ON unit	OFF
	Non-operating unit	OFF
	Thermostat OFF unit	OFF
Electronic expansion valve	Thermostat ON unit	Defrost EV opening degree
	Non-operating unit	Defrost EV opening degree
	Thermostat OFF unit	Defrost EV opening degree

7.5 Drain Pan Heater (Option)

When the drain pan heater is connected, it operates below.

Operating conditions

OR (

- Outdoor air temperature < 3°C (37.4 °F)
- During heating operation


)



 &


- During defrost operation

8. Outline of Control (Indoor Unit)

8.1 Operation Flowchart








Notes:

- *1. If any error occurs, the relevant error code will be displayed according to the error code display of the remote controller.
- *2. When the auxiliary electric heater turns ON, the fan will stop after it conducts residual operation.
- *3. When the drain pump kit turns ON, the drain pump kit will stop after it conducts residual operation for a period of 5 min.


- *4. The control of auxiliary electric heater connected to FXTQ-TA models differ from this flowchart. For details, refer to **Heater Control (FXTQ-TA Models)** on page 125.
- *5. If the evaporator inlet temperature is kept at not more than -5°C (23°F) for a period of cumulative 10 min. or not more than -1°C (30.2°F) for a cumulative period of 40 min., freeze-up prevention operation will be conducted. If the evaporator inlet temperature is kept at not less than 7°C (44.6°F) for a consecutive period of 10 min., the freeze-up prevention operation will be reset.

- *6. Thermostat status



$a = b = 1^{\circ}\text{C}$ (1.8°F) or 0.5°C (0.9°F)
The values a and b depend on the field setting 12(22)-2.

- *7. The following models have the drain pump as standard equipment.
FXFQ-T, FXZQ-TA, FXUQ-P, FXEQ-P, FXDQ-M, FXSQ-TA, FXMQ-PB
- *8. Program dry display
No set temperature and airflow rate of the remote controller are displayed.
- *9. Thermostat status
Set temperature when operating the program dry mechanism.



Suction air temperature

- *10. Fan operation

By setting the remote controller to Fan, the fan will operate with thermostat OFF in set temperature control operation mode.

- *11. Set wind direction

According to wind direction instruction from the remote controller, the wind direction is set to 100% horizontal while in heating operation.

- *12. Fan

According to fan speed instruction from the remote controller, the fan is put into operation in LL mode while in heating operation.


- *13. Wind direction

When the heating thermostat turns OFF, the wind direction will be set to 100% horizontal.

- *14. Hot start

If the condenser inlet temperature exceeds 34°C (93.2°F) at the time of starting operation or after the completion of defrost operation, or until 3 minutes pass or T_c is above 52°C (125.6°F), hot starting will be conducted.

- *15. Thermostat status



- *16. Outlet air temperature drop protection

When the set temperature is below 24°C (75.2°F) or the electronic expansion valve opening is small, the protection will be activated.

- *17. **Hu** indicates the Humidifier connected to the wiring modification adaptor.

It is not related to the Humidifier terminals on the PCB of FXTQ-TA or CXTQ-TA.

- *18. Only for CXTQ-TA.

Refer to **Gas Furnace Control (CXTQ-TA Models)** on page 128 for details.

8.2 Set Temperature and Control Temperature

8.2.1 Without Optional Infrared Presence/Floor Sensor

The relationship between remote controller set temperature and control target temperature is described below.

- When the suction air thermistor is used for controlling (Default), the control target temperature is determined as follows to prevent insufficient heating in heating operation.

Control target temperature: remote controller displayed temperature + 2°C (3.6°F).

- The temperature difference for cooling ↔ heating mode switching is 5°C (9°F).
- The above also applies to automatic operation.

■ When setting the suction air thermistor (Default setting)

Temperature		14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35°C	
		57.2	59	60.8	62.6	64.4	66.2	68	69.8	71.6	73.4	75.2	77	78.8	80.6	82.4	84.2	86	87.8	89.6	91.4	93.2	95°F	
Cooling	Remote controller set temperature																							
	Control target temperature																							
Heating	Remote controller set temperature																							
	Control target temperature																							

■ When using the remote controller thermistor (Field setting is required)

Temperature		14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35°C	
		57.2	59	60.8	62.6	64.4	66.2	68	69.8	71.6	73.4	75.2	77	78.8	80.6	82.4	84.2	86	87.8	89.6	91.4	93.2	95°F	
Cooling	Remote controller set temperature																							
	Control target temperature																							
Heating	Remote controller set temperature																							
	Control target temperature																							

Examples are given to illustrate a control target temperature that satisfies the remote controller set temperature.

8.2.2 With Optional Infrared Presence/Floor Sensor

The relationship between remote controller set temperature and control target temperature is described below.

- The temperature difference for cooling ⇔ heating mode switching is 5°C (9°F).
- When using the floor temperature as the control target, the remote controller set temperature is equal to the actual control target temperature in heating operation.
- The above also applies to automatic operation.

■ When setting the suction air thermistor (Default setting)

Temperature		14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	
		57.2	59	60.8	62.6	64.4	66.2	68	69.8	71.6	73.4	75.2	77	78.8	80.6	82.4	84.2	86	87.8	89.6	91.4	93.2	95	96.8	
Cooling	Remote controller set temperature																								
	Control target temperature																								
Heating	Remote controller set temperature																								
	Control target temperature																								

■ When using the remote controller thermistor (Field setting is required)

Temperature		14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	
		57.2	59	60.8	62.6	64.4	66.2	68	69.8	71.6	73.4	75.2	77	78.8	80.6	82.4	84.2	86	87.8	89.6	91.4	93.2	95	96.8	
Cooling	Remote controller set temperature																								
	Control target temperature																								
Heating	Remote controller set temperature																								
	Control target temperature																								

Examples are given to illustrate a control target temperature that satisfies the remote controller set temperature.

Regarding control target temperature

When using the infrared presence/floor sensor, the temperature around people will be treated as the control target temperature for operation.

What is the temperature around people?

The temperature around people refers to the temperature of the living space, obtained from the temperature around the ceiling and the temperature underfoot. The temperature is calculated using the detected values of the suction air thermistor and the infrared presence/floor sensor.

It is difficult to use only suction air temperature control for underfoot air conditioning.

8.3 Remote Controller Thermistor

Temperature is controlled by both the remote controller thermistor and suction air thermistor for the indoor unit. (This is however limited to when the field setting for the remote controller thermistor is set to Use.)




Note:

When fresh air intake kit is used, outdoor air is mixed with indoor air, and the room temperature may not reach the set temperature, since TS and TH1 do not enter the area in which remote controller thermistor can be used. In such case, install the remote sensor (optional accessory) in your room, and set the field settings to not use the remote controller thermistor.
 * FXTQ-TA and CXTQ-TA models do not have this control because they do not have suction air thermistor. The thermistor is selectable manually when remote sensor (optional accessory) is installed.

Cooling


If there is a significant difference in the set temperature and the suction temperature, fine adjustment control is carried out using a suction air thermistor, or using the remote controller thermistor near the position of the user when the suction temperature is near the set temperature.



- **Assuming the set temperature in the figure above is 24°C (75°F), and the suction temperature has changed from 18°C (64°F) to 30°C (86°F) (A → F):**
 (This example also assumes there are several other air conditioners, and the suction temperature changes even when the thermostat is off.)
 Suction air thermistor is used for temperatures from 18°C (64°F) to 23°C (73°F) (A → C).
 Remote controller thermistor is used for temperatures from 23°C (73°F) to 27°C (81°F) (C → E).
 Suction air thermistor is used for temperatures from 27°C (81°F) to 30°C (86°F) (E → F).
- **Assuming suction temperature has changed from 30°C (86°F) to 18°C (64°F) (F → A):**
 Suction air thermistor is used for temperatures from 30°C (86°F) to 25°C (77°F) (F → D).
 Remote controller thermistor is used for temperatures from 25°C (77°F) to 21°C (70°F) (D → B).
 Suction air thermistor is used for temperatures from 21°C (70°F) to 18°C (64°F) (B → A).

Heating

When heating, the hot air rises to the top of the room, resulting in the temperature being lower near the floor where the occupants are. When controlling by suction air thermistor only, the indoor unit may therefore be turned off by the thermostat before the lower part of the room reaches the set temperature. The temperature can be controlled so the lower part of the room where the occupants are does not become cold by widening the range in which remote controller thermistor can be used so that suction temperature is higher than the set temperature.



■ **Assuming the set temperature in the figure above is 24°C (75°F), and the suction temperature has changed from 18°C (64°F) to 28°C (82°F) (A → D):**

(This example also assumes there are several other air conditioners, and the suction temperature changes even when the thermostat sensor is off.)

Suction air thermistor is used for temperatures from 18°C (64°F) to 25°C (77°F) (A → C).

Remote controller thermistor is used for temperatures from 25°C (77°F) to 28°C (82°F) (C → D).

■ **Assuming suction temperature has changed from 28°C (82°F) to 18°C (64°F) (D → A):**

Remote controller thermistor is used for temperatures from 28°C (82°F) to 23°C (73°F) (D → B).

Suction air thermistor is used for temperatures from 23°C (73°F) to 18°C (64°F) (B → A).


8.4 Thermostat Control

8.4.1 Without Optional Infrared Presence/Floor Sensor


Whether the thermostat is turned on or off is determined by the difference between the remote controller set temperature and the actual detected room temperature (*1).

Normal operation

- Cooling operation




- Heating operation




Dry operation

- When $T_{ro} < 24.5^{\circ}\text{C}$ (76.1°F)




- When $T_{ro} \geq 24.5^{\circ}\text{C}$ (76.1°F)



FXTQ-TA, CXTQ-TA only

If the field setting 14(24)-5 is set to **02**, T_{ro} will be the same as the cooling set temperature.



ΔT : Room temperature – Remote controller set temperature

T_{ro} : Room temperature at the start of dry operation

T_r : Room temperature


*1: The thermistor for room temperature detection depends on the field setting 10 (20)-2.

8.4.2 With Optional Infrared Presence/Floor Sensor


Whether the thermostat is turned on or off is determined by the difference between the remote controller set temperature and the detected temperature around people.

Normal operation

- Cooling operation




- Heating operation




Dry operation

- When $T_{ro} \leq 24.5^{\circ}\text{C} (76.1^{\circ}\text{F})$



- When $T_{ro} > 24.5^{\circ}\text{C} (76.1^{\circ}\text{F})$



ΔT : Room temperature or temperature around people – Remote controller set temperature

T_{ro} : Room temperature or temperature around people at the start of dry operation

T_r : Room temperature or temperature around people

Control range of temperature around people

When the floor temperature is very low, operation using the temperature around people may cause the suction air temperature to operate outside of use range.

To avoid the above condition, a limit based on the suction air temperature is set for the use range of the temperature around people.

• Cooling operation

- When the floor temperature is lower than suction air temperature (R1T), R1T will be treated as the control target temperature for operation.
- When the temperature around people is $15^{\circ}\text{C} (59^{\circ}\text{F})$ or lower, R1T will be treated as the control temperature for operation.

• Heating operation

- When the floor temperature is higher than suction air temperature (R1T), R1T will be treated as the control target temperature in operation.
- When the temperature around people is $33^{\circ}\text{C} (91.4^{\circ}\text{F})$ or higher, R1T will be treated as the control temperature for operation.


8.4.3 Thermostat Control with Operation Mode Set to AUTO

The system will conduct this temperature control shown below, only when the wireless remote controller or any central remote controller is connected.


Furthermore, setting changes of the differential value (D) can be made.

Mode No.	First code No.	Contents of setting	Second code No.							
			01	02	03	04	05	06	07	08
12 (22)	4	Differential value while in AUTO operation mode	0°C 0°F	1°C 1.8°F	2°C 3.6°F	3°C 5.4°F	4°C 7.2°F	5°C 9.0°F	6°C 10.8°F	7°C 12.6°F

■ : Factory setting




(Ex.) When automatic cooling temperature is set to 27°C (80.6°F):




8.5 Drain Pump Control

8.5.1 Normal Operation




- The float switch is ON in normal operation.
- When cooling operation starts (thermostat ON), the drain pump turns ON simultaneously.
- After the thermostat turns OFF, the drain pump continues to operate for another 5 minutes.
- The aim of residual operation after thermostat OFF is to eliminate the dew that condenses on the indoor heat exchanger during cooling operation.

8.5.2 If the Float Switch is OFF with the Thermostat ON in Cooling Operation




- When the float switch turns OFF, the thermostat turns OFF simultaneously.
- After the thermostat turns OFF, the drain pump continues to operate for another 5 minutes.
- *1. If the float switch turns ON again during the residual operation of the drain pump, cooling operation also turns on again (thermostat ON).
- *2. If the float switch remains OFF even after the residual operation of the drain pump has ended, the error code **A3** is displayed on the remote controller.
- *3. The drain pump turns OFF once residual operation has ended, then turns ON again after 5 seconds.
- *4. After **A3** is displayed and the unit comes to an abnormal stop, the thermostat will remain OFF even if the float switch turns ON again.

8.5.3 If the Float Switch is OFF with the Thermostat OFF in Cooling Operation



- When the float switch turns OFF, the drain pump turns ON simultaneously.
- If the float switch remains OFF even after the residual operation of the drain pump has ended, the error code **A3** is displayed on the remote controller.
- The drain pump turns OFF once residual operation has ended, then turns ON again after 5 seconds.

8.5.4 If the Float Switch Turns OFF and ON Continuously, or the Float Switch Turns OFF While AF Displayed



- When the float switch turns OFF, the drain pump turns ON simultaneously.
- *1: If the float switch continues to turn OFF and ON 5 times consecutively, it is judged as a drain system error and the error code **AF** is displayed on the remote controller.
- *2: The drain pump continues to turn ON/OFF in accordance with the float switch ON/OFF even after **AF** is displayed on the remote controller.
- *3: While the error code **AF** is displayed, if the float switch remains OFF even after the residual operation of the drain pump has ended, the error code **A3** will be displayed on the remote controller.

8.6 Control of Electronic Expansion Valve

Electronic expansion valves in indoor units have the functions of conducting superheating degree control in cooling operation and subcooling degree control in heating operation. However, if the indoor units receive any control command such as a protection control command or a special control command from the outdoor unit, the units will give a priority to the control command.

• Superheating degree control in cooling operation

This function is used to adjust the opening of the electronic expansion valve so that superheating degree (SH), which is calculated from the detection temperature (Tg) of the gas pipe thermistor (R3T) and the detection temperature (TI) of the liquid temperature thermistor (R2T) of the indoor unit, will come close to a target superheating degree (SHS).

At that time, correction to the superheating degree is made according to the differences (ΔT) between set temperature and suction air temperature.

$$SH = T_g - T_I$$

SH: Evaporator outlet superheating degree

Tg: Indoor unit gas pipe temperature (R3T)

TI: Indoor unit liquid pipe temperature (R2T)

SHS (Target SH value)

SHS: Target superheating degree

- Normally 5°C (9°F)
- As ΔT (Remote controller set temp. – Suction air temp.) becomes larger, SHS becomes lower.
- As ΔT (Remote controller set temp. – Suction air temp.) becomes smaller, SHS becomes higher.

• Subcooling degree control in heating operation

This function is used to adjust the opening of the electronic expansion valve so that the high pressure equivalent saturated temperature (Tc), which is converted from the detected pressure of the high pressure sensor in the outdoor unit, and the subcooling degree (SC), which is calculated from the detected temperature (TI) of the liquid temperature thermistor (R2T) in the indoor unit, will come close to the target subcooling degree (SCS).

At that time, corrections to the subcooling degree are made according to differences (ΔT) between set temperature and suction air temperatures.

$$SC = T_c - T_I$$

SC: Condenser outlet subcooling degree

Tc: High pressure equivalent saturated temperature detected by the high pressure sensor (S1NPH)

TI: Indoor unit liquid pipe temperature (R2T)

SCS (Target SC value)

SCS: Target subcooling degree

- Normally 5°C (9°F)
- As ΔT (Remote controller set temp. – Suction air temp.) becomes larger, SCS becomes lower.
- As ΔT (Remote controller set temp. – Suction air temp.) becomes smaller, SCS becomes higher.

8.7 Freeze-up Prevention

Freeze-up Prevention by Off Cycle (Indoor Unit Individual Control)

When the temperature detected by the liquid pipe temperature thermistor of the indoor heat exchanger drops too low, the unit enters freeze-up prevention control in accordance with the following conditions, and is also set in accordance with the conditions given below. (Thermostat OFF)

When freeze-up prevention is activated, the electronic expansion valve is closed, the drain pump turns on and the airflow rate is fixed to L tap. When the following conditions for cancelling are satisfied, it will reset.

Conditions for starting:


Liquid pipe temperature $\leq -1^{\circ}\text{C}$ (30.2°F) (for total of 40 minutes)

or

Liquid pipe temperature $\leq -5^{\circ}\text{C}$ (23°F) (for total of 10 minutes)

Condition for cancelling:

Liquid pipe temperature $\geq +7^{\circ}\text{C}$ (44.6°F) (for 10 minutes continuously)



Concept of freeze-up prevention control

System avoids freeze-up prevention


- For comfort, system avoids unnecessary thermostat ON/OFF
- For ensuring compressor reliability, system avoids unnecessary compressor ON/OFF

When freeze-up prevention control starts, system makes sure the frost is completely removed.

- System avoids water leakage.



Note: When the indoor unit is FXFQ-T, FXZQ-TA or FXUQ-P, if the air outlet is set as dual-directional or tri-directional, the starting conditions will be changed as follows.
 Liquid pipe temperature $\leq 1^{\circ}\text{C}$ (33.8°F) (for total of 15 minutes)
or
 Liquid pipe temperature $\leq 0^{\circ}\text{C}$ (32°F) (for 1 minute continuously)
 During freeze-up prevention control, the airflow rate is fixed to LL.
 (The cancelling conditions are same as the standard.)



8.8 List of Swing Flap Operations

Swing flaps operate as shown in table below.

			Fan	Flap			
				FXFQ-T	FXEQ-P	FXHQ-M	FXAQ-P
Heating	Hot start from defrost operation	Swing	OFF	Horizontal	Horizontal	Horizontal	Horizontal
		Airflow direction set	OFF	Horizontal	Horizontal	Horizontal	Horizontal
	Defrost operation	Swing	OFF	Horizontal	Horizontal	Horizontal	Horizontal
		Airflow direction set	OFF	Horizontal	Horizontal	Horizontal	Horizontal
	Thermostat OFF	Swing	LL	Horizontal	Horizontal	Horizontal	Horizontal
		Airflow direction set	LL	Horizontal	Horizontal	Horizontal	Horizontal
	Hot start from thermostat OFF mode (for prevention of cold air)	Swing	LL	Horizontal	Horizontal	Horizontal	Horizontal
		Airflow direction set	LL	Horizontal	Horizontal	Horizontal	Horizontal
	Stop	Swing	OFF	Horizontal	Horizontal	Horizontal	Totally closed
		Airflow direction set	OFF	Horizontal	Horizontal	Horizontal	Totally closed
Cooling	Thermostat ON in program dry	Swing	L (*1)	Swing	Swing	Swing	Swing
		Airflow direction set	L (*1)	Set	Set	Set	Set
	Thermostat OFF in program dry	Swing	OFF or L	Swing	Swing	Swing	Swing
		Airflow direction set		Horizontal or Set	Set	Set	Set
	Thermostat OFF in cooling	Swing	Set	Swing	Swing	Swing	Swing
		Airflow direction set	Set	Set	Set	Set	Set
	Stop	Swing	OFF	Horizontal	Horizontal	Horizontal	Totally closed
		Airflow direction set	OFF	Horizontal	Horizontal	Horizontal	Totally closed
	Microcomputer control (including cooling operation)	Swing	L	Swing	Swing	Swing	Swing
		Airflow direction set	L	Set	Set	Set	Set




Note: *1. L or LL only on FXFQ-T models

8.9 Hot Start Control (In Heating Only)


At startup with thermostat ON or after the completion of defrosting in heating operation, the indoor fan is controlled to prevent cold air from blasting out and ensure startup capacity.

TH2 : Temperature detected with the gas thermistor

Tc : High pressure equivalent saturated temperature




■ When the heater of FXTQ-TA is to be used



8.10 Louver Control for Preventing Ceiling Dirt

We have added a control feature that allows you to select the range of in which air direction can be adjusted in order to prevent the ceiling surrounding the air discharge outlet of ceiling mounted cassette type units from being soiled. (This feature is available on FXFQ-T, FXZQ-TA and FXEQ-P models)



Factory setting

FXFQ-T models: draft prevention position

FXZQ-TA, FXEQ-P models: standard position

8.11 Heater Control (Except FXTQ-TA Models)




Note: Optional PCB KRP1B ... is required.

The heater control is conducted in the following manner.

Normal control


While in heating, the heater control (ON/OFF) is conducted as shown on the right.




Overload control

When the system is overloaded in heating, the heater will be turned OFF in the following 2 manners.

(1) The heater control (ON/OFF) is conducted through the liquid pipe temperature (R2T) of the indoor unit.



(2) The heater control (ON/OFF) is conducted by converting the heater temperature into the condensing pressure equivalent saturated temperature (Tc) according to the temperature detection through the high pressure sensor (S1NPH) of the outdoor unit.



Fan residual operation

While the heater turns OFF, in order to prevent the activation of the thermal protector, the fan conducts residual operation for a given period of time after the heater turns OFF. (This operation is conducted regardless of with or without heater equipped.)

Residual operation time: 100 seconds on ceiling suspended type or 60 seconds on other types


8.12 Heater Control (FXTQ-TA Models)



Note: Optional heater kit HKS... is required.
 For FXTQ-TA models, heater ON/OFF output from wiring adaptor interlocks with the operation of heater kit HKS....(When the heater 1 turns ON/OFF, heater output of wiring adaptor turns ON/OFF.)
 Fan residual operation also interlocks with the fan residual operation of heater kit HKS.... The residual time will be 90 seconds. (Refer to Fan Control (Heater Residual) (FXTQ-TA Models) on page 130.)

8.12.1 Auxiliary Electric Heater Control

If heating is insufficient in heat pump system alone, an electric heater is to be used as the auxiliary heater. The following shows the ON/OFF conditions for the electric heater.



Condition A

- No fan motor system error
 - High pressure condition: ON (*1)
 - Liquid pipe temperature condition: ON (*2)
- & (
- OR (
 - & (
 - Heater ON permission (Defrost/oil Return): 0 (*4)
 - Not during defrost/oil return
 - Heater ON permission (Defrost/oil return): 1 (*4)

Condition B


- No fan motor system error
- During defrost/oil return
- Heater ON permission (Defrost/oil return): 1 (*4)

Condition C


- OR (
- Not during defrost/oil return
- Fan motor system error
- Heater ON permission (Defrost/oil return): 0 (*4)

**Notes:**

*1: High pressure condition



*2: Liquid pipe temperature condition



*3. Auxiliary heater enabled

- 1: (
- Electric heater setting (Field setting 11(21)-3): **02, 08** (*6)
- Electric heater capacity setting \neq **01**
- 0: Other than the above

*4. Heater ON permission (Defrost/oil return)

- 1: Electric heater setting (Field setting 11(21)-3): **08** (*6)
- 0: Electric heater setting (Field setting 11(21)-3): **02** (*6)


*5. Field setting 11(21)-5. Refer to page 146.

*6. Field setting 11(21)-3. Refer to page 145.

8.12.2 Heat Pump Lockout Control

For heating operation, users can select to use electric heater. For this, signals are sent using ABC terminal of outdoor unit PCB.

When the hot-water heating signal is received from the outdoor unit PCB, heating operation is performed only with the electric heater as manual backup operation. The ON/OFF conditions for the electric heater are shown below.



Notes:


- *1. The heater backup prohibiting conditions are prioritized. Even when the heater ON conditions are met, the heater is turned OFF when the prohibiting conditions are met.
- *2. When the remote controller is ON, Time-up will be set to the initial value.

8.13 Gas Furnace Control (CXTQ-TA Models)

Outline

When conditions for gas furnace operation are established, the system transits into gas furnace operation, CXTQ-TA requires the gas furnace combustion heating.

Detail



Note: The airflow rate during gas furnace operation depends on the intensity of combustion heating and therefore may be different from the airflow setting displayed on the remote controller.

8.14 3-Step Thermostat Processing (FXTQ-TA Models)

Outline


The thermostat ON/OFF for the indoor unit is controlled in accordance with [Thermostat Step 1].
The heater ON/OFF operation during heating is controlled as follows.

Thermostat step 2, 3: Auxiliary electric heater control

Thermostat step 1, 2: Heat pump lockout control

For more details of the heater, refer to **Heater Control (FXTQ-TA Models)** on page 125.

Detail



Notes:


- *1. **S** value varies automatically based on the room temperature trend.
- *2. $T_{on} + S > -B$ ($^{\circ}C$), $T_{off} + S < A$ ($^{\circ}C$)
- *3. For parameters, refer to page 144.
- *4. **A** and **B** values vary automatically based on the field setting 12(22)-2.
- *5. If, directly after a change in conditions, it is such that the thermostat could be either ON or OFF (controlled temperature is within ranges **A** and **B**), the thermostat will be switched to ON.

8.15 Fan Control (Heater Residual) (FXTQ-TA Models)

Outline

If the indoor heater turned OFF from ON during heating operation, the fan will keep operating for further period of time in order to cool the heater.

Detail




- *1. When the heater is ON, the airflow rate of the fan will be whichever is the largest between the CFM dictated by the heater's own capacity, or the fan tap CFM determined by other controls.
- *2. Fan residual operation will continue, even if the indoor unit is turned off with the remote controller operation button.

8.16 Interlocked with External Equipment (FXTQ-TA and CXTQ-TA Models)

8.16.1 Air Purifier (UV lamp)


When an air purifier is connected onsite, the fan is operated with the airflow rate set of the remote controller or with the H tap.



- *1. External input ON is an input signal to the X1M-AIR CLEANER terminal on the PCB.

8.16.2 Humidifier

When a humidifier is connected onsite, the fan operates with the airflow rate set of the remote controller or with the H tap.



- *1. External input ON is an input signal to the X1M-HUMIDIFIER terminal on the PCB.



Note:

This control is not applicable to the humidifier connected to the wiring adaptor, but to the humidifier connected to HUMIDIFIER on the X1M terminal of the indoor unit PCB.

8.16.3 Economizer

When indoor and outdoor air temperatures are reversed, the compressor is stopped to let in the outdoor air to save energy.


This operation is called economizer operation, and the equipment to detect indoor and outdoor air temperatures and open and close the damper to perform this operation is called an economizer.

The economizer detects indoor and outdoor air temperatures, informs the air conditioner that the economizer operation is ready, and opens and closes the damper.


The indoor unit stops the outdoor unit when it receives a signal from the economizer and performs air supply operation.

When the indoor air temperature is cooled down sufficiently by the economizer operation, and it is no longer necessary (thermostat OFF), the indoor unit outputs a signal to the economizer to close the damper.


■ Thermostat ON signal



■ Operation



■ Indoor unit ON signal



*1. Thermostat ON signal: A signal to turn ON the indoor unit thermostat and allow the economizer to open the damper.

It turns ON the relay on the X2M-ECONOMIZER2 on the PCB.

*2. External input ON is an input signal to the X1M-ECONOMIZER1 terminal on the PCB.

*3. Refer to **Optional Kit Setting (UV lamp + Humidifier + Economizer) (for FXTQ-TA and CXTQ-TA model)** on page 153.

*4. Remote control ON signal: Contact output which shows the operating status of the indoor unit. This signal turns on the relay X2M-CONTROL ON/OFF on the PCB.

Part 5

Field Settings and Test Operation

1. Field Settings for Indoor Unit.....	133
1.1 Field Settings with Remote Controller	133
1.2 Wireless Remote Controller	135
1.3 Simplified Remote Controller.....	136
1.4 List of Field Settings for Indoor Unit	137
1.5 Gas Furnace Set Up.....	156
1.6 List of Field Settings for Outdoor-Air Processing Unit.....	157
1.7 Setting of Operation Control Mode.....	157
2. Field Settings for Outdoor Unit.....	159
2.1 Function Setting	159
2.2 Settings by DIP Switches	161
2.3 Accessing the BS Buttons on the PCB.....	164
2.4 Settings by BS Buttons.....	165
2.5 Normal Mode.....	167
2.6 Monitor Mode (Mode 1).....	168
2.7 Setting Mode (Mode 2).....	172
3. Test Operation	190
3.1 Checks before Test Operation	190
3.2 Checkpoints.....	190
3.3 Check Work Prior to Turn Power Supply ON	191
3.4 Turn Power ON	192
3.5 Gas Furnace Test Operation.....	193

1. Field Settings for Indoor Unit


1.1 Field Settings with Remote Controller

Individual function of indoor unit can be changed from the remote controller. At the time of installation or after service inspection / repair, make the field setting in accordance with the following description.

Wrong setting may cause error.

(When optional accessory is mounted on the indoor unit, setting for the indoor unit may be required to change. Refer to information in the option handbook.)

1.1.1 Wired Remote Controller




1. Press and hold Cancel button for 4 seconds or more. Service settings menu is displayed.
2. Select **Field Settings** in the Service Settings menu, and press Menu/OK button. Field settings screen is displayed.
3. Highlight the mode, and select desired **Mode No.** by using ▲▼ (Up/Down) button.
4. In the case of setting per indoor unit during group control (When Mode No. such as **20, 21, 22, 23, 25** are selected), highlight the unit No. and select **Indoor unit No.** to be set by using ▲▼ (Up/Down) button. (In the case of group total setting, this operation is not needed.)

[In the case of individual setting per indoor unit, current settings are displayed. And, SECOND CODE NO. " - " means no function.]

5. Highlight SECOND CODE NO. of the FIRST CODE NO. to be changed, and select desired **SECOND CODE NO.** by using ▲▼ (Up/Down) button. Multiple identical mode number settings are available.

[In case of setting for all indoor units in the remote control group, available SECOND CODE NO. is displayed as " * " which means it can be changed. When SECOND CODE NO. is displayed as " - ", there is no function.]




6. Press Menu/OK button. Setting confirmation screen is displayed.
7. Select **Yes** and press Menu/OK button. Setting details are determined and field settings screen returns.
8. In the case of multiple setting changes, repeat (3) to (7).
9. After all setting changes are completed, press Cancel button twice.
10. Backlight goes out, and **Checking the connection. Please standby.** is displayed for initialization. After the initialization, the basic screen returns.

NOTE

- Installation of optional accessories on the indoor unit may require changes to field settings. See the manual of the optional accessory.
- For field setting details related to the indoor unit, see installation manual shipped with the indoor unit.

1.2 Wireless Remote Controller




To set the field settings, you have to change:

- Mode No.
- First code No.
- Second code No.

To change the field settings, proceed as follows:

1. Press the **INSPECTION/TEST** button for 4 seconds during normal mode to enter the field setting mode.
2. Press the **MODE** button to select the desired mode No.
3. Press the **UP** button to select the first code No.
4. Press the **DOWN** button to select the second code No.
5. Press the **RESERVE** button to confirm the setting.
6. Press the **INSPECTION/TEST** button to return to the normal mode.

1.3 Simplified Remote Controller



1. Remove the upper part of remote controller.
2. When in the normal mode, press the **BS6** button (2) (field setting) to enter the field setting mode.
3. Select the desired MODE No. with the **BS2** button (3) (temperature setting ▲) and the **BS3** button (3) (temperature setting ▼).
4. During group control, when setting by each indoor unit (mode No. 20, 22, and 23 have been selected), press the **BS8** (4) button (unit No.) and select the indoor unit No. to be set. (This operation is unnecessary when setting by group.)
5. Press the **BS9** button (5) (set A) and select first code No.
6. Press the **BS10** button (6) (set B) and select second code No.
7. Press the **BS7** button (7) (set/cancel) once and the present settings are confirmed.
8. Press the **BS6** button (8) (field setting) to return to the normal mode.

1.4 List of Field Settings for Indoor Unit

■ : Factory setting

Mode No. (*2)	First Code No.	Setting Contents		Second Code No.				
				01	02	03	04	
10 (20)	0	Ultra long life filter	Light	Approx. 10,000 hrs.	Heavy	Approx. 5,000 hrs.	—	—
		Long life filter		Approx. 2,500 hrs.		Approx. 1,250 hrs.		
		Standard filter		Approx. 200 hrs.		Approx. 100 hrs.		
	0	Filter sign setting	Light		Heavy		—	—
	1	Filter type	Long life filter		Ultra long life filter		—	—
	1	Filter cleaning sign interval	Short interval		Long interval		—	—
	2	Thermistor selection	Refer to page 141 for details.					
	3	Filter cleaning sign	Displayed		Not displayed		—	—
	5	Information for intelligent Touch Manager / intelligent Touch Controller	Refer to page 143 for details.					
6	Remote controller thermostat control during group control	Not permitted		Permitted		—	—	
7	Time for absence area detection	30 minutes		60 minutes		—	—	
11 (21)	1	Auxiliary electric heater ON temperature: Ton		Refer to page 144 for details.				
	1	Auxiliary electric heater ON/OFF temperature: Ton/Toff						
	2	Auxiliary electric heater OFF temperature: Toff						
	3	Setting the airflow rate when heating		Standard	Slightly increased	Increased	—	
	3	Electric heater setting		Refer to page 145 for details.				
	5	Electric heater capacity setting		Refer to page 146 for details.				
	6	Setting the rate of human detection		High sensitivity	Low sensitivity	Standard sensitivity	Infrared presence/floor sensor disabled	
	7	Automatic airflow adjustment		OFF	Completion of airflow adjustment	Start of airflow adjustment	—	
	8	Compensating the temperature around people		Suction air temperature only	Priorities given on the suction air temperature	Standard	Priorities given on the floor temperature	
9	Compensating the floor temperature		-4°C (-7.2°F)	-2°C (-3.6°F)	0°C (0°F)	+2°C (+3.6°F)		
12 (22)	0	Optional output switching		Refer to page 148 for details.				
	1	External ON/OFF input		Refer to page 148 for details.				
	2	Thermostat switching		1°C (1.8°F)	0.5°C (0.9°F)	—	—	
	3	Airflow setting when heating thermostat is OFF		LL tap	Set fan speed	OFF	—	
	4	Setting of operation mode to AUTO		Refer to page 149 for details.				
	5	Auto restart after power failure		OFF	ON	—	—	
	6	Airflow setting when cooling thermostat is OFF		LL tap	Set fan speed	OFF	—	
13 (23)	0	Setting of airflow rate		Standard	High ceiling 1	High ceiling 2	—	
	1	Airflow direction setting		F (4 directions)	T (3 directions)	W (2 directions)	—	
	2	Swing pattern settings		All direction synchronized swing	—	Facing swing	—	
	4	Setting of airflow direction adjustment range		Draft prevention	Standard	Ceiling soiling prevention	—	
	5	Setting of static pressure selection		Standard	High static pressure	—	—	
	6	External static pressure settings		Refer to page 152 for details.				

Mode No. (*2)	First Code No.	Setting Contents	Second Code No.			
			01	02	03	04
14 (24)	4	Optional kit setting (UV lamp + humidifier + economizer)	Refer to page 153 for details.			
	5	Residential dry	Set temperature: room temperature	Set temperature: same as cooling set temperature	—	—
	9	Mold proof operation setting	—	Standard	For high humidity areas	—
	11	Gas furnace test mode	OFF	Low heat	High heat	—
15 (25)	0	Drain pump operation settings	—	ON	OFF	—
	1	Humidification when heating thermostat is OFF	Not equipped	Equipped	—	—
	2	Setting of direct duct connection	Not equipped	Equipped	—	—
	3	Interlocked operation between humidifier and drain pump	Not interlocked	Interlocked	—	—
	5	Individual setting of ventilation	— (Normal)	Individual	—	—
1b	4	Display of error codes on the remote controller	—	Two-digit display	—	Four-digit display
	14	Setting "restricted / permitted" of airflow block	Refer to page 155 for details.			
1c	0	Room temperature display	Room temperature is not displayed	Room temperature is displayed	—	—
	1	Thermistor sensor for auto changeover and setback control by the remote controller	Utilize the return air thermistor	Utilize the remote controller thermistor	—	—
	3	Access permission level setting	Level 2	Level 3	—	—
1e	2	Setback availability	N/A	Heat only	Cool only	Cool/heat

**Notes :**

1. Settings are made simultaneously for the entire group, however, if you select the mode No. inside parentheses, you can also set by each individual unit. Setting changes however cannot be checked except in the individual mode for those in parentheses.
- *2. The mode numbers inside parentheses cannot be used by wireless remote controllers, so they cannot be set individually. Setting changes also cannot be checked.
3. Do not make settings other than those described above. Nothing is displayed for functions the indoor unit is not equipped with.
4. **88** or **Checking the connection. Please stand by.** may be displayed to indicate the remote controller is resetting when returning to the normal mode.

1.4.1 Applicable Range of Field setting

Field setting	First Code No.	Setting Modes	FXFQ-T	FXZQ-TA	FXUQ-P	FXEQ-P	FXDQ-M	FXSQ-TA	FXMQ-PB
10 (20)	0	Filter cleaning sign interval	●	●	●	●	●	●	●
	0	Filter sign setting	—	—	—	—	—	—	—
	1	Filter type	●	●	●	—	—	●	—
	1	Filter cleaning sign interval	—	—	—	—	—	—	—
	2	Thermistor selection	●	●	●	●	●	●	●
	3	Filter cleaning sign	●	●	●	●	●	●	●
	5	Information for intelligent Touch Manager/ intelligent Touch Controller	●	●	●	●	●	●	●
	6	Remote controller thermostat control during group control	●	●	●	●	●	●	●
	7	Time for absence area detection	●	●	●	—	—	—	—
11 (21)	1	Auxiliary electric heater ON temperature	—	●	●	●	—	●	—
	1	Auxiliary electric heater ON/OFF temperature	●	—	—	—	—	—	●
	2	Auxiliary electric heater OFF temperature	—	●	●	●	—	●	—
	3	Setting the airflow rate when heating	●	●	●	●	—	—	—
	3	Electric heater setting	—	—	—	—	—	—	—
	5	Electric heater capacity setting	—	—	—	—	—	—	—
	6	Setting the rate of human detection	●	●	●	—	—	—	—
	7	Automatic airflow adjustment	—	—	—	—	—	●	● (*1)
	8	Compensating the temperature around people	●	●	●	—	—	—	—
9	Compensating the floor temperature	●	●	●	—	—	—	—	
12 (22)	0	Optional output switching	●	●	●	●	●	●	●
	1	External ON/OFF input	●	●	●	●	●	●	●
	2	Thermostat switching	●	●	●	●	●	●	●
	3	Airflow setting when heating thermostat is OFF	●	●	●	●	●	●	●
	4	Setting of operation mode to AUTO	●	●	●	●	●	●	●
	5	Auto restart after power failure	●	●	●	●	●	●	●
	6	Airflow setting when cooling thermostat is OFF	●	●	●	●	●	●	●
13 (23)	0	Setting of airflow rate	●	●	●	●	●	●	●
	1	Airflow direction setting	●	●	●	—	—	—	—
	2	Swing pattern settings	●	●	●	—	—	—	—
	4	Setting of airflow direction adjustment range	●	●	●	●	—	—	—
	5	Setting of static pressure selection	—	—	—	—	●	—	—
	6	External static pressure settings	—	—	—	—	—	●	●
14 (24)	4	Optional kit setting (UV lamp + Humidifier + Economizer)	—	—	—	—	—	—	—
	5	Residential dry	—	—	—	—	—	—	—
	9	Mold proof operation setting	—	—	—	●	—	—	—
	11	Gas furnace test mode	—	—	—	—	—	—	—
15 (25)	0	Drain pump operation settings	—	—	—	—	—	—	●
	1	Humidification when heating thermostat is OFF	●	●	●	●	●	●	●
	2	Setting of direct duct connection	●	●	●	●	—	—	—
	3	Interlocked operation between humidifier and drain pump	●	●	●	●	●	●	●
	5	Individual setting of ventilation	●	●	●	●	●	●	●
1b	4	Display of error codes on the remote controller	●	●	●	●	●	●	●
	14	Setting "restricted / permitted" of airflow block	●	●	●	—	—	—	—
1c	0	Room temperature display	●	●	●	●	●	●	●
	1	Thermistor sensor for auto changeover and setback control by the remote controller	●	●	●	●	●	●	●
	3	Access permission level setting	●	●	●	●	●	●	●
1e	2	Setback availability	●	●	●	●	●	●	

● : Available

— : Not available



Note: *1. FXMQ07-48PBVJU only

Field setting	First Code No.	Setting Modes	FXMQ-M	FXHQ-M	FXAQ-P	FXLQ-M	FXNQ-M	FXTQ-TA	CXTQ-TA
10 (20)	0	Filter cleaning sign interval	●	●	●	●	●	—	—
	0	Filter sign setting	—	—	—	—	—	●	●
	1	Filter type	●	—	—	—	—	—	—
	1	Filter cleaning sign interval	—	—	—	—	—	●	●
	2	Thermistor selection	●	●	●	●	●	●	●
	3	Filter cleaning sign	●	●	●	●	●	●	●
	5	Information for intelligent Touch Manager/ intelligent Touch Controller	●	●	●	●	●	●	●
	6	Remote controller thermostat control during group control	●	●	●	●	●	●	●
11 (21)	7	Time for absence area detection	—	—	—	—	—	—	—
	1	Auxiliary electric heater ON temperature	—	—	—	●	●	●	●
	1	Auxiliary electric heater ON/OFF temperature	—	—	—	—	—	—	—
	2	Auxiliary electric heater OFF temperature	—	—	—	●	●	●	●
	3	Setting the airflow rate when heating	—	—	—	—	—	—	—
	3	Electric heater setting	—	—	—	—	—	●	—
	5	Electric heater capacity setting	—	—	—	—	—	●	—
	6	Setting the rate of human detection	—	—	—	—	—	—	—
	7	Automatic airflow adjustment	—	—	—	—	—	—	—
	8	Compensating the temperature around people	—	—	—	—	—	—	—
12 (22)	9	Compensating the floor temperature	—	—	—	—	—	—	—
	0	Optional output switching	●	●	●	●	●	●	●
	1	External ON/OFF input	●	●	●	●	●	●	●
	2	Thermostat switching	●	●	●	●	●	●	●
	3	Airflow setting when heating thermostat is OFF	●	●	●	●	●	●	●
	4	Setting of operation mode to AUTO	●	●	●	●	●	●	●
	5	Auto restart after power failure	●	●	●	●	●	●	●
13 (23)	6	Airflow setting when cooling thermostat is OFF	●	●	●	●	●	●	●
	0	Setting of airflow rate	—	●	●	—	—	—	—
	1	Airflow direction setting	—	—	●	—	—	—	—
	2	Swing pattern settings	—	—	—	—	—	—	—
	4	Setting of airflow direction adjustment range	—	—	●	—	—	—	—
	5	Setting of static pressure selection	—	—	—	—	—	—	—
	6	External static pressure settings	—	—	—	—	—	—	—
14 (24)	4	Optional kit setting (UV lamp + Humidifier + Economizer)	—	—	—	—	—	●	●
	5	Residential dry	—	—	—	—	—	●	●
	9	Mold proof operation setting	—	—	—	—	—	—	—
	11	Gas furnace test mode	—	—	—	—	—	—	●
15 (25)	0	Drain pump operation settings	—	—	—	—	—	—	—
	1	Humidification when heating thermostat is OFF	●	●	●	●	●	●	●
	2	Setting of direct duct connection	—	—	●	—	—	—	—
	3	Interlocked operation between humidifier and drain pump	●	●	●	●	●	—	—
	5	Individual setting of ventilation	●	●	●	●	●	●	●
1b	4	Display of error codes on the remote controller	●	●	●	●	●	●	●
	14	Setting "restricted / permitted" of airflow block	—	—	—	—	—	—	—
1c	0	Room temperature display	●	●	●	●	●	●	●
	1	Thermistor sensor for auto changeover and setback control by the remote controller	●	●	●	●	●	●	●
	3	Access permission level setting	●	●	●	●	●	●	●
1e	2	Setback availability	●	●	●	●	●	●	

● : Available

— : Not available

1.4.2 Detailed Explanation of Setting Modes

Filter Cleaning Sign Interval, Filter Type

Setting	10 (20)-1	01: Long life filter		02: Ultra long life filter	
	Filter contamination heavy/light 10 (20)-0	Light 01	Heavy 02	Light 01	Heavy 02
Model	FXFQ-T	2,500 hrs.	1,250 hrs.	10,000 hrs.	5,000 hrs.
	FXZQ-TA				
	FXUQ-P				
	FXEQ-P				
	FXDQ-M				
	FXSQ-TA				
	FXMQ-PB				
	FXMQ-M				
	FXHQ-M				
	FXLQ-M				
	FXNQ-M				
		FXAQ-P	200 hrs.	100 hrs.	200 hrs.

Setting	10 (20)-1	01: Short interval		02: Long interval	
	Filter contamination heavy/light 10 (20)-0	Light 01	Heavy 02	Light 01	Heavy 02
Model	FXTQ-TA	2,500 hrs.	1,250 hrs.	10,000 hrs.	5,000 hrs.
	CXTQ-TA				

Thermistor Selection

Select a thermistor to control room temperature.

- When the unit is not equipped with an infrared presence/floor sensor:

Mode No.	First Code No.	Second Code No.	Contents
10 (20)	2	01	Remote controller thermistor and suction air thermistor for indoor unit
		02	Suction air thermistor only
		03	Remote controller thermistor only

The factory setting for the Second Code No. is **01** and room temperature is controlled by the suction air thermistor and remote controller thermistor.

When the Second Code No. is set to **02**, room temperature is controlled by the suction air thermistor.



When the Second Code No. is set to **03**, room temperature is controlled by the remote controller thermistor.

■ FXTQ-TA, CXTQ-TA

Mode No.	First Code No.	Second Code No.	Contents
10 (20)	2	01	—
		02	Remote sensor thermistor only
		03	Remote controller thermistor only

When the Second Code No. is set to **02**, room temperature is controlled by the remote sensor thermistor.


When the Second Code No. is set to **03**, room temperature is controlled by the remote controller thermistor.



When the unit is equipped with an infrared presence/floor sensor:

Mode No.	First Code No.	Second Code No.					
10 (20)	2	01	02	02	02	02	03
11 (21)	8	01	01	02	03	04	01

The thermistor to be used	↓	↓	↓	↓	↓	↓
Remote controller thermistor	✓	—	—	—	—	✓
Suction air thermistor	✓	✓	✓	✓	✓	—
Infrared presence/floor sensor	—	—	✓	✓	✓	—



* Refer to **Compensating the Temperature around People** on page 147.

Note that the control is automatically switched to the one performed only by the suction air thermistor for indoor unit when the Second code No. is **01** during group control.
 To use the **remote controller thermostat control during group control**, select the Second code No. **02** in First code No. **6**.

Mode No.	First Code No.	Second Code No.	Contents
10 (20)	6	01	Remote controller thermostat control is not permitted during group control.
		02	Remote controller thermostat control is permitted during group control.

i Note: When the 10 (20)-6 setting is changed to **02**, several indoor units are controlled by one remote controller thermistor, so note that the room temperature might be uneven.

Filter Cleaning Sign

Whether or not to display "Filter Cleaning" after operation of certain duration can be selected.

Mode No.	First Code No.	Second Code No.	Contents
10 (20)	3	01	Displayed
		02	Not displayed

* Filter cleaning sign is not displayed when an Auto-clean Panel is connected.

Information for intelligent Touch Manager/intelligent Touch Controller

Mode No.	First Code No.	Second Code No.	Contents
10 (20)	5	01	Only indoor unit sensor value (or remote controller sensor value, if installed.)
		02	Sensor values according to 10 (20)-2 and 10 (20)-6.


* When field setting 10 (20)-6-**02** is set at the same time as 10 (20)-2-**01,02,03**, field setting 10 (20)-2 has priority.
 When field setting 10 (20)-6-**01** is set at the same time as 10 (20)-2-**01,02,03**, field setting 10 (20)-6 has priority for group connection, and 10 (20)-2 has priority for individual connection.

Time for Absence Area Detection

(For units with an infrared presence/floor sensor only)

By selecting the energy-saving operation mode in the absence, the target temperature is shifted to the energy-saving end by 1°C (1.8°F) (maximum 2°C (3.6°F)) after the state of absence continues for a certain period of time.
 Absent time defined for detection can be selected as follows:


Mode No.	First Code No.	Second Code No.	Contents
10 (20)	7	01	30 minutes
		02	60 minutes



* The values in parentheses represent the time when Second code No. is **02**.

- The set temperature displayed on the remote controller remains same even if the target temperature is shifted.
- As soon as people is detected while the temperature is shifted, this control will be cancelled (reset).

Auxiliary Electric Heater ON/OFF Temperature



Note: *1. S value varies automatically based on the room temperature trend.

■ FXFQ-T, FXMQ-PB

Mode No.	First Code No.	Symbol	Second Code No.					
			01	02	03	04	05	06
11 (21)	1	Ton	-4°C (-7.2°F)	-3.5°C (-6.3°F)	-3°C (-5.4°F)	-2.5°C (-4.5°F)	-2°C (-3.6°F)	-1.5°C (-2.7°F)
		Toff	-2°C (-3.6°F)	-1.5°C (-2.7°F)	-1°C (-1.8°F)	-0.5°C (-0.9°F)	0°C (0°F)	0.5°C (0.9°F)

■ FXUQ-P, FXEQ-P, FXLQ-M, FXNQ-M, FXTQ-TA

Mode No.	First Code No.	Symbol	Second Code No.					
			01	02	03	04	05	06
11 (21)	1	Ton	-4°C (-7.2°F)	-3.5°C (-6.3°F)	-3°C (-5.4°F)	-2.5°C (-4.5°F)	-2°C (-3.6°F)	-1.5°C (-2.7°F)
	2	Toff	-2°C (-3.6°F)	-1.5°C (-2.7°F)	-1°C (-1.8°F)	-0.5°C (-0.9°F)	0°C (0°F)	0.5°C (0.9°F)

There is a limitation of combination between Ton and Toff as below due to 2°C (3.6°F) hysteresis required for reliability.

Second Code No.			Ton					
			01	02	03	04	05	06
			-4°C (-7.2°F)	-3.5°C (-6.3°F)	-3°C (-5.4°F)	-2.5°C (-4.5°F)	-2°C (-3.6°F)	-1.5°C (-2.7°F)
Toff	06	0.5°C (0.9°F)	●	●	●	●	●	●
	05	0°C (0°F)	●	●	●	●	●	—
	04	-0.5°C (-0.9°F)	●	●	●	●	—	—
	03	-1°C (-1.8°F)	●	●	●	—	—	—
	02	-1.5°C (-2.7°F)	●	●	—	—	—	—
	01	-2°C (-3.6°F)	●	—	—	—	—	—

● : Available

— : Not available

■ CXTQ-TA

Mode No.	First Code No.	Symbol	Second Code No.						
			01	02	03	04	05	06	07 (*1)
11 (21)	1	Ton	-4°C (-7.2°F)	-3.5°C (-6.3°F)	-3°C (-5.4°F)	-2.5°C (-4.5°F)	-2°C (-3.6°F)	-1.5°C (-2.7°F)	-100°C (-148°F)
	2	Toff	-2°C (-3.6°F)	-1.5°C (-2.7°F)	-1°C (-1.8°F)	-0.5°C (-0.9°F)	0°C (0°F)	0.5°C (0.9°F)	-98°C (-144.4°F)

*1. The second code No. 07 is used for disabling the starting of gas furnace interlocking with room temperature.

Second Code No.		Ton						
		01	02	03	04	05	06	07
		-4°C (-7.2°F)	-3.5°C (-6.3°F)	-3°C (-5.4°F)	-2.5°C (-4.5°F)	-2°C (-3.6°F)	-1.5°C (-2.7°F)	-100°C (-148°F)
Toff	07	-98°C (-144.4°F)	—	—	—	—	—	●
	06	0.5°C (0.9°F)	●	●	●	●	●	●
	05	0°C (0°F)	●	●	●	●	—	●
	04	-0.5°C (-0.9°F)	●	●	●	●	—	●
	03	-1°C (-1.8°F)	●	●	●	—	—	●
	02	-1.5°C (-2.7°F)	●	●	—	—	—	●
	01	-2°C (-3.6°F)	●	—	—	—	—	●

● : Available
 — : Not available

Setting the Airflow Rate when Heating

The fan revolution is changed to maintain the sufficient distance for warm air to reach during the heating operation. The setting should be changed depending on the installation condition of the unit.

Mode No.	First Code No.	Second Code No.	Contents
11 (21)	3	01	Standard
		02	Slightly increased
		03	Increased

Note that this setting is effective only during the heating operation.

Electric Heater Setting (for FXTQ-TA model)

Mode No.	First Code No.	Second Code No.	Contents	
			Heater operation	Electric heater run for defrost/oil return operation
11 (21)	3	01	Electric heater with heat pump not allowed	Not allowed
		02	Electric heater with heat pump allowed	Not allowed
		07	Electric heater with heat pump not allowed	Allowed
		08	Electric heater with heat pump allowed	Allowed

Electric Heater Capacity Setting (for FXTQ-TA model)

Model	Mode No.	First Code No.	Second Code No.									
			01	02	03	04	05	06	07	08	09	10
			Heater (kW)									
			No heater kit	3	5	6	8	10	15	19	20	25
FXTQ09TAVJUA	11 (21)	5	●	●	●	—	—	—	—	—	—	—
FXTQ09TAVJUD			●	●	●	—	—	—	—	—	—	—
FXTQ12TAVJUA			●	●	●	●	—	—	—	—	—	—
FXTQ12TAVJUD			●	●	●	●	—	—	—	—	—	—
FXTQ18TAVJUA			●	●	●	●	●	●	—	—	—	—
FXTQ18TAVJUD			●	●	●	●	●	●	—	—	—	—
FXTQ24TAVJUA			●	●	●	●	●	●	—	—	—	—
FXTQ24TAVJUD			●	●	●	●	●	●	—	—	—	—
FXTQ30TAVJUA			●	●	●	●	●	●	—	—	—	—
FXTQ30TAVJUD			●	●	●	●	●	●	—	—	—	—
FXTQ36TAVJUA			●	●	●	●	●	●	—	—	—	—
FXTQ36TAVJUD			●	●	●	●	●	●	—	—	—	—
FXTQ42TAVJUA			●	—	●	●	●	●	●	●	—	—
FXTQ42TAVJUD			●	—	●	●	●	●	●	●	—	—
FXTQ48TAVJUA			●	—	●	●	●	●	●	●	—	—
FXTQ48TAVJUD			●	—	●	●	●	●	●	●	—	—
FXTQ54TAVJUA			●	—	●	●	●	●	●	●	—	●
FXTQ54TAVJUD			●	—	●	●	●	●	●	●	—	●
FXTQ60TAVJUA			●	—	●	●	●	●	●	●	—	●
FXTQ60TAVJUD			●	—	●	●	●	●	●	●	—	●

● : Available

— : Not available

Setting the Rate of Human Detection**(For units with the infrared presence/floor sensor only)**

Set the sensitivity of the infrared presence/floor sensor.

- The infrared presence/floor sensor can be disabled by selecting the Second code No. **04**.

(Note) When the infrared presence/floor sensor is disabled, the remote controller menu does not display some functions such as the automatic draft reduction, energy-saving operation in absence and halt in absence.

Mode No.	First Code No.	Second Code No.	Contents
11(21)	6	01	High sensitivity
		02	Low sensitivity
		03	Standard sensitivity
		04	Infrared presence/floor sensor disabled

Automatic Airflow Adjustment

The volume of blow-off air is automatically adjusted to the rated quantity.
Make settings before performing the test operation of the outdoor unit.

Setting procedure

- (1) Make sure that electric wiring and duct construction have been completed.
In particular, if the closing damper is installed on the way of the duct, make sure that it is open. In addition, make sure that a field-supplied air filter is installed within the air passageway on the suction port side.
- (2) If there are multiple blow-off and suction ports, adjust the throttle part so that the airflow volume ratio of each suction/blow-off port conforms to the designed airflow volume ratio. In that case, operate the unit with the operation mode "fan". When you want to change the airflow rate, adjust it by pressing the airflow rate control button to select High, Middle or Low.
- (3) Make settings to adjust the airflow rate automatically.
After setting the operation mode to "fan", enter the field setting mode while operation is stopped and then select the Mode No. 11 (21), set the First Code No. to **7** and the Second Code No. to **03**.
- (4) After setting, return to the basic screen (to the normal mode in the case of a wireless remote controller) and press the ON/OFF button. Fan operation for automatic airflow adjustment will start with the operation lamp turned ON. Do not adjust the throttle part of the suction and blow-off ports during automatic adjustment. After operation for approximately one to fifteen minutes, airflow adjustment automatically stops with the operation lamp turned OFF.
- (5) After operation stopped, make sure that the Second Code No. is set to **02** as in the following table by indoor unit with the Mode No. 11 (21). If operation does not stop automatically or the Second Code No. is not set to **02**, return to the step (3) above to make settings again.

Mode No.	First Code No.	Second Code No.	Contents
11 (21)	7	01	OFF
		02	Completion of airflow adjustment
		03	Start of airflow adjustment



Notes:

1. Make sure that the external static pressure is within the range of specifications before making settings. If it is outside the range, automatic adjustment fails, which may cause an insufficient airflow volume or leakage of water.
2. If the air passageway including duct or blow-off ports is changed after automatic adjustment, make sure to perform automatic airflow adjustment again.

Compensating the Temperature around People (For units with the infrared presence sensor only)

Change the ratio between the suction air temperature and floor temperature used to calculate the temperature around human.

The temperature around human is calculated using the values of the suction air thermistor and the infrared floor sensor. The factory setting is Normal (the average value of the suction air temperature and the floor temperature is applied). However, the rate at which the suction air thermistor and the infrared floor sensor affect the temperature around human can be changed with this setting.

- To reflect the effect of the temperature around the ceiling, select the "Priorities given on the suction air temperature" (the Second code No. **02**).
- To reflect the effect of the temperature around the floor, select the "Priorities given on the floor temperature" (the Second code No. **04**).
- The infrared presence/floor sensor can be disabled by selecting "Suction air temperature only" (the Second code No. **01**).

Mode No.	First Code No.	Second Code No.	Contents
11 (21)	8	01	Suction air temperature only
		02	Priorities given on the suction air temperature
		03	Standard
		04	Priorities given on the floor temperature

Compensating the Floor Temperature (For units with the infrared presence/floor sensor only)

Offset the detected value of the infrared floor sensor with a certain temperature. This setting should be used to have the actual floor temperature detected when, for example, the unit is installed close to a wall.

Mode No.	First Code No.	Second Code No.	Contents
11 (21)	9	01	-4°C (-7.2°F)
		02	-2°C (-3.6°F)
		03	0°C (0°F)
		04	+2°C (+3.6°F)

Actual procedure to use the setting

Although the standard setting is normally used with no problem, the setting should be changed in the following cases:

Environment	Operation Mode	Problem	Setting Value
<ul style="list-style-type: none"> · The unit is installed close to a wall or a window. · High thermal capacity of the floor (such as concrete, etc.) · There are many heat sources including PC. · There is a non-negligible heat source such as floor heating. 	Heating	Excessive heating	+2°C (+3.6°F)
		Insufficient heating	-2°C or -4°C (-3.6°F or -7.2°F)


Optional Output Switching

Using this setting, "operation output signal" and "abnormal output signal" can be provided. Output signal is output between terminals X1 and X2 of "adaptor for wiring", an optional accessory.

Mode No.	First Code No.	Second Code No.	Contents
12 (22)	0	01	Indoor unit thermostat ON/OFF signal is provided.
		02	—
		03	Output linked with "Start/Stop" of remote controller is provided.
		04	In case of "Error Display" appears on the remote controller, output is provided.
		05	—
		06	—
		07	Only for FXMQ-PB Economizer (field supply) ON/OFF signal is provided.

External ON/OFF Input

This input is used for "ON/OFF operation" and "Protection device input" from the outside. The input is performed from the T1-T2 terminal of the operation terminal block in the electrical component box.



Mode No.	First Code No.	Second Code No.	Contents
12 (22)	1	01	ON: Forced stop (prohibition of using the remote controller) OFF: Permission of using the remote controller
		02	OFF → ON: Permission of operation ON → OFF: Stop
		03	ON: Operation OFF: The system stops, then the applicable unit indicates A0 . The other indoor units indicate U9 .
		04	—
		05	Only for FXMQ-PB ON: Economizer (field supply) is connected. OFF: Not connected

Thermostat Switching

Differential value during thermostat ON/OFF control can be changed.

Mode No.	First Code No.	Second Code No.	Contents
12(22)	2	01	1°C (1.8°F)
		02	0.5°C (0.9°F)

Factory Setting

Model	Second Code No.	Contents
FXFQ-T, FXZQ-TA, FXUQ-P, FXEQ-P, FXHQ-M, FXTQ-TA	01	1.0°C (1.8°F)
FXDQ-M, FXMQ-PB, FXAQ-P, FXLQ-M, FXNQ-M, FXMQ-MF, CXTQ-TA	02	0.5°C (0.9°F)

Airflow Setting when Heating Thermostat is OFF

This setting is used to set airflow when heating thermostat is OFF.

If the airflow setting when thermostat is OFF is set to 03: OFF, the air in the indoor unit will be stagnant and suction air thermistor may not detect room temperature correctly, resulting in problems that thermostat will not be ON easily.

Use optional remote sensor in such conditions, or set the field setting 10 (20)-2 to **03** (only remote controller thermistor).

- * When thermostat OFF airflow volume up mode is used, careful consideration is required before deciding installation location.

Mode No.	First Code No.	Second Code No.	Contents
12 (22)	3	01	LL tap
		02	Set fan speed
		03	OFF

Setting of Operation Mode to AUTO

This setting makes it possible to change differential values for mode selection while in automatic operation mode, only when the wireless remote controller or any central remote controller is connected.

Mode No.	First Code No.	Second Code No.							
		01	02	03	04	05	06	07	08
12 (22)	4	0°C (0°F)	1°C (1.8°F)	2°C (3.6°F)	3°C (5.4°F)	4°C (7.2°F)	5°C (9.0°F)	6°C (10.8°F)	7°C (12.6°F)

The automatic operation mode setting is made by the use of the "Operation Mode Selector" button.

Auto Restart after Power Failure

Mode No.	First Code No.	Second Code No.	Contents
12 (22)	5	01	OFF
		02	ON

When the "Auto Restart after Power Failure" setting is turned OFF, all the units will remain OFF after power failure, or after the main power supply is restored. When this setting is turned ON (factory setting), the units that were operating before the power failure will automatically restart operation after power failure, or after the main power supply is restored.

Due to the aforementioned, when the "Auto restart after power failure" setting is ON, be careful for the following situations that may occur.



Caution

1. The air conditioner will start operation suddenly after power failure, or when the main power supply is restored. The user might be surprised and wonder why the air conditioner turned ON suddenly.
2. During maintenance, if the main power supply is turned OFF while the units are in operation, the units will automatically start operation (the fan will rotate) after the power supply is restored due to completion of the maintenance work.

Airflow Setting when Cooling Thermostat is OFF

This is used to set airflow to "LL airflow" when cooling thermostat is OFF.

If the airflow setting when thermostat is OFF is set to 03: OFF, the air in the indoor unit will be stagnant and suction air thermistor may not detect room temperature correctly, resulting in problems that thermostat will not be ON easily.

Use optional remote sensor in such conditions, or set the field setting 10 (20)-2 to 03 (only remote controller thermistor).

Mode No.	First Code No.	Second Code No.	Contents
12 (22)	6	01	LL tap
		02	Set fan speed
		03	OFF

Setting of Airflow Rate

Make the following setting according to the ceiling height. The second code No. is set to **01** at the factory.

■ FXFQ07-24T, FXUQ18/24P

Mode No.	First Code No.	Second Code No.	Contents	Ceiling height		
				4-way Outlets	3-way Outlets	2-way Outlets
13 (23)	0	01	Standard	Lower than 2.7 m (8-3/4 ft)	Lower than 3.0 m (10 ft)	Lower than 3.5 m (11-1/2 ft)
		02	High Ceiling 1	Lower than 3.0 m (10 ft)	Lower than 3.3 m (10-3/4 ft)	Lower than 3.8 m (12-1/2 ft)
		03	Higher Ceiling 2	Lower than 3.5 m (11-1/2 ft)	Lower than 3.5 m (11-1/2 ft)	—

■ FXFQ30-48T, FXUQ30/36P

Mode No.	First Code No.	Second Code No.	Contents	Ceiling height		
				4-way Outlets	3-way Outlets	2-way Outlets
13 (23)	0	01	Standard	Lower than 3.2 m (10-1/2 ft)	Lower than 3.6 m (12 ft)	Lower than 4.2 m (13-3/4 ft)
		02	High Ceiling 1	Lower than 3.6 m (12 ft)	Lower than 4.0 m (13-1/8 ft)	Lower than 4.2 m (13-3/4 ft)
		03	Higher Ceiling 2	Lower than 4.2 m (13-3/4 ft)	Lower than 4.2 m (13-3/4 ft)	—

■ FXZQ-TA, FXEQ-P

Mode No.	First Code No.	Second Code No.	Contents	Ceiling height
13 (23)	0	01	Standard	Lower than 2.7 m (8-3/4 ft)
		02	High Ceiling 1	Lower than 3.0 m (10 ft)
		03	Higher Ceiling 2	Lower than 3.5 m (11-1/2 ft)

■ FXHQ-M, FXAQ-P

Mode No.	First Code No.	Second Code No.	Contents
13 (23)	0	01	Standard
		02	Slight increase
		03	Normal increase

Airflow Direction Setting

Set the airflow direction of indoor units as given in the table below. (Set when sealing material kit of air discharge outlet has been installed.) The second code No. is factory set to **01**.

Mode No.	First Code No.	Second Code No.	Contents
13 (23)	1	01	F: 4-direction airflow
		02	T: 3-direction airflow
		03	W: 2-direction airflow

Swing Pattern Settings

(For units with the infrared presence/floor sensor only)

Set the flap operation in swing mode.


With the factory swing, flaps facing each other are synchronized to operate, and flaps placed side by side are set to swing in an opposite direction to agitate airflow to reduce temperature irregularity.

Conventional swing operation (all direction synchronized swing) can be set onsite.

Mode No.	First Code No.	Second Code No.	Contents
13 (23)	2	01	All direction synchronized swing
		02	—
		03	Facing swing

Setting of Airflow Direction Adjustment Range

Make the following airflow direction setting according to the respective purpose.



Mode No.	First Code No.	Second Code No.	Contents
13 (23)	4	01	Upward (Draft prevention)
		02	Standard
		03	Downward (Ceiling soiling prevention)

*Some indoor unit models are not equipped with draft prevention (upward) function.

Setting of the Static Pressure Selection (for FXDQ-M model)

Model No.	First Code No.	Second Code No.	Contents
13 (23)	5	01	Standard (FXDQ07-12M: 10 Pa (0.04 inWG), FXDQ18/24M: 30 Pa (0.12 inWG))
		02	High static pressure (FXDQ07-12M: 15 Pa (0.06 inWG), FXDQ18/24M: 45 Pa (0.18 inWG))

External Static Pressure Settings

■ FXMQ-PB models

Mode No.	First Code No.	Second Code No.	Contents
13 (23)	6	01	30 Pa (0.12 inWG) (*1) (*3)
		02	50 Pa (0.20 inWG)
		03	60 Pa (0.24 inWG)
		04	70 Pa (0.28 inWG)
		05	80 Pa (0.32 inWG)
		06	90 Pa (0.36 inWG)
		07	100 Pa (0.40 inWG)
		08	110 Pa (0.44 inWG) (*2)
		09	120 Pa (0.48 inWG) (*2)
		10	130 Pa (0.52 inWG) (*2)
		11	140 Pa (0.56 inWG) (*2)
		12	150 Pa (0.60 inWG) (*2) (*3)
		13	160 Pa (0.64 inWG) (*2) (*3)
		14	180 Pa (0.72 inWG) (*2) (*3)
		15	200 Pa (0.80 inWG) (*2) (*3)

The Second Code No. is set to **02** for FXMQ07/09/12PB, and **07** for FXMQ15/18/24/30/36/48/54PB at factory setting.

- *1. FXMQ15/18/24/30/36/48PB cannot be set to 30 Pa (0.12 inWG).
- *2. FXMQ07/09/12PB cannot be set to 110-200 Pa (0.44-0.80 inWG).
- *3. FXMQ54PB cannot be set to 30 Pa (0.12 inWG) or 150-200 Pa (0.60-0.80 inWG).

■ FXSQ-TA models

Mode No.	First Code No.	Second Code No.	Contents
13 (23)	6	03	30 Pa (0.12 inWG) (*1) (*2)
		04	40 Pa (0.16 inWG) (*1) (*2)
		05	50 Pa (0.20 inWG)
		06	60 Pa (0.24 inWG)
		07	70 Pa (0.28 inWG)
		08	80 Pa (0.32 inWG)
		09	90 Pa (0.36 inWG)
		10	100 Pa (0.40 inWG)
		11	110 Pa (0.44 inWG)
		12	120 Pa (0.48 inWG)
		13	130 Pa (0.52 inWG)
		14	140 Pa (0.56 inWG)
		15	150 Pa (0.60 inWG) (*2)

The Second Code No. is set to **05** (an external static pressure of 50 Pa (0.20 inWG)) at factory setting.

- *1. FXSQ18-48TA cannot be set to 30-40 Pa (0.12-0.16 inWG).
- *2. FXSQ54TA cannot be set to 30-40 Pa (0.12-0.16 inWG) or 150 Pa (0.60 inWG).

Optional Kit Setting (UV lamp + Humidifier + Economizer) (for FXTQ-TA and CXTQ-TA models)

Mode No.	First Code No.	Second Code No.	Contents	
			UV lamp + humidifier fan speed	Economizer setting for Mech standby duration (minutes)
14 (24)	4	01	Refer to controller	10
		02	High	10
		03	Refer to controller	20
		04	High	20
		05	Refer to controller	30
		06	High	30
		07	Refer to controller	40
		08	High	40
		09	Refer to controller	50
		10	High	50
		11	Refer to controller	60
		12	High	60
		13	Refer to controller	Free cooling only
		14	High	Free cooling only

Residential Dry (for FXTQ-TA and CXTQ-TA models)

Mode No.	First Code No.	Second Code No.	Contents
14 (24)	5	01	Set temperature: room temperature
		02	Set temperature: same as cooling set temperature

Mold Proof Operation Setting (for FXEQ-P models)

Mode No.	First Code No.	Second Code No.	Contents
14 (24)	9	01	—
		02	Standard
		03	For high humidity areas (*)

* Areas with average humidity over 80%.

Gas Furnace Test Mode (for CXTQ-TA models)

This setting is used for gas furnace test run.

For details, refer to **Gas Furnace Test Operation** on page 193.

Mode No.	First Code No.	Second Code No.	Contents
14 (24)	11	01	OFF
		02	Low heat
		03	High heat

Drain Pump Operation Settings (for FXMQ-PB model)

The drain pump operation can be disabled for natural drainage by changing the following field setting.

Mode No.	First Code No.	Second Code No.	Contents
15 (25)	0	01	—
		02	ON
		03	OFF

Humidification when Heating Thermostat is OFF

Setting to "Humidification Setting" turns ON the humidifier if suction air temperature is 20°C (68°F) or above and turns OFF the humidifier if suction air temperature is 18°C (64.4°F) or below when the heating thermostat is OFF.

Mode No.	First Code No.	Second Code No.	Contents
15 (25)	1	01	Not equipped
		02	Setting of humidifier

Setting of Direct Duct Connection

This is used when "fresh air intake kit equipped with fan" is connected. If the second code is set to 02: Equipped, energy recovery ventilator fan conducts the fan residual operation by linking to indoor unit. The indoor fan carries out residual operation for one minute after the thermostat is stopped. (For the purpose of preventing dust on the air filter from falling off.)

Mode No.	First Code No.	Second Code No.	Contents
15 (25)	2	01	Not equipped
		02	Equipped

Interlocked Operation between Humidifier and Drain Pump

This is used to interlock the humidifier with the drain pump. When water is drained out of the unit, this setting is unnecessary.

Mode No.	First Code No.	Second Code No.	Contents
15 (25)	3	01	Not interlocked
		02	Interlocked

Individual Setting of Ventilation

This is set to perform individual operation of Energy recovery ventilator using the remote controller/central unit when Energy recovery ventilator is built in.

(Switch only when Energy recovery ventilator is built in.)

Mode No.	First Code No.	Second Code No.	Contents
15 (25)	5	01	— (Normal)
		02	Individual operation of ventilation

Display of Error Codes on the Remote Controller (For BRC1E73 only)

Error code (four digits) is displayed for limited products.

Select two-digit display if four-digit display is not preferred.

Mode No.	First Code No.	Second Code No.	Contents
1b	4	01	—
		02	Two-digit display
		03	—
		04	Four-digit display

Setting "Restricted/Permitted" of Airflow Block (For units with the infrared presence/floor sensor only)

Due to possibility of dew condensation, the airflow block function cannot be enabled when closure material kit, fresh air intake kit, natural/separately installed evaporation humidifier, or branch air duct is equipped.

This setting will prevent the airflow block is advertently set to ON.

Ensure that this setting is "Disable airflow block" when using together with options listed above.

Mode No.	First Code No.	Second Code No.	Contents
1b	14	01	Airflow block permitted
		02	—
		03	—
		04	—
		05	Airflow block restricted

Room Temperature Display (For BRC1E73 only)

A "Detailed display screen" can be selected as the display screen. This setting is used if you do not want to display "Room temperature display" on the "Detailed display screen."

Mode No.	First Code No.	Second Code No.	Contents
1c	0	01	Not displayed
		02	Displayed

Thermistor Sensor for Auto Changeover and Setback Control by the Remote Controller (For BRC1E73 only)

Select a thermistor to utilize for the cool/heat mode automatic changeover and setback functions.

The sensed temperature will be displayed on the remote controller as the room temperature.

Mode No.	First Code No.	Second Code No.	Contents
1c	1	01	Utilize the return air thermistor
		02	Utilize the remote controller thermistor

Access Permission Level Setting (For BRC1E73 only)

There are 2 levels as follows:

- Level 2: The following buttons are selectable to be disable or enable.
- Level 3: No buttons are selectable and only **On/Off** button is available.

Button	Level 2	Level 3
▲▼◀▶	Selectable (Enable)	Unselectable (Disable)
On/Off	Selectable (Enable)	Unselectable (Enable)
Mode	Selectable (Enable)	Unselectable (Disable)
Fan Speed	Selectable (Enable)	Unselectable (Disable)
Menu/OK	Unselectable (Disable)	Unselectable (Disable)
Cancel	Unselectable (Disable)	Unselectable (Disable)

() shows the factory setting.

Mode No.	First Code No.	Second Code No.	Contents
1c	3	01	Level 2
		02	Level 3

Setback Availability (For BRC1E73 only)

Select the operation mode in which the setback function is available.

Mode No.	First Code No.	Second Code No.	Contents
1e	2	01	N/A
		02	Heat only
		03	Cool only
		04	Cool/heat

1.5 Gas Furnace Set Up

Set-up for gas furnace is possible only by using the DIP switches located on CXTQ-TA.

Gas furnace's DIP switch is not valid. Refer to the gas furnace's installation manual for details of each setting menu.



Note:

If the Heat OFF Delay time was changed to a longer time, warm-up process time of the heat pump might be longer.

■ : Factory setting

Purpose	Function		Position			
	Modulating	2-Stage	1	2	3	4
Dip switch			DS1			
Heat Airflow Trim	-15%	-10%	OFF	OFF	OFF	OFF
	-12%	-8%	ON	OFF	OFF	OFF
	-9%	-6%	OFF	ON	OFF	OFF
	-6%	-4%	ON	ON	OFF	OFF
	-3%	-2%	OFF	OFF	ON	OFF
	0%	0%	ON	OFF	ON	OFF
	+3%	+2%	OFF	ON	ON	OFF
	+6%	+4%	ON	ON	ON	OFF
	+9%	+6%	OFF	OFF	OFF	ON
	+12%	+8%	ON	OFF	OFF	ON
	+15%	+10%	OFF	ON	OFF	ON
		0%	ON	ON	OFF	ON
		0%	OFF	OFF	ON	ON
		0%	ON	OFF	ON	ON
		0%	OFF	ON	ON	ON
	0%	ON	ON	ON	ON	
Dip switch			DS2			
Heat ON Delay	5 sec.		OFF	OFF	OFF	—
	10 sec.		ON	OFF	OFF	—
	15 sec.		OFF	ON	OFF	—
	20 sec.		ON	ON	OFF	—
	25 sec.		OFF	OFF	ON	—
	30 sec.		ON	OFF	ON	—
	30 sec.		OFF	ON	ON	—
	30 sec.		ON	ON	ON	—
Dip switch			DS3			DS2
Heat OFF Delay	30 sec.		OFF	OFF	—	OFF
	60 sec.		OFF	OFF	—	ON
	90 sec.		ON	OFF	—	OFF
	120 sec.		ON	OFF	—	ON
	150 sec.		OFF	ON	—	OFF
	180 sec.		OFF	ON	—	ON
	150 sec.		ON	ON	—	OFF
	150 sec.		ON	ON	—	ON
Dip switch			DS3			
Heating Speed Tap	A		—	—	OFF	OFF
	B		—	—	ON	OFF
	C		—	—	OFF	ON
	D		—	—	ON	ON

1.6 List of Field Settings for Outdoor-Air Processing Unit

■ : Factory setting

Mode No.	First Code No.	Setting Contents	Second Code No.															
			01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	
10 (20)	0	Filter contamination	2500 hr	1250 hr	—	—	—	—	—	—	—	—	—	—	—	—	—	
	3	Display time to clean air filter calculation	Display	No display	—	—	—	—	—	—	—	—	—	—	—	—	—	
12 (22)	1	External ON/OFF input	Forced OFF	ON/OFF control	—	—	—	—	—	—	—	—	—	—	—	—	—	
	5	Power failure automatic reset	Not equipped	Equipped	—	—	—	—	—	—	—	—	—	—	—	—	—	
14 (24)	3	Discharge pipe temperature (cooling)	°C	13	14	15	16	17	18	19	20	21	22	23	24	25★	25★	25★
			°F	55.4	57.2	59	60.8	62.6	64.4	66.2	68	69.8	71.6	73.4	75.2	77★	77★	77★
	4	Discharge pipe temperature (heating)	°C	18	19	20	21	22	23	24	25	26	27	28	29	30★	30★	30★
			°F	64.4	66.2	68	69.8	71.6	73.4	75.2	77	78.8	80.6	82.4	84.2	86★	86★	86★

1.7 Setting of Operation Control Mode

The operation control mode is compatible with a variety of controls and operations by limiting the functions of the operation remote controller. Furthermore, operations such as remote controller ON/OFF can be limited in accordance with the combination conditions. (Refer to information in the next page.)

Central remote controller is normally available for operations. (Except when centralized monitor is connected)

Contents of Control Modes


20 modes consisting of combinations of the following 5 operation modes with temperature and operation mode setting by remote controller can be set and displayed by operation modes 0 through 19.

- ◆ ON/OFF control impossible by remote controller
Used when you want to turn ON/OFF by central remote controller only.
(Cannot be turned ON/OFF by remote controller.)
- ◆ OFF control only possible by remote controller
Used when you want to turn ON by central remote controller only, and OFF by remote controller only.
- ◆ Centralized
Used when you want to turn ON by central remote controller only, and turn ON/OFF freely by remote controller during set time.
- ◆ Individual
Used when you want to turn ON/OFF by both central remote controller and remote controller.
- ◆ Timer operation possible by remote controller
Used when you want to turn ON/OFF by remote controller during set time and you do not want to start operation by central remote controller when time of system start is programmed.

How to Select Operation Mode

Whether operation by remote controller will be possible or not for turning ON/OFF, controlling temperature or setting operation mode is selected and decided by the operation mode given on the right edge of the table below.

Example




■ : Factory setting

Control mode	Control by remote controller					Control mode
	Operation		OFF	Temperature control	Operation mode setting	
	Unified operation, individual operation by central remote controller, or operation controlled by timer	Unified OFF, individual stop by central remote controller, or timer stop				
ON/OFF control impossible by remote controller	Rejection (Example)	Rejection (Example)	Rejection (Example)	Rejection	Acceptance	0
OFF control only possible by remote controller				Acceptance	Acceptance	Acceptance (Example)
	Centralized	Acceptance	Acceptance			Rejection
Individual				Acceptance	Acceptance	
	Timer operation possible by remote controller	Acceptance (During timer at ON position only)	Rejection (During timer at OFF position only)			Acceptance

Do not select "timer operation possible by remote controller" if not using a remote controller. Operation by timer is impossible in this case.

Local remote controllers cannot set temperature or operation mode when the system is under centralized control and **CENTRAL CONTROL** is displayed on the screen.

BRC1E73



2. Field Settings for Outdoor Unit

This section shows a list of field setting items possible to set at time of initial startup. For details of DIP switch setting, setting mode ("mode 2") and monitoring mode ("mode 1"), refer to information on one after the following page onwards.

2.1 Function Setting

Following settings may be required to set to comply to specific application requirements.

No	Setting item	Contents and objective of setting	Overview of setting procedure
1	Setting of COOL/HEAT selection	<ul style="list-style-type: none"> ■ To select cooling or heating mode by one of the following methods: <ol style="list-style-type: none"> 1. From 1 indoor unit remote controller (default). 2. From the optional COOL/HEAT switch. Optional board "BRP2A81*1" required in outdoor unit. 3. Multiple outdoor systems from 1 indoor unit remote controller. 4. Multiple outdoor systems from the optional COOL/HEAT switch. Optional board "BRP2A81" required in 1 outdoor unit per zone. 	2.1: Optional COOL/HEAT switch "KRC19-26B". 2.2: Set DIP switch DS1-1 on the outdoor board to "OUT" (upper). 2.3: Install option "BRP2A81*1" in outdoor unit. 3.1: Set the system to "MASTER" or "SLAVE" using mode 2-0. 3.2: Set COOL/HEAT zone address mode 2-1. 4: Combine 2 and 3.
2	Setting of low noise operation	A. To reduce operation noise level through reduction of the upper limit of the fan using external input (use outdoor fan step 8 for normal operation). <ol style="list-style-type: none"> 1. Level 1: upper than fan step 6. 2. Level 2: upper fan step 5 + upper limit compressor capacity step mid level. 3. Level 3: upper fan step 5 + upper limit compressor capacity step low level. 	<ul style="list-style-type: none"> ■ Use the optional board "DTA104A61*2". ■ Set "mode 2" No. 12-1. ■ Choose level by "mode 2" No. 25. ■ If required, set the "Capacity priority setting" to "ON", by "mode 2" No. 29-1.
		B. To perform automatic night-time low noise operation. Start time: selectable from 8:00PM to 12:00AM (step by 2 hours). End time: selectable from 6:00AM to 8:00AM (step by 1 hour). (Note that the set time is estimated according to outdoor air temperature.)	<ul style="list-style-type: none"> ■ Select required level by mode 2-22. ■ Select start time with mode 2-26. ■ Select end time with mode 2-27. ■ Select capacity priority setting if required by mode 2-29-1.

For detailed description about each setting, refer to "Description Field Settings (mode 2: m2) on Outdoor Unit Main PCB" on page 177.



Notes:

- *1. ABC I/P PCB kit for **VRV**.
- *2. External control adaptor for outdoor unit.

No	Setting item	Contents and objective of setting	Overview of setting procedure
3	Setting of demand operation	<ul style="list-style-type: none"> ■ To limit power consumption: upper limit set on the compressor operating frequency. ■ Demand 1: % current limit 1. ■ Demand 2: % current limit 2. ■ Demand 3: forced thermostat OFF (only indoor fan operation is possible). 	<ul style="list-style-type: none"> ■ Use the optional board "DTA104A61". ■ Wire external signal(s) to the optional adaptor "DTA104A61".
			<ul style="list-style-type: none"> ■ Activate input optional board "DTA104A61" "mode 2" No. 12-1. ■ Select level of demand 1, by mode 2-30. ■ Select level of demand 2, by mode 2-31.
			<ul style="list-style-type: none"> ■ If fixed demand control is required (without adaptor "DTA104A61"), set level by mode 2-32.
4	Setting of AIRNET address	<ul style="list-style-type: none"> ■ Make "AIRNET" address when it is connected to AIRNET monitoring, or to view detail in the map on Service Checker type III. 	<ul style="list-style-type: none"> ■ Set AIRNET address with mode 2-13.
5	High level difference outdoor to indoor	<ul style="list-style-type: none"> ■ Required setting when level difference between outdoor and indoor units of same refrigerant exceeds standard level. 	<ul style="list-style-type: none"> ■ Set "mode 2" No. 35 to "1" if outdoor is > 40 m (131 ft) below indoor unit. ■ Set "mode 2" No. 49 to "1" if outdoor is > 50 m (164 ft) above indoor unit.
6	Setting of high static pressure	<ul style="list-style-type: none"> ■ Set "high static pressure" in order to operate the system with duct to the outdoor unit (used at concealed installation on floors or balconies). 	<ul style="list-style-type: none"> ■ Set "mode 2" No. 18 to "ON".
7	Evaporating temperature setting (cooling performance)	<ul style="list-style-type: none"> ■ Setting to choose the reaction time of outdoor control on change of outdoor and cooling indoor load. 	<ul style="list-style-type: none"> ■ Set "mode 2" No. 8 to choose cooling capacity control logic between fixed, automatic or high sensible. ■ Set "mode 2" No. 81 to choose Te adjustment at start up between Powerful, Quick, Mild or Eco.
8	Condensing temperature setting (heating performance)	<ul style="list-style-type: none"> ■ Setting to choose the reaction time of outdoor control on change of outdoor and heating indoor load. 	<ul style="list-style-type: none"> ■ Set "mode 2" No. 9 to choose heating capacity control logic between fixed, automatic or high sensible. ■ Set "mode 2" No. 82 to choose Tc adjustment at start up between Powerful, Quick, Mild or Eco.

For detailed description about each setting, refer to "Description Field Settings (mode 2: m2) on Outdoor Unit Main PCB" on page 177.

2.2 Settings by DIP Switches

2.2.1 COOL/HEAT Selection


For factory mounted board only use DIP switch DS1-1 if required.

DIP switch		Setting item	Description
No.	Setting		
DS1-1	ON	COOL/HEAT select	Used to choose source to select Cooling/Heating/fan only. Source can be or indoor remote controller, or optional cool/heat switch wired to option "BRP2A81".
	OFF (Factory setting)		
DS1-2 ~DS1-4	ON	not used	Do not change the factory settings.
	OFF (Factory setting)		

2.2.2 DIP Switch Setting Mounting a Spare PCB






Caution:

- After replacement with spare PCB, be sure to make settings shown in the table on the following page. The procedure for making settings of spare PCB is different from that used for factory settings described above. Be sure to refer to the table shown on the following page in order to make settings of spare PCB after replacement.
- Enforce a re-initialization of communication: hold press the **RETURN (BS3)** button for minimum 5 seconds.
- After initialization, a test operation is required from outdoor unit (hold the **SET (BS2)** button until indication **t01** appears).



- (1) Microcomputer normal monitor
This monitor blinks while in normal operation, and turns ON or OFF when an error occurs.
- (2) 7 segment display
 - Used to check the transmission.
 - Used to display the transmission state between indoor and outdoor units.
 - Used to display the error description.
 - Used to display the contents of field setting.
- (3) BS button
Used to change mode.
- (4) DIP switch
Used to make field settings.


The figure below shows the required position of the DIP switches on spare PCB for RXYQ-XA. Change DIP switches at time of power disconnected.

Application model	The setting method (■ represents the position of switches)	
RXYQ72XA		Set DS1-2, DS1-4 and DS2-2 to ON.
RXYQ96XA		Set DS1-2, DS1-4, DS2-1 and DS2-2 to ON.
RXYQ120XA		Set DS1-2, DS1-4 and DS2-3 to ON.
RXYQ144XA		Set DS1-2, DS1-4, DS2-2 and DS2-3 to ON.
RXYQ168XA		Set DS1-2, DS1-4, DS2-1, DS2-2 and DS2-3 to ON.

2.3 Accessing the BS Buttons on the PCB

It is not required to open the complete control box to access the BS buttons on the PCB and read out the seven-segment display (s).

To access you can remove the service window cover (see figure). Now you can open the inspection door of the control box cover (see figure). You can see the 3 BS buttons and 3 seven-segment displays and DIP switches.




1 Service window cover
2 Inspection door
3 Main PCB with 3 seven-segment display
and 3 BS buttons

Operate the switches and BS buttons with an insulated stick (such as a closed ballpoint pen) to avoid touching of live parts.



Location of the segment displays, buttons and DIP switches:




MODE (BS1) for changing setting mode
SET (BS2), RETURN (BS3) for changing field setting
DS1, DS2 DIP switches
1 3 seven-segment displays
2 BS buttons

2.4 Settings by BS Buttons

The following settings can be made using the BS buttons on the PCB.

In case of a multi outdoor system, make these settings with the master outdoor unit (settings made with a slave unit are disabled).


BS buttons




7 segment display (SEG1-3)

SEG1 SEG2 SEG3


Normal mode




Setting mode




Monitor mode



- Normal mode:
 - Blank: If no abnormality is detected and initialization of communication was completed.
 - Flashing combination of letter and number (4 digits): Error code detected by outdoor control or trouble by communication.
 - Setting mode: Used to make changes to operating status, performance settings or address setting.
 - Monitor mode: Used to verify contents of settings, quantity of units, current value of some parameters during operation of outdoor unit.
- **Mode changing procedure can be selected using the MODE (BS1) button as shown below:**




■ Selection between normal mode, monitor mode (Mode 1) and setting mode (Mode 2).




2.5 Normal Mode

1. Indoor/outdoor transmission status: Used to check for the initial status of indoor/outdoor transmission.




2. Descriptions: Used to display an error content.



2.6 Monitor Mode (Mode 1)

In the monitor mode, information can be retrieved about settings related to performance, addresses, number of units and actual operation data.

2.6.1 Retrieve Data by Using BS Button Outdoor Unit Main PCB



2.6.2 Overview of Monitor Mode (Mode 1)

No. *1	Monitoring item				Data display			
	Item	7 segment display			Contents	7 segment display		
		SEG 1	SEG 2	SEG 3		SEG 1	SEG 2	SEG 3
0	Master/slave outdoor unit	1	0	0	Undefined Master unit Slave 1 unit Slave 2 unit			- 0 1 2
1	Low noise operation state	1	0	1	In normal operation In low noise operation			0 1
2	Demand operation state	1	0	2	In normal operation In demand operation			0 1
3	Automatic backup operation state	1	0	3	OFF ON			0 1
4	Defrost selection setting	1	0	4	Later start defrost Normal Earlier start defrost			0 1 2
5	Te setting	1	0	5	Automatic 3°C (37.4°F) 6°C (42.8°F) 7°C (44.6°F) 8°C (46.4°F) 9°C (48.2°F) 10°C (50.0°F) 11°C (51.8°F)			0 1 2 3 4 5 6 7
6	Tc setting	1	0	6	Automatic 41°C (105.8°F) 42°C (107.6°F) 43°C (109.4°F) 44°C (111.2°F) 45°C (113.0°F) 46°C (114.8°F) 49°C (120.2°F)			0 1 2 3 4 5 6 7
7	COOL/HEAT unified address	1	0	7	Possible 0-31		- 3	0 1
8	Low noise/demand address	1	0	8	Possible 0-31		- 3	0 1
9	AIRNET address	1	0	9	Possible 0-63		- 6	0 3
10	Number of indoor unit connected *2	1	1	0	Possible 0-63		- 6	0 3
13	Number of outdoor units *3	1	1	3	Possible 0-63		- 6	0 3
15	Number of units in zone	1	1	5	Possible 0-63		- 6	0 3
16	Number of all indoor units of several systems if "F1F2 OUT/D" is wired between systems *4	1	1	6	Possible 0-128	- 1	- 2	0 8
17	Description of error (latest)	1	1	7	Refer to information in Check for Descriptions of Errors/Retries on page 171.			
18	Description of error (1 cycle before)	1	1	8				
19	Description of error (2 cycles before)	1	1	9				

*1: Numbers in the "No." column represent the number of times to press the BS button.

*2: Number of indoor units connected: represents the number of indoor units connected to a single outdoor system.

*3: Number of outdoor units: represents the number of outdoor units connected to a single DIII-NET that is a communication line.

*4: Number of terminal units: represents the number of indoor units connected to a single DIII-NET that is a communication line.

No. *1	Monitoring item				Data display			
	Item	7 segment display			Contents	7 segment display		
		SEG 1	SEG 2	SEG 3		SEG 1	SEG 2	SEG 3
23	Description of retry (latest)	1	2	3	Refer to information in Check for Descriptions of Errors/Retries on page 171.			
24	Description of retry (1 cycle before)	1	2	4				
25	Description of retry (2 cycles before)	1	2	5				
28	Number of outdoor units connected to a multi system	1	2	8	Possible 0-63		- 6	0 3
32	Outdoor board status judgment	1	3	2	0: standard judgment 1: normal 2: abnormal			0 1 2
33	Number of abnormal status judgment outdoor unit PCB	1	3	3	Possible 0-15		- 1	0 5
38	Number of connected RA indoor unit (through BP unit)	1	3	8	Possible 0-63		- 6	0 3
40	Cooling comfort setting (see mode 2 No. 8)	1	4	0	Possible 0-7			0 7
41	Heating comfort setting (see mode 2 No. 9)	1	4	1	Possible 0-6			0 6
42	High pressure (psi)	1	4	2	Possible -99-999	- 9	9 9	9 9
43	Low pressure (psi)	1	4	3	Possible -99-999	- 9	9 9	9 9
44	Compressor total frequency (Hz)	1	4	4	0-999	0 9	0 9	0 9
45	Opening pulses EV main "Y1E" (pulses / 10)	1	4	5	0-999	0 9	0 9	0 9
46	Discharge pipe temperature R21T (°F)	1	4	6	-99-999	- 9	9 9	9 9
47	Discharge pipe temperature R22T (°F)	1	4	7	-99-999	- 9	9 9	9 9
48	Compressor body temperature R8T (°F)	1	4	8	-99-999	- 9	9 9	9 9
49	Air temperature R1T (°F)	1	4	9	-99-999	- 9	9 9	9 9
50	Accumulator inlet temperature R3T (°F)	1	5	0	-99-999	- 9	9 9	9 9
51	Gas outlet sub-cool heat-exchanger R6T (°F)	1	5	1	-99-999	- 9	9 9	9 9
52	Coil temperature R7T (°F)	1	5	2	-99-999	- 9	9 9	9 9
53	Compressor operation hours / 100	1	5	3	0-999	0 9	0 9	0 9


*1: Numbers in the "No." column represent the number of times to press the BS button.

2.6.3 Check for Descriptions of Errors/Retries

Follow the procedure described below. This procedure is different than indicated in previous “Monitor mode”.

The error codes for forced stop outdoor or retry are item:

- 17, 18, 19: description of error (outdoor system stopped operation).
- 23, 24, 25: description of retry.




- The tables on next pages show a full list of possible error codes displayed on the 3 digit 7 segment display of the outdoor unit. The error code contains an upper and lower digit. To scroll between upper and lower error digit, use the **SET (BS2)** button when the select number in the monitor mode is chosen:
 - No. 17-19 for error: system operated stopped.
 - No. 23-25 for retry: system attempts to keep operation.
- The errors cover problems detected in the outdoor unit or the communication.
- Errors detected on the indoor unit are not shown on the outdoor display. For inspecting error code on indoor unit, please consult:
 - Display of the remote controller connected to the indoor units.
 - If there are no remote controllers, there should be a central control device set up. Prior to start up, make the necessary group number settings on each indoor unit.



Reference: Refer to page 205 for **Error Codes and Descriptions**.

2.7 Setting Mode (Mode 2)



* If you become unsure of how to proceed, press the **MODE (BS1)** button and return to Normal mode.

Legend Segment : OFF : ON : BLINKS : hold 5 seconds

2.7.1 Overview of Setting Mode (Mode 2)

This overview shows the available settings by using the press buttons on the outdoor unit PCB.

No. *1	Item	Description	7 segment display			Description	7 segment display		
			Range				Range		
			SEG 1	SEG 2	SEG 3		SEG 1	SEG 2	SEG 3
0	COOL/HEAT selection	Several systems as 1 zone change over COOL/HEAT: ■ INDIVIDUAL: VRV indoor unit or A-B-C input set mode. ■ MASTER: System is the COOL/HEAT master unit. ■ SLAVE: System is not a COOL/HEAT master.	2.	0	0	Individual Unified master Unified slave			0 1 2
1	COOL/HEAT unified address	Used to make address setting for unified cooling/heating operation.	2.	0	1	Address 0 1 31			0 1 3
2	Low noise/demand address	Used to make address setting for low noise/demand operation.	2.	0	2	Address 0 1 31			0 1 3
5	Indoor fan forced H	Used to force the fan of indoor unit to H tap.	2.	0	5	Normal operation Indoor fan H			0 1
6	Forced thermostat	Used to force all indoor units to operate forced thermostat ON.	2.	0	6	Normal operation Forced thermostat ON			0 1
8	Te setting	Used to make setting of targeted evaporating temperature for cooling operation.	2.	0	8	Auto 6°C (42.8°F) 7°C (44.6°F) 8°C (46.4°F) 9°C (48.2°F) 10°C (50.0°F) 11°C (51.8°F)			0 2 3 4 5 6 7
9	Tc setting	Used to make setting of targeted condensing temperature for heating operation.	2.	0	9	Auto 41°C (105.8°F) 43°C (109.4°F) 46°C (114.8°F)			0 1 3 6
12	External low noise setting/demand setting	Used to receive external low noise or demand signal.	2.	1	2	Input LNO/DE : NO : YES			0 1
13	AIRNET address	Used to set address of AIRNET	2.	1	3	Address 0 1 63			0 1 3
16	Heat pump lockout 1	Used for heat pump lockout	2.	1	6	OFF ON			0 1
18	High ESP setting FAN	Fan high static pressure setting	2.	1	8	OFF ON			0 1
20	Additional refrigerant charge	Used to perform additional refrigerant charging operation (compressor operation).	2.	2	0	Refrigerant charging OFF ON			0 1
21	Refrigerant recovery and vacuuming	Used to set the system to refrigerant recovery mode (without compressor run).	2.	2	1	Refrigerant recovery OFF ON			0 1
22	Automatic night-time low noise operation	Automatic night-time low noise operation. Time for the operation is subject to the start and end time settings.	2.	2	2	OFF Level 1 Level 2 Level 3			0 1 2 3
25	External low noise level	Low noise level when the external low noise signal is input at option DTA104A61.	2.	2	5	Level 1 Level 2 Level 3			1 2 3

*1: Numbers in the "No." column represent the number of times to press the BS button.

No. *1	Item	Description	7 segment display			Description	7 segment display Range		
			SEG 1	SEG 2	SEG 3		SEG 1	SEG 2	SEG 3
26	Automatic night-time low noise operation start	Time to start automatic "night-time low noise" operation. ("Night-time low noise" level setting should also be made.)	2.	2	8	About 8:00PM About 10:00PM About 12:00AM			1 2 3
27	Automatic night-time low noise operation stop	Time to stop automatic "night-time low noise" operation. ("Night-time low noise" level setting should also be made.)	2.	2	7	About 06:00AM About 07:00AM About 08:00AM			1 2 3
28	Power transistor check	Used to troubleshoot DC compressor. Inverter waveforms are output without wire connections to the compressor. It is useful to determine whether the relevant trouble has resulted from the compressor or inverter PCB.	2.	2	8	OFF ON (10 Hz)			0 1
29	Capacity priority setting	Cancel the low noise level control if capacity is required while low noise operation or night-time low noise operation is in progress.	2.	2	9	OFF ON			0 1
30	Demand 1 setting	Used to make a change to the targeted power consumption level when the demand 1 control signal is inputted.	2.	3	0	Level 1 (60%) Level 2 (65%) Level 3 (70%) Level 4 (75%) Level 5 (80%) Level 6 (85%) Level 7 (90%) Level 8 (95%)			1 2 3 4 5 6 7 8
31	Demand 2 setting	Used to use a targeted power current level when the demand 2 control signal is input.	2.	3	1	Level 1 (40%) Level 2 (50%) Level 3 (55%)			1 2 3
32	Normal demand setting	Used to set permanent demand 1 or 2 control without inputting any external signal.	2.	3	2	OFF Demand 1 (2-30) Demand 2 (2-31)			0 1 2
34	Indoor fan tap setting	Indoor fan speed is limited to L tap depending on connection capacity and outdoor air temperature (Ta). Condition A: Temperature difference average of (indoor air temperature – set temperature) is less than 1.5°C (2.7°F). Condition B: Temperature difference average of (indoor air temperature – set temperature) is 3°C (5.4°F) or more.	2.	3	4	Indoor capacity ≥ 130% Indoor capacity ≥ 130% in heating Remote controller setting (Not limited) Limited in cooling when Ta < 29.5°C (85.1°F) and indoor condition is in Condition A. Returned when Ta > 32.5°C (90.5°F) or indoor condition is in Condition B. Limited in cooling when Ta < 23.5°C (74.3°F) and indoor condition is in Condition A. Returned when Ta > 26.5°C (79.7°F) or indoor condition is in Condition B. Limited in cooling when Ta < 19.3°C (66.7°F) and indoor condition is in Condition A. Returned when Ta > 22.3°C (72.1°F) or indoor condition is in Condition B.			0 1 2 3 4 5
35	Outdoor > 40 m (130 ft) below indoor	To increase Tc target heating.	2.	3	5	Level > 40 m (130 ft) Level max. 40 m (130 ft) Do not use			0 1 2 7
37	Heat pump lockout 2	Used for heat pump lockout	2.	3	7	OFF Mode 1 Mode 2 Mode 3 Mode 4 Mode 5 Mode 6			0 1 2 3 4 5 6

*1: Numbers in the "No." column represent the number of times to press the BS button.

No. *1	Item	Description	7 segment display			Description	7 segment display		
			SEG 1	SEG 2	SEG 3		Range		
						SEG 1	SEG 2	SEG 3	
38	Emergency operation (master)	To prohibit a compressor or complete in "Master". Since module is permanent disabled, immediately replace the defective component(s).	2.	3	8	OFF Master INV. 1 OFF Master INV. 2 OFF Master unit OFF			0 1 2 3
39	Emergency operation (slave 1)	To prohibit a compressor or complete "Slave 1". Since module is permanent disabled, immediately replace the defective component(s).	2.	3	9	OFF Slave 1 INV. 1 OFF Slave 1 INV. 2 OFF Slave 1 unit OFF			0 1 2 3
40	Emergency operation (slave 2)	To prohibit a compressor or complete "Slave 2". Since module is permanent disabled, immediately replace the defective component(s).	2.	4	0	OFF Slave 2 INV. 1 OFF Slave 2 INV. 2 OFF Slave 2 unit OFF			0 1 2 3
42	Outdoor fan	Outdoor fan noise countermeasure (limit fan speed).	2.	4	2	Standard Mode A Mode B			0 1 2
49	Outdoor > 50 m (164 ft) above indoor	Height difference setting max. 90 m (295 ft).	2.	4	9	Off (max. 50 m (164 ft)) On (max 90 m (295 ft))			0 1
51	Sequence multi outdoor	Sequence addressing between master and slave units.	2	5	1	Automatic Forced master Forced slave 1 Forced slave 2			0 1 2 3
62	Cooling/Heating capacity learning control	Adjust cooling and heating capacity learning control	2.	6	2	OFF Cooling adjustment Heating adjustment Cooling and heating adjustment			0 1 2 3
80	Intermittent fan operation	Used for intermittent fan operation setting	2.	8	0	OFF 30 minutes OFF, 1 minute ON with medium fan speed 30 minutes OFF, 1 minute ON with high fan speed			0 1 2
81	Cooling comfort setting	Cooling comfort setting	2.	8	1	Eco Mild Quick Powerful			0 1 2 3
82	Heating comfort setting	Heating comfort setting	2.	8	2	Eco Mild Quick Powerful			0 1 2 3
83	Master user interface setting	Master user interface allocation in case VRV DX indoor units and RA DX indoor units are used at the same time	2.	8	3	VRV DX master RA DX master			0 1
84	Initial opening EEV BP unit at heating mode	Initial opening EEV BP unit at heating thermostat-ON	2.	8	4	400 pulse 500 pulse 600 pulse 300 pulse			0 1 2 3
90	Indoor unit without power	Multi-tenant function setting	2.	9	0	Invalid Valid (No U4 error generation) Valid (Operating with U4 warning)			0 1 2

*1: Numbers in the "No." column represent the number of times to press the BS button.

No. *1	Item	Description	7 segment display			Description	7 segment display		
			Range				Range		
			SEG 1	SEG 2	SEG 3		SEG 1	SEG 2	SEG 3
94	Heat pump lockout temperature	Heat pump is locked out when the outdoor air temperature is smaller than the heat pump lockout temperature.	2.	9	4	-26.1°C (-15°F)			0
						-23.3°C (-10°F)			1
						-20.5°C (-5°F)			2
						-17.7°C (0°F)			3
						-15°C (5°F)			4
						-12.2°C (10°F)			5
						-9.4°C (15°F)			6
						-6.6°C (20°F)			7
						-3.8°C (25°F)			8
						-1.1°C (30°F)			9
						1.6°C (35°F)		:	0
						4.4°C (40°F)		:	1
						7.2°C (45°F)		:	2
						10°C (50°F)		:	3
Forced heat pump lockout		:	4						
95	Heat pump lockout release differential	Heat pump would be resumed when the outdoor air temperature is recovered by differential above the heat pump lockout temperature.	2.	9	5	2.8°C (5°F)			0
						5.6°C (10°F)			1
						8.3°C (15°F)			2
96	Auxiliary heater maximum allowable temperature	Auxiliary heater is allowed to energize when the ambient temperature is smaller than the auxiliary heater maximum allowable temperature.	2.	9	6	-17.7°C (0°F)			0
						-15°C (5°F)			1
						-12.2°C (10°F)			2
						-9.4°C (15°F)			3
						-6.6°C (20°F)			4
						-3.8°C (25°F)			5
						-1.1°C (30°F)			6
						1.6°C (35°F)			7
						4.4°C (40°F)			8
						7.2°C (45°F)			9
						10°C (50°F)		:	0
						12.7°C (55°F)		:	1
						15.5°C (60°F)		:	2
						18.3°C (65°F)		:	3
Auxiliary heater always not allowed		:	4						
Auxiliary heater always allowed		:	5						
97	Auxiliary heater maximum allowable temperature release differential	Auxiliary heater is not allowed to energize when the outdoor air temperature is recovered by differential above the auxiliary heater maximum allowable temperature.	2.	9	7	2.8°C (5°F)			0
						5.6°C (10°F)			1
						8.3°C (15°F)			2

*1: Numbers in the "No." column represent the number of times to press the BS button.

* : Setting does not return to factory setting when exit mode 2. To cancel the function, change setting manually to factory setting.

* : Once function is activated **t01** appears. To stop current function, press once BS3 "Return" button.

For detailed description about each setting, refer to "Description Field Settings (mode 2: m2) on Outdoor Unit Main PCB" on page 177.

Indication **bold** means factory setting.

2.7.2 Details of Setting Mode (Mode 2)

Mode 2 is used to change the field settings of the system. Consulting the current field setting value and changing the current field setting value is possible.

In general, normal operation can be resumed without special intervention after changing field settings.

Some field settings are used for special operation (e.g., 1 time operation, recovery/vacuumping setting, adding refrigerant setting, etc.). In such a case, it is required to abort the special operation before normal operation can restart. It will be indicated in below explanations.

[2-0]: Cool/Heat selection setting

Cool/Heat selection setting is used in case the optional Cool/Heat selector (KRC19-26A) is used.


Depending on the outdoor unit setup (single outdoor unit setup or multi outdoor unit setup), the correct setting should be chosen. More details on how to use the Cool/Heat selector option can be found in the manual of the Cool/Heat selector.

- Default value: 0.
- 0: Each individual outdoor unit can select Cool/Heat operation (by Cool/Heat selector if installed), or by defining master indoor user interface (see setting [2-83])
- 1: Master unit decides Cool/Heat operation when outdoor units are connected in multiple system combination
- 2: Sub unit for Cool/Heat operation when outdoor units are connected in multiple system combination

[2-1]: Cool/heat unified address

Address for cool/heat unified operation.

- When multiple heat pump systems need to change over together between cooling and heating (example multiple systems serve indoor units in landscape area). Per zone the optional PCB DTA104A61/62 needs to be installed. Recommended location is in one of the **VRV** indoor units belonging to the system that will be set as "Master cool/heat unit" (field setting 2-0-1).
- The address set to the multiple systems need to operate as a zone, should be same as the address set by the DIP switches on the related optional PCB DTA104A61/62.



- Default value: 0.
- Field setting: 1-31.
- The source for cool/heat selection can be:
 - Indoor unit: when outdoor unit DIP switch DS1-1 is at the OFF position.
 - Cool/heat switch: set DIP switch DS1-1 on outdoor unit PCB to ON. Operation mode according to connections A-B-C to optional PCB BRP2A81.

[2-2]: Low noise/demand address

Address for low noise/demand operation.

1 or more systems (maximum 10 systems wired by "F1F2 OUT/D") can operate use the LNO (Low Noise Operation) or/and the DE (Demand Control) by instruction of field supplied input to optional PCB DTA104A61/62.

To link the system to the corresponding DTA104A61/62, set the address same as the DIP switches position on the related optional PCB DTA104A61/62.

Ensure that also field setting 2-12-1 is set to enable input from optional PCB DTA104A61/62.

[2-5]: Cross wiring check

Default value: 0. Not active.

Set 1: force all connected indoor units to operate the indoor fan on high speed. This setting can be made to check which units are missing in the communication if the number of indoor units do not correspond to the system lay out. Ensure that after cross wiring check was confirmed, to return setting to default 2-5-0. Once setting 2-5-1 is active, it is not automatically returning to default when exit mode 2.

[2-6]: Forced thermostat ON command all connected indoor units

Default value: 0. Not active.

Set 1: force all connected indoor units to operate under "Test" (forced thermostat ON command to outdoor). Ensure that when the forced thermostat ON needs to be ended, to return setting to default 2-6-0. Once setting 2-6-1 is active, it is not automatically returning to default when exit mode 2.

[2-8]: Te target temperature during cooling operation

Default value: 0

Value [2-8]	Te target
0 (default)	Auto (6-11°C) (42.8-51.8°F)
2	6°C (42.8°F)
3	7°C (44.6°F)
4	8°C (46.4°F)
5	9°C (48.2°F)
6	10°C (50°F)
7	11°C (51.8°F)

Change [2-8] to 0, 2-7 in function of required operation method during cooling.

[2-9]: Tc target temperature during heating operation

Default value: 0

Value [2-9]	Tc target
0 (default)	Auto (38-46°C) (100.4-114.8°F)
1	41°C (105.8°F)
3	43°C (109.4°F)
6	46°C (114.8°F)

Change [2-9] to 0, 1, 3 or 6 in function of required operation method during heating.

- [2-12]: Enable the night-time low noise function and/or power consumption limitation via external control adaptor (DTA104A61/62)
If the system needs to be running under night-time low noise operation or under power consumption limitation conditions when an external signal is sent to the unit, this setting should be changed. This setting will only be effective when the optional external control adaptor (DTA104A61/62) is installed.

Default value: 0

To activate this function, change [2-12] to 1.

- [2-13]: AIRNET address

When an AIRNET system will be used, outdoor unit needs an AIRNET address.

Also to facilitate the recognition of a system in the map lay out of the service checker type III, set each system a unique address between 1 and 63.

When duplicating of AIRNET address, **UC** error code will appear on central control.

- [2-16]: Heat pump lockout 1

Heat pump is always locked out when this setting is ON. If the indoor fan control needs to be changed or the auto-backup function is required, refer to the setting [2-37].

Value [2-16]	Heat pump lockout 1
0 (default)	OFF
1	ON

- [2-18]: Fan high static pressure setting

In order to increase the static pressure the outdoor fan is delivering, this setting should be activated. For details about this setting, see technical specifications.

Default value: 0

To activate this function, change [2-18] to 1.

- [2-20]: Manual additional refrigerant charge

In order to add the additional refrigerant charge amount in a manual way (without automatic refrigerant charging functionality), following setting should be applied.

Default value: 0

To activate this function, change [2-20] to 1.

To stop the manual additional refrigerant charge operation (when the required additional refrigerant amount is charged), press the **RETURN (BS3)** button. If this function was not aborted by pressing the **RETURN (BS3)** button, the unit will stop its operation after 30 minutes.

If 30 minutes was not sufficient to add the needed refrigerant amount, the function can be reactivated by changing the field setting again.

- [2-21]: Refrigerant recovery/vacuuming mode

In order to achieve a free pathway to reclaim refrigerant out of the system or to remove residual substances or to vacuum the system it is necessary to apply a setting which will open required valves in the refrigerant circuit so the reclaim of refrigerant or vacuuming process can be done properly.

Default value: 0

To activate this function, change [2-21] to 1.

To stop the refrigerant recovery/vacuuming mode, press the **RETURN (BS3)** button. If the **RETURN (BS3)** button is not pressed, the system will remain in refrigerant recovery/vacuuming mode.

[2-22]: Automatic night-time low noise setting and level during night time

By changing this setting, you can activate the automatic night-time low noise operation function of the unit and define the level of operation. Depending on the chosen level, the noise level will be lowered (3: Level 3 < 2: Level 2 < 1: Level 1).

The start and stop moments for this function are defined under setting [2-26] and [2-27].

Default value: 0

Change [2-22] to 1, 2 or 3 in function of required level.

[2-25]: Night-time low noise operation level via the external control adaptor

If the system needs to be running under night-time low noise operation conditions when an external signal is sent to the unit, this setting defines the level of night-time low noise that will be applied (3: Level 3 < 2: Level 2 < 1: Level 1).

This setting will only be effective when the optional external control adaptor (DTA104A61/62) is installed and the setting [2-12] was activated.

Default value: 2

Change [2-25] to 1, 2 or 3 in function of required level.

[2-26]: Night-time low noise operation start time

Change [2-26] to 1, 2 or 3 in function of required timing.

Default value: 2.

Value [2-26]	Start time automatic night-time low noise operation (approximately)
1	About 8:00 PM
2 (default)	About 10:00 PM
3	About 12:00 AM

This setting is used in conjunction with setting [2-22].

[2-27]: Night-time low noise operation stop time

Default value: 3.

Value [2-27]	Stop time automatic night-time low noise operation (approximately)
1	About 6:00 AM
2	About 7:00 AM
3 (default)	About 8:00 AM

This setting is used in conjunction with setting [2-22].


[2-28]: Power transistor check mode

To evaluate the output of the power transistors. Use this function in case error code is displayed related to defective inverter PCB or compressor is locked.

- Default value: 0. Power transistor check mode is not active.
- Field setting 1: Power transistor check mode is active.
 - Function:
 - Inverter PCB gives output of 10 Hz in sequence by all 6 transistors. Remove the U/V/W terminals of the compressor, and connect to the inverter checker module. If all 6 LEDs blink, the transistors switch correctly.
 - When the power transistor check mode is interrupted, after internal power circuit is disconnected on the inverter PCB, 2 LEDs will light up to indicate discharge of the DC voltage. Wait till the LEDs are OFF before returning fasten terminals back to the compressor terminals.
 - Minimum requirements to refer to the result on the inverter checker module:
 - All 3 phases and neutral are available, and
 - Inverter PCB control is active. Check if the green LED “HAP” on the inverter PCBs are blinking normal (approx. 1/ second). If LEDs are OFF, need to exit the “standby mode” of the inverter:
 - Disconnect and reconnect power supply control PCB, or
 - Forced thermostat ON condition, or
 - Make shortly set 2-6-1 (forced thermostat ON indoor), or 2-20-1 (manual refrigerant charge).
 - Once the LED is blinking on the inverter PCB, change related setting immediately back to set 0 to deactivate related function.
 - Diode module generates the required 500 VDC.
 - Cautions:
 - In case there is more than 1 compressor in a system (outdoor is 14 HP or larger, or multi outdoor configuration) all compressor inverter PCBs will perform the power transistor check. In such case, disconnect U/V/W fasten terminals on all compressors. Avoid accidental touch of fasten terminals to short circuit or ground leak to casing.
 - To stop the power transistor check mode, change setting to default 2-28-0.
 - Output to U/V/W will also stop when outdoor unit main PCB decides standby mode of inverter circuit.

- Next time graph shows the different steps during the power transistor check mode.
- Switching sequence during power transistor check mode:

Power transistor check mode RXYQ-XA
disconnect fasten U/V/W from compressor!



- Check 1 :** AC power input (connector X10A on A2P: compressor) 380-415 V unbalance max.2%.
- Check 2 :** relay "K1M" on inverter PCB switches : check DC voltage on P&N increase to ± 500 VDC.
- Check 3 :** DC = 1.42 x VAC power supply L1-L3 : check at connector X3A (8-12 HP), or X5,6A (14-20 HP).
- Check 4 :** AC UVW 10 Hz intermediate : check difference within 10 V (at fasten U/V/W)
- Check 5 :** AC UVW 240 Hz continuous output while voltage drop (discharge capacitors DC) (check difference between UVW within 10 V. 2 LEDs (V phase) brightness reduce till of.


*note : actual voltage value depends on meter characteristics

[2-29]: Capacity priority

When the night-time low noise operation is in use, performance of system might drop because airflow rate of outdoor unit is reduced.

- Default value: 0. Capacity priority cannot be used.
- Field setting 1: Capacity priority can temporary cancel the night-time low noise operation. Capacity priority can be initiated when certain operation parameters approach the safety setting:
 - Raise in high pressure during cooling.
 - Drop in low pressure during heating.
 - Raise of discharge pipe temperature.
 - Raise of inverter current.
 - Raise of fin temperature inverter PCB.

When operation parameters return to normal range, the capacity priority is switched OFF, enable to reduce airflow rate depending on night-time low noise operation is still required (end time for night-time low noise operation is not reached or external input night-time low noise operation is still closed).



[2-30]: Power consumption limitation level (step 1) via the external control adaptor (DTA104A61/62)
 If the system needs to run under power consumption limitation conditions when an external signal is sent to the unit, this setting defines the level power consumption limitation that will be applied for step 1. The level is according to the table.

Default value: 3.
 Change [2-30] to 1, 2, 3, 4, 5, 6, 7 or 8 in function of required limitation.

Value [2-30]	Power consumption limitation (approximately)
1	60%
2	65%
3 (default)	70%
4	75%
5	80%
6	85%
7	90%
8	95%

[2-31]: Power consumption limitation level (step 2) via the external control adaptor (DTA104A61/62)
 If the system needs to run under power consumption limitation conditions when an external signal is sent to the unit, this setting defines the level power consumption limitation that will be applied for step 2. The level is according to the table.

Default value: 1.
 Change [2-31] to 1, 2 or 3 in function of required limitation.

Value [2-31]	Power consumption limitation (approximately)
1 (default)	40%
2	50%
3	55%

[2-32]: Forced, all time, power consumption limitation operation (no external control adaptor is required to perform power consumption limitation)

If the system always needs to be running under power consumption limitation conditions, this setting activates and defines the level power consumption limitation that will be applied continuously. The level is according to the table.

Default value: 0 (OFF).

Value [2-32]	Restriction reference
0 (default)	Function not active
1	Follows [2-30] setting
2	Follows [2-31] setting

Change [2-32] to 0, 1 or 2 in function of required limitation.

[2-34]: Indoor fan tap setting

Indoor fan speed limitation related to connection capacity and outdoor air temperature for energy saving.

Default value: 0.

Value [2-34]	Indoor fan tap setting
0 (default)	Fan speed is limited to L tap when indoor units capacity \geq 130%.
1	In heating mode, fan speed is limited to L tap when indoor units capacity \geq 130%.
2	Fan speed follows a setting of the remote controller (not limited by indoor units connection capacity).
3	Fan speed is limited to L tap when outdoor air temperature goes down to below 29.5°C (85.1°F). It returns to remote controller setting when outdoor air temperature goes up to over 32.5°C (90.5 °F).
4	Fan speed is limited to L tap when outdoor air temperature goes down to below 23.5°C (74.3°F). It returns to remote controller setting when outdoor air temperature goes up to over 26.5°C (79.7°F).
5	Fan speed is limited to L tap when outdoor air temperature goes down to below 19.3°C (66.7°F). It returns to remote controller setting when outdoor air temperature goes up to over 22.3°C (72.1°F).

[2-35]: Height difference setting

Default value: 1

In case the outdoor unit is installed in the lowest position (indoor units are installed on a higher position than outdoor units) and the height difference between the highest indoor unit and the outdoor unit exceeds 40 m (130 ft), the setting [2-35] should be changed to 0.

[2-37]: Heat pump lockout 2

Heat pump is locked out when this setting and an external input to ABC terminal are made.

Automatic lockout

When this setting is made, the auto-backup function will automatically be activated. This will allow the auxiliary or secondary heat source to be automatically energized in the event of a system failure related to outdoor units.

Value [2-37]	Heat pump lockout 2
0 (default)	OFF
1	Mode 1
2	Mode 2
3	Mode 3
4	Mode 4
5	Mode 5
6	Mode 6

Mode	Description	Actions					
		Field setting	Shorted between	Heating Thermo-on		Heating Thermo-off	
				Heater	Fan	Heater	Fan
Mode 1	Lockout is controlled by an external input to ABC terminal	2-37: Mode 1	A-C	ON	ON (H/L)	OFF	LL (*2)
B-C			OFF				
Mode 2 (*1)		2-37: Mode 2	A-C		LL		LL (*2)
B-C			OFF		OFF		
Mode 3	Lockout is controlled by the outdoor temperature and setpoint which is configured by the setting [2-94] and [2-95]	2-37: Mode 3	Same as 2-37: Mode 1, A-C shorted				
Mode 4		2-37: Mode 4	Same as 2-37: Mode 1, B-C shorted				
Mode 5		2-37: Mode 5	Same as 2-37: Mode 2, A-C shorted				
Mode 6		2-37: Mode 6	Same as 2-37: Mode 2, B-C shorted				

*1. For a heater which does not need airflow

*2. Depends on the indoor unit field setting 12(22)-3.

[2-38]: Emergency operation “Master”

To disable permanent compressor operation: in case of single module or “Master” unit of a multi outdoor system, this setting allows:

Default value: 0. Compressor operation enabled.

Field setting:

- Set 1: inverter 1 compressor is disabled.
- Set 2: inverter 2 compressor is disabled. Only to make in case of 12/14 ton.
Note that compressor 2 is left side located.
- Set 3: all compressors in this master module are disabled permanent.

[2-39]: Emergency operation “Slave 1”

To disable permanent compressor operation of “Slave 1” unit of a multi outdoor system (RXYQ-XA):

Default value: 0. Compressor operation enabled.

Field setting:

- Set 1: inverter 1 compressor is disabled.
- Set 2: inverter 2 compressor is disabled. Only to make in case of 12/14 ton. Note that compressor 2 is left side located.
- Set 3: all compressors in this master module are disabled permanent.

[2-40]: Emergency operation “Slave 2”

To disable permanent compressor operation of “Slave 2” unit of a multi outdoor system (RXYQ-XA):
Default value: 0. Compressor operation enabled.

Field setting:

- Set 1: inverter 1 compressor is disabled.
- Set 2: inverter 2 compressor is disabled. Only to make in case of 12/14 ton. Note that compressor 2 is left side located.
- Set 3: all compressors in this master module are disabled permanent.

Combination table setting 2-38, 2-39 and 2-40:

disable	Master/ individual	Slave 1	Slave 2
compressor 1	2-38-1	2-39-1	2-40-1
compressor 2	2-38-2	2-39-2	2-40-2
module	2-38-3	2-39-3	2-40-3

[2-42]: Outdoor fan noise countermeasure

Change fans rotational speed and reduce noise by the interference of air blow noise between outdoor units.

Default value: 0

Field setting:

- Mode A: 1
- Mode B: 2

[2-49]: Height difference setting

Default value: 0.

In case the outdoor unit is installed in the highest position (indoor units are installed on a lower position than outdoor units) and the height difference between the lowest indoor unit and the outdoor unit exceeds 50 m (164 ft), the setting [2-49] has to be changed to 1.

[2-51]: Master/Slave setting Multi

When 2 or 3 modules are installed as a multi-outdoor (by common refrigerant piping and wiring by terminals Q1Q2) configuration is automatically detected. In certain cases, the sequence of the slave units need to be set manually (in case of AIRNET monitoring).

Default value: 0. Automatic detection.

Field setting: ensure that the modules in a multi are set different status. Even some modules in a multi are set manually to same status, U7 error will appear.

- 1: forced “Master” (F1F2/Ind terminals should be connected to indoor units).
- 2: forced “Slave 1” (only Q1Q2 terminals should be wired to “Master” module).
- 3: forced “Slave 2” (only Q1Q2 terminals should be wired to “Master” module).

[2-62]: Cooling and heating capacity learning control

Default value: 0.

Value [2-62]	Description
0 (default)	OFF
1	Cooling adjustment
2	Heating adjustment
3	Cooling and heating adjustment

Adjust cooling and heating system operation to achieve stable capacity.

Note:

This setting may result in a longer reaction time to large load variations.

[2-80]: Intermittent fan drive setting

Default value: 0.

Used for intermittent fan operation to assist snow discharge on outdoor fan.

Value [2-80]	Intermittent fan operation
0 (default)	OFF
1	30 minutes OFF, 1 minute ON with medium fan speed
2	30 minutes OFF, 1 minute ON with high fan speed

[2-81]: Cooling comfort setting

Default value: 1.

Value [2-81]	Cooling comfort setting
0	Eco
1 (default)	Mild
2	Quick
3	Powerful

Change [2-81] to 0, 1, 2 or 3 in function of required limitation.

This setting is used in conjunction with setting [2-8].

[2-82]: Heating comfort setting

Default value: 1.

Value [2-82]	Heating comfort setting
0	Eco
1 (default)	Mild
2	Quick
3	Powerful

Change [2-82] to 0, 1, 2 or 3 in function of required limitation.

This setting is used in conjunction with setting [2-9].

[2-83]: Master user interface allocation in case **VRV** indoor units and RA indoor units are used at the same time
By changing setting [2-83], you can allow the **VRV** indoor unit to be the operation mode selector (system power OFF/ON is required after applying this setting).

- 1: RA indoor unit has mode selection right (default setting).
- 0: **VRV** indoor unit has mode selection right.

[2-84]: Initial opening electronic expansion valve BP unit heating thermostat-ON

- Default value: 1 (500 pulse)
- Field setting 0: 400 pulse, 2: 600 pulse, 3: 300 pulse.

[2-90]: Indoor unit without power

U4 error generation.

In case an indoor unit needs maintenance or repair on the electric side, it is possible to keep the rest of the **VRV** DX indoor units operating without power supply to some indoor unit(s).

Default value: 0 (not active)

Field setting 1: It is possible to operate system without **U4** error when some indoor units are temporarily without power supply.

Field setting 2: It is possible to operate system with **U4** warning when some indoor units are temporarily without power supply.

Following conditions need to fulfil:

- Maximum equivalent piping length of the farthest indoor less than 120 m (394 ft).
- Index indoor units power simultaneously less than 30% of the nominal outdoor.
- Total capacity is less than 30% of the nominal one of the outdoor unit.
- Operation time is limited to 24 hours period.
- It is recommended to shut down connected indoor units at the same floor.
- Not possible to use service mode operation (e.g. recovery mode).
- Backup operation has priority over this special feature.

[2-94]: Heat pump lockout temperature

Heat pump is locked out when the outdoor air temperature is smaller than the heat pump lockout temperature.

This is only effective when the heat pump lockout 2 setting [2-37] is Mode 3 to 6.

Value [2-78]	Heat pump lockout temperature
0 (default)	-26.1°C (-15°F)
1	-23.3°C (-10°F)
2	-20.5°C (-5°F)
3	-17.7°C (0°F)
4	-15°C (5°F)
5	-12.2°C (10°F)
6	-9.4°C (15°F)
7	-6.6°C (20°F)
8	-3.8°C (25°F)
9	-1.1°C (30°F)
10	1.6°C (35°F)
11	4.4°C (40°F)
12	7.2°C (45°F)
13	10°C (50°F)
14	Forced heat pump lockout

[2-95]: Heat pump lockout release differential

Heat pump is resumed when the outdoor air temperature is recovered by differential above the heat pump lockout temperature.

Value [2-79]	Heat pump lockout release differential
0	2.8°C (5°F)
1 (default)	5.6°C (10°F)
2	8.3°C (15°F)

[2-96]: Auxiliary heater maximum allowable temperature

Auxiliary heater is allowed to energize when the ambient temperature is smaller than the auxiliary heater maximum allowable temperature.

Value [2-97]	Auxiliary heater maximum allowable temperature
0	-17.7°C (0°F)
1	-15°C (5°F)
2	-12.2°C (10°F)
3	-9.4°C (15°F)
4	-6.6°C (20°F)
5	-3.8°C (25°F)
6	-1.1°C (30°F)
7 (default)	1.6°C (35°F)
8	4.4°C (40°F)
9	7.2°C (45°F)
10	10°C (50°F)
11	12.7°C (55°F)
12	15.5°C (60°F)
13	18.3°C (65°F)
14	Auxiliary heater always not allowed
15	Auxiliary heater always allowed

[2-97]: Auxiliary heater maximum allowable temperature release differential

Auxiliary heater is not allowed to energize when the outdoor air temperature is recovered by differential above the auxiliary heater maximum allowable temperature.

Value [2-98]	Auxiliary heater maximum allowable temperature release differential
0	2.8°C (5°F)
1 (default)	5.6°C (10°F)
2	8.3°C (15°F)

3. Test Operation

3.1 Checks before Test Operation

Before carrying out a test operation, proceed as follows:

Step	Action
1	Make sure the voltage at the primary side of the safety breaker is: (230 V or 460 V) \pm 10% for 3-phase units
2	Fully open the liquid and the gas stop valve.

3.2 Checkpoints

To carry out a test operation, check the following:

- Check that the temperature setting of the remote controller is at the lowest level in cooling mode or use test mode.
- Go through the following checklist:

Checkpoints	Cautions or warnings
Are all units securely installed?	<ul style="list-style-type: none"> ● Dangerous for turning over during storm ● Possible damage to pipe connections
Is the ground wire installed according to the applicable local standard?	Dangerous if electric leakage occurs
Are all air inlets and outlets of the indoor and outdoor units unobstructed?	<ul style="list-style-type: none"> ● Poor cooling ● Poor heating
Does the drain flow out smoothly?	Water leakage
Is piping adequately heat-insulated?	Water leakage
Have the connections been checked for gas leakage?	<ul style="list-style-type: none"> ● Poor cooling ● Poor heating ● Stop
Is the supply voltage conform to the specifications on the name plate?	Incorrect operation
Are the cable sizes as specified and according to local regulations?	Damage of cables
Are the remote controller signals received by the unit?	No operation

3.3 Check Work Prior to Turn Power Supply ON

Check that the installation work for the indoor and outdoor units has been performed in accordance with the instructions in the Installation Manual.

Check the below items.

- Power wiring
- Control transmission wiring between units
- Ground wire
- Branch switch
- Ground leakage circuit breaker



Check on refrigerant piping / insulation materials



Check air tight test and vacuum drying.



Check on amount of additional refrigerant charge



Check the stop valves for conditions.

- Is the wiring performed as specified?
- Are the branch switches and ground leakage circuit breakers wired correctly?
- Is the designated wire used?
- Is the wiring screw of wiring not loose?
- Is the grounding work completed?
- Is the insulation of the main power supply circuit deteriorated?


Use a 500 V megger tester to measure the insulation. (*1)

Do not use a megger tester for other circuits than 400 V or 200 V circuit.

*1: Measure to be taken against decreased insulation resistance in the compressor

If the compressor is left to stand for an extended period of time after the refrigerant charge with the stop valve open and the power supply OFF, the refrigerant may be mixed in the compressor, thus decreasing the insulation resistance.

Heat the compressor as shown on the right and then recheck the insulation.



- Is the pipe size proper? Are the design pressures for the gas pipe and liquid pipe more than 4.0 MPa (580 psi)?
- Is the pipe insulation material installed securely?
Liquid and gas pipes need to be insulated. (Otherwise causes water leak.)

- Have the air tight test and the vacuum drying been conducted according to the procedure in the Installation Manual?

- Is a proper quantity of refrigerant charged?
* When the refrigerant level is insufficient, leave the liquid and gas stop valves closed and charge with liquid refrigerant via the liquid stop valve service port. (* Do not charge via the gas stop valve service port. Doing so will result in error.)
- Is the amount of additional refrigerant charge recorded in the Service Precaution label?

- Check to be sure the stop valves are under the following conditions.

Liquid side stop valve	Gas side stop valve
Open	Open

3.4 Turn Power ON

Turn outdoor unit and indoor unit power ON.




Check the 7 segment display of the outdoor unit PCB.




- Be sure to turn the power ON 6 hours before starting operation to protect compressors. (to power ON crankcase heater)


- Check to be sure the transmission is normal. In a normal condition, the 7-segment display is OFF. Please refer to the following figure for other states.



Power switched ON
initial check




Normal




Initialisation in progress

Abnormal




Main error code

Switching alternative 1 second



Initialisation terminated (normal)



Sub error code

(*) The master unit is the outdoor unit to which the transmission wiring for the indoor units is connected. The other outdoor units are slave units.

Make field settings with outdoor unit PCB.



Conduct check operations.



Check for normal operation.

- Make field settings if needed. (For the setting procedure, refer to information in "Field Settings for Outdoor Unit" on page 159 onward.) For the outdoor-multi system, make field settings with the master unit. (Field settings made with the slave unit will be all invalid.)

The check operations shown below will be automatically initiated.

- Check for erroneous wirings
- Check for failure to open stop valves
- Check for excessive refrigerant refilling
- Automatic judgment of piping length

- Before starting the normal operation after the completion of check operations, make sure indoor and outdoor units normally operate.

3.5 Gas Furnace Test Operation



Caution: Always use the remote controller to stop the test operation.

The test should be performed with the following procedure.

1. All install process, including heat pump system, has been done.
2. Test operation of heat pump system has been successfully completed.
3. Turn off remote controller connected to CXTQ-TA.
4. Change the setting according to the following table.

■ : Factory setting

Mode No.	First Code No.	Second Code No.	Gas furnace test mode
14 (24)	11	01	OFF
		02	Low heat
		03	High heat

5. Turn on remote controller connected to CXTQ-TA.
6. The compressor will be forcibly stopped if the compressor is running at this time.
After that, the gas furnace will run in tens of seconds.
(Tens of minutes might well be needed to stop compressor if the outdoor unit is particular operation.)
7. The gas furnace will operate with selected heat stage.
8. This test operation will stop automatically after 30 minutes or when the remote controller is turned off.



- Note:**
- Heat pump operation is not allowed during this test operation.
 - When the heat pump is in service mode (test mode, pump down mode, refrigerant charge mode, etc.), this gas furnace test will not start.
 - This setting will be returned to factory setting automatically after finishing test operation.

Part 6

Service Diagnosis


1. Symptom-based Troubleshooting	197
1.1 Indoor Unit Overall	197
1.2 With Gas Furnace	200
1.3 Gas Furnace Lockout Reset.....	200
1.4 With Optional Infrared Presence/Floor Sensor.....	201
2. Troubleshooting with Remote Controller.....	202
2.1 Wired Remote Controller.....	202
2.2 Wireless Remote Controller	203
3. Troubleshooting by Error Code	205
3.1 Error Codes and Descriptions	205
3.2 Error Codes - Sub Codes	207
3.3 External Protection Device Abnormality	219
3.4 Indoor Unit PCB Abnormality	221
3.5 Drain Level Control System Abnormality.....	222
3.6 Fan Motor Lock, Overload.....	224
3.7 Indoor Fan Motor Abnormality	226
3.8 Overload/Overcurrent/Lock of Indoor Fan Motor.....	230
3.9 Blower Motor Not Running	231
3.10 Indoor Fan Motor Status Abnormality.....	232
3.11 Low Indoor Airflow.....	233
3.12 Swing Flap Motor Abnormality	234
3.13 Power Supply Voltage Abnormality	236
3.14 Blower Motor Stops for Over/Under Voltage.....	237
3.15 Electronic Expansion Valve Coil Abnormality, Dust Clogging	238
3.16 Gas Furnace Abnormality.....	239
3.17 Drain Level above Limit.....	240
3.18 Capacity Determination Device Abnormality	241
3.19 Transmission Abnormality between Indoor Unit PCB and Fan PCB.....	242
3.20 Blower Motor Communication Error	244
3.21 Climate Talk Communication Error	245
3.22 Thermistor Abnormality	246
3.23 Combination Error between Indoor Unit Control PCB and Fan PCB	247
3.24 Blower Motor HP Mismatch.....	248
3.25 Indoor Blower Does Not Have Required Parameters to Function.....	249
3.26 Remote Sensor Abnormality	250
3.27 Humidity Sensor System Abnormality	251
3.28 Infrared Presence/Floor Sensor Error	252
3.29 Remote Controller Thermistor Abnormality	257
3.30 Outdoor Unit Main PCB Abnormality.....	258
3.31 Current Leakage Detection	259
3.32 Missing of Leakage Detection Core	260

3.33 Activation of High Pressure Switch	261
3.34 Activation of Low Pressure Sensor	263
3.35 Compressor Motor Lock	264
3.36 Compressor Damage Alarm	266
3.37 Outdoor Fan Motor Abnormality	268
3.38 Electronic Expansion Valve Coil Abnormality.....	271
3.39 Discharge Pipe Temperature Abnormality	273
3.40 Wet Alarm.....	275
3.41 Refrigerant Overcharged.....	277
3.42 Harness Abnormality (between Outdoor Unit Main PCB and Inverter PCB)	278
3.43 Outdoor Fan Motor Signal Abnormality	279
3.44 Thermistor Abnormality	280
3.45 High Pressure Sensor Abnormality	282
3.46 Low Pressure Sensor Abnormality	284
3.47 Inverter PCB Abnormality	286
3.48 Reactor Temperature Rise Abnormality	288
3.49 Inverter Radiation Fin Temperature Rise Abnormality	289
3.50 Compressor Instantaneous Overcurrent	290
3.51 Compressor Overcurrent.....	292
3.52 Compressor Startup Abnormality	294
3.53 Transmission Error between Inverter PCB and Outdoor Unit Main PCB.....	297
3.54 Power Supply Voltage Imbalance	299
3.55 Reactor Temperature Abnormality	301
3.56 Inverter Radiation Fin Temperature Abnormality	302
3.57 Field Setting after Replacing Outdoor Unit Main PCB Abnormality or Combination of PCB Abnormality	304
3.58 Refrigerant Shortage	305
3.59 Reverse Phase, Open Phase	306
3.60 Power Supply Insufficient or Instantaneous Abnormality	307
3.61 Check Operation not Executed	310
3.62 Transmission Error between Indoor Units and Outdoor Units.....	311
3.63 Transmission Error between Remote Controller and Indoor Unit.....	314
3.64 Transmission Error between Outdoor Units	315
3.65 Transmission Error between Main and Sub Remote Controllers	321
3.66 Transmission Error between Indoor Unit and Outdoor Unit in the Same System.....	322
3.67 Improper Combination of Indoor Unit and Outdoor Unit, Indoor Unit and Remote Controller	323
3.68 Incorrect Gas Furnace Connecting Number.....	328
3.69 Incorrect Electric Heater Capacity Setting.....	329
3.70 Address Duplication of Centralized Controller.....	330
3.71 Transmission Error between Centralized Controller and Indoor Unit.....	331
3.72 System Not Set Yet.....	334
3.73 System Abnormality, Refrigerant System Address Undefined	335
3.74 Climate Talk Communication System Combination Error (Before Initial Setting for Communication Completes)	337

3.75 Climate Talk Communication System Combination Error (After Initial Setting for Communication Completes)	338
4. Check	339
4.1 High Pressure Check	339
4.2 Low Pressure Check	340
4.3 Superheat Operation Check	342
4.4 Power Transistor Check	344
4.5 Refrigerant Overcharge Check	345
4.6 Refrigerant Shortage Check	346
4.7 Vacuuming and Dehydration Procedure	347
4.8 Thermistor Check	348
4.9 Pressure Sensor Check	351
4.10 Broken Wire Check of the Relay Wires	352
4.11 Fan Motor Connector Check (Power Supply Cable)	353
4.12 Fan Motor Connector Check (Signal Cable)	354
4.13 Electronic Expansion Valve Coil Check	356
4.14 Fan Motor Connector Check for FXTQ-TA	358

1. Symptom-based Troubleshooting

1.1 Indoor Unit Overall

	Symptom	Supposed Cause	Countermeasure	
1	The system does not start operation at all.	Blowout of fuse(s)	Turn Off the power supply and then replace the fuse(s).	
		Cutout of breaker(s)	<ul style="list-style-type: none"> If the knob of any breaker is in its OFF position, turn ON the power supply. If the knob of any circuit breaker is in its tripped position, do not turn ON the power supply.  <p>The diagram shows a vertical rectangular circuit breaker. To its right, a knob is shown in three positions: 'ON' at the top, 'Tripped' in the middle, and 'OFF' at the bottom. A line points from the text 'Circuit breaker' to the main body of the breaker.</p>	
		Power failure	After the power failure is reset, restart the system.	
		The connector loose or not fully plugged in	Turn off the power supply to verify the connection of the connector.	
2	The system starts operation but makes an immediate stop.	Blocked air inlet or outlet of indoor or outdoor unit	Remove obstacle(s).	
		Clogged air filter(s)	Clean the air filter(s).	
3	The system does not cool or heat air well.	Blocked air inlet or outlet of indoor or outdoor unit	Remove obstacle(s).	
		Clogged air filter(s)	Clean the air filter(s).	
		Enclosed outdoor unit(s)	Remove the enclosure.	
		Improper set temperature	Set the temperature to a proper degree.	
		Airflow rate set to LOW	Set it to a proper airflow rate.	
		Improper direction of air diffusion	Set it to a proper direction.	
		Open window(s) or door(s)	Shut it tightly.	
		[In cooling] Direct sunlight received	Hang curtains or shades on windows.	
		[In cooling] Too many persons staying in a room	The model must be selected to match the air conditioning load.	
[In cooling] Too many heat sources (e.g. OA equipment) located in a room				
4	The system does not operate.	The system stops and immediately restarts operation.	If the operation lamp on the remote controller turns ON, the system will be normal. These symptoms indicate that the system is controlled so as not to put unreasonable loads on the system.	
		Pressing the temperature setting button immediately resets the system.		
		The remote controller displays CENTRAL CONTROL , which blinks for a period of several seconds when the OPERATION button is depressed.	The system is controlled with centralized controller. Blinking display indicates that the system cannot be operated using the remote controller.	Operate the system using the COOL/HEAT centralized remote controller.
		The system stops immediately after turning ON the power supply.	The system is in preparation mode of micro computer operation.	Wait for a period of approximately one minute.
5	The system makes intermittent stops.	The remote controller displays error codes U4 or U5 , and the system stops but restarts after a lapse of several minutes.	The system stops due to an interruption in communication between units caused by electrical noises coming from equipment other than air conditioners.	Remove causes of electrical noises. If these causes are removed, the system will automatically restart operation.

	Symptom	Supposed Cause	Countermeasure	
6	COOL/HEAT selection is disabled.	The remote controller displays CENTRAL CONTROL .	This remote controller has no option to select cooling operation.	Use a remote controller with option to select cooling operation.
		The remote controller displays CENTRAL CONTROL , and the COOL/HEAT selection remote controller is provided.	COOL/HEAT selection is made using the COOL/HEAT selection remote controller.	Use the COOL/HEAT selection remote controller to select cool or heat.
7	The system conducts fan operation but not cooling or heating operation.	This symptom occurs immediately after turning ON the power supply.	The system is in preparation mode of operation.	Wait for a period of approximately 10 minutes.
		The remote controller displays CENTRAL CONTROL ; no cooling or heating operation is performed. Switch to fan operation.	In thermal storage operation, the unit is set to fan operation in cooling or heating operation, and the remote controller shows CENTRAL CONTROL .	Normal operation.
8	The airflow rate is not reproduced according to the setting.	Even pressing the airflow rate setting button makes no changes in the airflow rate.	In heating operation, when the room temperature reaches the set degree, the outdoor unit will stop while the indoor unit is brought to fan LL operation so that no one gets cold air. Furthermore, if fan operation mode is selected when other indoor unit is in heating operation, the system will be brought to fan LL operation.	Normal operation.
9	The airflow direction is not reproduced according to the setting.	The airflow direction is not corresponding to that displayed on the remote controller. The flap does not swing.	Automatic control	Normal operation.
10	A white mist comes out from the system.	Indoor unit In cooling operation, the ambient humidity is high. (This indoor unit is installed in a place with much oil or dust.)	Uneven temperature distribution due to heavy stain of the inside of the indoor unit	Clean the inside of the indoor unit.
		Indoor unit Immediately after cooling operation stopping, the indoor air temperature and humidity are low.	Hot gas (refrigerant) that has flowed in the indoor unit results to be vapor from the unit.	Normal operation.
		Indoor and outdoor units After the completion of defrost operation, the system is switched to heating operation.	Defrosted moisture turns to be vapor and comes out from the units.	Normal operation.

	Symptom	Supposed Cause	Countermeasure
11	The system produces sounds.	Indoor unit Immediately after turning ON the power supply, indoor unit produces ringing sounds.	These are operating sounds of the electronic expansion valve of the indoor unit. Normal operation. This sound becomes low after a lapse of approximately one minute.
		Indoor and outdoor units Hissing sounds are continuously produced while in cooling or defrost operation.	These sounds are produced from gas (refrigerant) flowing respectively through the indoor and outdoor units. Normal operation.
		Indoor and outdoor units Hissing sounds are produced immediately after the startup or stop of the system, or the startup or stop of defrost operation.	These sounds are produced when the gas (refrigerant) stops or changes flowing. Normal operation.
		Indoor unit Faint sounds are continuously produced while in cooling operation or after stopping the operation.	These sounds are produced from the drain discharge device in operation. Normal operation.
		Indoor unit Creaking sounds are produced while in heating operation or after stopping the operation.	These sounds are produced from resin parts expanding and contracting with temperature changes. Normal operation.
		Indoor unit Sounds like trickling or the like are produced from indoor units in the stopped state.	On VRV systems, these sounds are produced when other indoor units in operation. The reason is that the system runs in order to prevent oil or refrigerant from dwelling. Normal operation.
		Outdoor unit Pitch of operating sounds changes.	The reason is that the compressor changes the operating frequency. Normal operation.
12	Dust comes out from the system.	Dust comes out from the system when it restarts after the stop for an extended period of time.	Dust, which has deposited on the inside of indoor unit, is blown out from the system. Normal operation.
13	Odors come out from the system.	In operation	Odors of room, cigarettes or else adsorbed to the inside of indoor unit are blown out. The inside of the indoor unit should be cleaned.
14	Outdoor fan does not rotate.	In operation	The reason is that fan revolutions are controlled to put the operation to the optimum state. Normal operation.
15	LCD display 88 or Checking the connection. Please stand by. appears on the remote controller.	Immediately after turning ON the power supply	The reason is that the system is checking to be sure the remote controller is normal. Normal operation. This code is displayed for a period of approximately one minute at maximum.
16	The outdoor unit compressor or the outdoor fan does not stop.	After stopping operation	It stops in order to prevent oil or refrigerant from dwelling. Normal operation. It stops after a lapse of approximately 5 to 10 minutes.
17	The outdoor gets hot.	While stopping operation	The reason is that the compressor is warmed up to provide smooth startup of the system. Normal operation.
18	Hot air comes out from the system even though it stops.	Hot air is felt while the system stops.	On VRV systems, small quantity of refrigerant is fed to indoor units in the stopped state when other indoor units are in operation. Normal operation.
19	The system does not cool air well.	The system is in dry operation.	The reason is that the dry operation serves not to reduce the room temperature where possible. Change the system to cooling operation.

1.2 With Gas Furnace

	Symptom	Supposed Cause
1	The gas furnace does not start operation.	The gas furnace does not start operation while the compressor is during operation or under stop-control, or right after defrost IN or defrost OUT. Wait until the operation becomes stable.
2	Operation does not switch from heat pump to gas furnace in spite of low room temperature. Operation does not switch from gas furnace to heat pump even though the room temperature is nearing the set temperature.	This function is performed only with outdoor units which support automatic switching between gas furnace and heat pump <u>interlocking with room temperature</u> . Some models are enabled to support automatic switching between gas furnace and heat pump <u>interlocking with outdoor air temperature</u> by setting heat pump lockout on an outdoor unit side. However, the compressor stops while gas furnace is during operation.
3	AA-03 (Gas furnace abnormality) is indicated on the remote controller while no error is indicated on the PCB of the gas furnace.	In some cases of gas furnace abnormality, error indication on the remote controller is retained even after the abnormality is removed. Execute combustion heating operation once or reset the power source.
4	The airflow rate indication on the remote controller is not consistent with the actual airflow rate of the indoor unit.	The airflow rate of the indoor unit during gas furnace combustion heating depends on the intensity of combustion. Therefore, the airflow rate of the indoor unit does not reflect the airflow setting of the remote controller.

1.3 Gas Furnace Lockout Reset

Furnace lockout is characterized by a non-functioning furnace (circulator blower may be running continuously) providing a diagnostic LED code located on the furnace board.

Lockout results when a furnace control detects abnormal conditions. If the furnace is in "lockout", the following methods can be used to clear the error.

- a. Turn the remote controller OFF to clear the error. If the error is not cleared, proceed to next step.
- b. Heat pump lockout conditions are met.
- c. Set the setting temperature to maximum, then turn the remote controller ON.
- d. Turn the remote controller OFF.
- e. Turn the remote controller ON after around 15 seconds from procedure d.


The procedures c, d, and e will not work during certain outdoor unit operations, i.e. defrost, startup, compressor stop, service mode etc.

If the LED of the **ON/OFF** button is flashing when you turn the remote controller ON, you cannot clear the error with the method above. In that case, the error must be cleared using the gas furnace. Refer to the gas furnace operation manual for more details.

1.4 With Optional Infrared Presence/Floor Sensor

	Condition	Measure
1	"Louver operation different from setting" or "No downward airflow in heating operation"	Refer to the following table.
2	Individual airflow direction setting different from the actual airflow direction	· Check the "Louver operation different from setting" error diagnosis.
3	While not operating, the louver does not close completely.	Turn off the circuit breaker and then turn it on again.
4	The remote controller menu does not display energy saving operating mode for when people are not present. The remote controller menu does not display the stop function for when people are not present. The remote controller menu does not display the automatic draft prevention function.	Refer to Infrared Presence/Floor Sensor Error (CE) on page 252.
5	The menu does not display the eco-friendly display function.	No defect. Set the clock.
6	During cooling and dry operation, the louver automatically switches from horizontal (P0) to one-level downward (P1).	No defect. When relative ambient humidity is higher, automatic louver control will be activated.
7	During heating operation, the use of an airflow block will not cause other louvers to turn downward (P4).	No defect. In heating operation, if an airflow block is set, then the air outlet control outside the airflow block will be within the range P0-P3.
8	When using airflow block, the airflow block will be routinely lifted (become horizontal) during heating operation.	No defect. Set louver to horizontal (P0) during thermostat OFF.
9	Although people are not present, the infrared presence sensor detects human presence.	Check if there are any objects that generate temperature change when moving. For example: · An electric heater with swing function · Doors, curtains, blind switches · Output of paper from a fax machine or a printer · Turning on/off of incandescent lights · Moving objects
10	Although people are present, the infrared presence sensor fails to determine their presence.	Check for the following conditions. · Lack of movement · Facing away from the sensor · Little skin exposed · Slight movement in a place far from the sensor
11	Large difference between floor temperature and actual temperature	Check for the following conditions. · Sensor detection zone affected by solar radiation · High or low temperature objects in the sensor detection zone · Large difference between floor temperature and temperature of the living space · Sensors installed near walls may be affected by wall temperature.


Error diagnosis of "Louver operation different from setting"



2. Troubleshooting with Remote Controller

2.1 Wired Remote Controller

The following will be displayed on the screen when an error (or a warning) occurs during operation. Check the error code and take the corrective action specified for the particular model.



(1) Checking an error or warning

	Operation Status	Display	
Abnormal shutdown	The system stops operating.	The operation lamp (green) starts to blink. The message Error: Push Menu button will blink at the bottom of the screen.	
Warning	The system continues its operation.	The operation lamp (green) remains on. The message Warning: Push Menu button will blink at the bottom of the screen.	

(2) Taking corrective action.

Press the **Menu/OK** button to check the error code.






Take the corrective action specific to the model.

Error Code:A1	— Error code
Indoor Model FXFQ07TVJU Outdoor Model RXYQ72XAYDA	— Applicable model names

2.2 Wireless Remote Controller


If the unit stops due to an error, the operation indicating LED on the signal receiving part of indoor unit blinks. The error code can be determined by following the procedure described below. (The error code is displayed when an operation error has occurred. In normal condition, the error code of the last problem is displayed.)




1. Press **INSPECTION/TEST** button to enter inspection mode. Then the figure  blinks on the unit number display.
2. Press **UP** button or **DOWN** button and change the unit number until the receiver of the remote controller starts to beep.
3 short beeps : Follow all steps below.
1 short beep : Follow steps 3 and 4. Continue the operation in step 4 until you hear a continuous beep. This continuous beep indicates that the error code is confirmed.
Continuous beep : There is no abnormality.
3. Press **MODE** button. The left  (upper digit) indication of the error code blinks.
4. Press **UP** button or **DOWN** button to change the error code upper digit until the receiver of the indoor unit starts to beep.

■ The upper digit of the code changes as shown below.



- Continuous beep** : Both upper and lower digits match. (Error code is confirmed.)
 - 2 short beeps** : The upper digit matches but the lower digit does not.
 - 1 short beep** : The upper digit does not match.
5. Press **MODE** button. The right  (lower digit) indication of the error code blinks.
 6. Press **UP** button or **DOWN** button and change the error code lower digit until the receiver of the indoor unit generates a continuous beep.

- The lower digit of the code changes as shown below.




Continuous beep : Both upper and lower digits match. (Error code is confirmed.)

2 short beeps : The upper digit matches but the lower digit does not.

1 short beep : The upper digit does not match.

7. Press **MODE** button to return to the normal mode. If you do not press any button for 1 minute, the remote controller automatically returns to the normal mode.



3. Troubleshooting by Error Code

3.1 Error Codes and Descriptions

○: ON ●: OFF ◐: Blink

	Error code	Operation lamp	Descriptions	Reference page
Indoor Unit	A0	●	External protection device abnormality	219
	A1	●	Indoor unit PCB abnormality	221
	A3	●	Drain level control system abnormality	222
	A6	●	Fan motor lock, overload	224
			Indoor fan motor abnormality	226
			Overload/overcurrent/lock of indoor fan motor	230
			Blower motor not running	231
			Indoor fan motor status abnormality	232
			Low indoor airflow	233
	A7 (*1)	○	Swing flap motor abnormality	234
	A8	●	Power supply voltage abnormality	236
			Blower motor stops for over/under voltage	237
	A9	●	Electronic expansion valve coil abnormality, dust clogging	238
	AA	●	Gas furnace abnormality	239
	AF (*1)	○	Drain level above limit	240
	AJ	●	Capacity determination device abnormality	241
	C1	●	Transmission abnormality between indoor unit PCB and fan PCB	242
			Blower motor communication error	244
			Climate Talk communication error	245
	C4	●	Heat exchanger liquid pipe thermistor abnormality	246
	C5	●	Heat exchanger gas pipe thermistor abnormality	246
	C6	●	Combination error between indoor unit control PCB and fan PCB	247
			Blower motor HP mismatch	248
			Indoor blower does not have required parameters to function	249
	C9 (*2)	●	Suction air thermistor abnormality	246
			Remote sensor abnormality	250
	CA	●	Discharge air thermistor abnormality	246
CC	○	Humidity sensor system abnormality	251	
CE (*1)	○	Infrared presence/floor sensor error	252	
CJ (*2)	○	Remote controller thermistor abnormality	257	
Outdoor Unit	E1	●	Outdoor unit main PCB abnormality	258
	E2	●	Current leakage detection	259
			Missing of leakage detection core	260
	E3	●	Activation of high pressure switch	261
	E4	●	Activation of low pressure sensor	263
	E5	●	Compressor motor lock	264
	E6	●	Compressor damage alarm	266
	E7	●	Outdoor fan motor abnormality	268
	E9	●	Electronic expansion valve coil abnormality	271
	F3	●	Discharge pipe temperature abnormality	273
	F4	○/●	Wet alarm	275
	F6	●	Refrigerant overcharged	277
	H3	●	Harness abnormality (between outdoor unit main PCB and inverter PCB)	278
	H7	●	Outdoor fan motor signal abnormality	279
	H9	●	Outdoor air thermistor (R1T) abnormality	280
	J3	●	Discharge pipe thermistor (R21T, R22T) abnormality Compressor body thermistor (R8T) abnormality	280
	J5	●	Accumulator inlet thermistor (R3T) abnormality	280

○: ON ●: OFF ◐: Blink

	Error code	Operation lamp	Descriptions	Reference page
Outdoor Unit	J6	●	Heat exchanger deicer thermistor (R7T) abnormality	280
	J7	●	Subcooling heat exchanger liquid pipe thermistor (R5T) abnormality	280
	J8	●	Heat exchanger liquid pipe thermistor (R4T) abnormality	280
	J9	●	Subcooling heat exchanger gas pipe thermistor (R6T) abnormality	280
	JA	●	High pressure sensor abnormality	282
	JC	●	Low pressure sensor abnormality	284
	L1	●	Inverter PCB abnormality	286
	L3	●	Reactor temperature rise abnormality	288
	L4	●	Inverter radiation fin temperature rise abnormality	289
	L5	●	Compressor instantaneous overcurrent	290
	L8	●	Compressor overcurrent	292
	L9	●	Compressor startup abnormality	294
	LC	●	Transmission error between inverter PCB and outdoor unit main PCB	297
	P1	●	Power supply voltage imbalance	299
	P3	●	Reactor temperature abnormality	301
	P4 (*1)	●	Inverter radiation fin temperature abnormality	302
	PJ	●	Field setting after replacing outdoor unit main PCB abnormality or combination of PCB abnormality	304
System	U0 (*1)	○	Refrigerant shortage	305
	U1	●	Reverse phase, open phase	306
	U2	●	Power supply insufficient or instantaneous abnormality	307
	U3	●	Check operation not executed	310
	U4	●	Transmission error between indoor units and outdoor units	311
	U5	●	Transmission error between remote controller and indoor unit	314
	U7	●	Transmission error between outdoor units	315
	U8	●	Transmission error between main and sub remote controllers	321
	U9	●	Transmission error between indoor unit and outdoor unit in the same system	322
	UA	●	Improper combination of indoor unit and outdoor unit, indoor unit and remote controller	323
			Incorrect gas furnace connecting number	328
			Incorrect electric heater capacity setting	329
	UC (*1)	○	Address duplication of centralized controller	330
	UE	●	Transmission error between centralized controller and indoor unit	331
	UF	●	System not set yet	334
UH	●	System abnormality, refrigerant system address undefined	335	
		Climate Talk communication system combination error (before initial setting for communication completes)	337	
		Climate Talk communication system combination error (after initial setting for communication completes)	338	



- Notes:**
- *1. The system can keep operating, however, be sure to check and repair.
 - *2. The system may or may not continue operation depending on the conditions.

3.2 Error Codes - Sub Codes

If an error code like the one shown below is displayed when the navigation remote controller (BRC1E series) is in use, make a detailed diagnosis or a diagnosis of the relevant unit.

3.2.1 Indoor Unit

Error code	Troubleshooting	
	Description of error	Diagnosis
A0 - 01	External protection device abnormality	Refer to page 220.
A6 - 01	Fan motor locked	A locked fan motor current has been detected. Turn the fan by hand to check for the connection of connectors.
A6 - 10	Fan overcurrent error	A fan motor overcurrent has been detected. Check for the connection of the connector between the fan motor and the fan PCB. If the connection is normal, replace the fan motor. If this still cannot solve the error, replace the fan PCB.
A6 - 11	Fan position detection error	An error in the detection of position of the fan motor. Check for the connection of the connector between the fan motor and the fan PCB. If the connection is normal, replace the fan motor. If this still cannot solve the error, replace the fan PCB.
A6 - 20	Indoor fan motor status abnormality	Refer to page 232.
A6 - 21	Indoor fan motor insufficient airflow abnormality	Refer to page 233.
A8 - 01	Power supply voltage error	Check for the input voltage of the fan motor.
A9 - 01	Electronic expansion valve error	There is an error in the electronic expansion valve coil or a connector disconnected.
A9 - 02	Refrigerant leakage detection error	Refrigerant leaks even if the electronic expansion valve is closed. Replace the electronic expansion valve.
AA - 03	Gas furnace abnormality	Refer to page 239.
AH - 03	Transmission error (between the self-cleaning decoration panel and the indoor unit) (when the self-cleaning decoration panel is mounted)	Check for the connection of the harness connector between the panel PCB and the indoor unit PCB.
AH - 04	Dust detection sensor error (when the self-cleaning decoration panel is mounted)	Check for the connections of the connector X12A on the panel PCB and the connectors X18A and X19A on the sensor PCB.
AH - 05	Dust collection sign error (when the self-cleaning decoration panel is mounted)	Check for clogging with dust at the dust collection port as well as in the brush unit, S-shaped pipe, and dust box. Furthermore, check for any stains of the light receiving and emitting parts of the infrared unit.
AH - 06	Air filter rotation error (when the self-cleaning decoration panel is mounted)	Check for anything getting in the way of rotating the filter (e.g. the filter comes off or the drive gear is clogged with foreign matter).
AH - 07	Damper rotation error (when the self-cleaning decoration panel is mounted)	The damper does not rotate normally. Check for any foreign matter around the damper and for the operation of the gear and limit switch.
AH - 08	Filter self-cleaning operation error (when the self-cleaning decoration panel is mounted)	The unit has not yet completed the filter self-cleaning operation even after the lapse of specified period of time. Check for any external noise, etc.
AH - 09	Filter self-cleaning operation start disabled error (when the self-cleaning decoration panel is mounted)	The unit has been put into a state in which the filter self-cleaning operation is disabled. Check the unit for the operating conditions.
AJ - 01	Capacity setting error	There is an error in the capacity setting of the indoor unit PCB.
AJ - 02	Electronic expansion valve setting error	There is a fault in the setting of the gear type electronic expansion valve/direct acting type electronic expansion valve.
C1 - 01	Transmission abnormality between indoor unit PCB and fan PCB	Check for the conditions of transmission between the indoor unit PCB and the fan PCB.
C1 - 07	Blower motor communication error	Refer to page 244.
C1 - 08	Climate Talk Communication error	Refer to page 245.
C6 - 01	Defective combination of indoor unit PCB and the fan PCB Blower motor HP mismatch	A combination of indoor unit PCB and the fan PCB is defective. Check whether the capacity setting adaptor is correct and the type of the fan PCB is correct.
C6 - 02	Indoor blower does not have required parameters to function	Refer to page 249.
U4 - 01	Indoor-outdoor transmission error	Refer to the U4 flow chart.
UA - 13	Refrigerant type error	The type of refrigerant used for the indoor unit is different from that used for the outdoor unit.
UA - 15	Not applicable for self-cleaning decoration panel [when the self-cleaning decoration panel is mounted]	An outdoor unit is not applicable for the self-cleaning decoration panel is connected.
UA - 17	Incorrect electric heater capacity setting	Refer to page 329.

Error code	Troubleshooting	
	Description of error	Diagnosis
UH - 05	Climate Talk Communication system combination error (before initial setting for communication completes)	Refer to page 337.
UH - 06	Climate Talk Communication system combination error (after initial setting for communication completes)	

3.2.2 Outdoor Unit

Error code	Troubleshooting	
	Description of error	Diagnosis
E1 - 01 E1 - 02	Outdoor unit main PCB error Defective outdoor unit main PCB	Refer to the E1 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
E2 - 01 E2 - 02 E2 - 03 E2 - 06 E2 - 07 E2 - 08	Ground leakage detection error (Master) Ground leakage detection error (Slave 1) Ground leakage detection error (Slave 2) Missing of ground leakage detection core (Master) Missing of ground leakage detection core (Slave 1) Missing of ground leakage detection core (Slave 2)	
E3 - 01 E3 - 02 E3 - 03 E3 - 04 E3 - 05 E3 - 06 E3 - 13 E3 - 14 E3 - 15 E3 - 18	Activation of high pressure switch (Master) Activation of high pressure switch (Slave 1) Activation of high pressure switch (Slave 2) Liquid stop valve check error (Master) Liquid stop valve check error (Slave 1) Liquid stop valve check error (Slave 2) Overall retry of high pressure switch	Refer to the E3 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
E4 - 01 E4 - 02 E4 - 03	Low pressure sensor error (Master) Low pressure sensor error (Slave 1) Low pressure sensor error (Slave 2)	
E5 - 01 E5 - 02 E5 - 03 E5 - 07 E5 - 08 E5 - 09	Compressor M1C lock (Master) Compressor M1C lock (Slave 1) Compressor M1C lock (Slave 2) Compressor M2C lock (Master) Compressor M2C lock (Slave 1) Compressor M2C lock (Slave 2)	Refer to the E5 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.

Error code	Troubleshooting	
	Description of error	Diagnosis
E7 - 01	Fan motor M1F lock (Master)	Make a diagnosis of the fan motor of the relevant unit based on the following. Fan motor lock: 01, 02, 13, 14, 25, 26 Momentary overcurrent: 05, 06, 17, 18, 29, 30 IPM error: 09, 10, 21, 22, 33, 34
E7 - 02	Fan motor M2F lock (Master)	
E7 - 05	Fan motor M1F momentary overcurrent (Master)	
E7 - 06	Fan motor M2F momentary overcurrent (Master)	
E7 - 09	Fan motor M1F IPM error (Master)	
E7 - 10	Fan motor M2F IPM error (Master)	
E7 - 13	Fan motor M1F lock (Slave 1)	
E7 - 14	Fan motor M2F lock (Slave 1)	
E7 - 17	Fan motor M1F momentary overcurrent (Slave 1)	
E7 - 18	Fan motor M2F momentary overcurrent (Slave 1)	
E7 - 21	Fan motor M1F IPM error (Slave 1)	
E7 - 22	Fan motor M2F IPM error (Slave 1)	
E7 - 25	Fan motor M1F lock (Slave 2)	
E7 - 26	Fan motor M2F lock (Slave 2)	
E7 - 29	Fan motor M1F momentary overcurrent (Slave 2)	
E7 - 30	Fan motor M2F momentary overcurrent (Slave 2)	
E7 - 33	Fan motor M1F IPM error (Slave 2)	
E7 - 34	Fan motor M2F IPM error (Slave 2)	
E9 - 01	Electronic expansion valve coil (Y2E) error (Master)	Refer to the E9 flowchart and make a diagnosis of the relevant electronic expansion valve of the relevant unit based on the Error code shown to the left.
E9 - 04	Electronic expansion valve coil (Y1E) error (Master)	
E9 - 05	Electronic expansion valve coil (Y2E) error (Slave 1)	
E9 - 07	Electronic expansion valve coil (Y1E) error (Slave 1)	
E9 - 08	Electronic expansion valve coil (Y2E) error (Slave 2)	
E9 - 10	Electronic expansion valve coil (Y1E) error (Slave 2)	
E9 - 20	Defective electronic expansion valve coil (Y1E) (Master)	
E9 - 21	Defective electronic expansion valve coil (Y1E) (Slave 1)	
E9 - 22	Defective electronic expansion valve coil (Y1E) (Slave 2)	
E9 - 23	Defective electronic expansion valve coil (Y2E) (Master)	
E9 - 24	Defective electronic expansion valve coil (Y2E) (Slave 1)	
E9 - 25	Defective electronic expansion valve coil (Y2E) (Slave 2)	
F3 - 01	Discharge pipe high temperature error (Master)	Refer to the F3 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
F3 - 03	Discharge pipe high temperature error (Slave 1)	
F3 - 05	Discharge pipe high temperature error (Slave 2)	
F3 - 20	Compressor overheat error (Master)	
F3 - 21	Compressor overheat error (Slave 1)	
F3 - 22	Compressor overheat error (Slave 2)	

Error code	Troubleshooting	
	Description of error	Diagnosis
F4 - 01	Wet alarm	Refer to the F4 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
F4 - 02	Wet alarm for compressor M1C (Master)	
F4 - 03	Wet alarm for compressor M2C (Master)	
F4 - 04	Wet alarm for compressor M1C (Slave 1)	
F4 - 05	Wet alarm for compressor M2C (Slave 1)	
F4 - 06	Wet alarm for compressor M1C (Slave 2)	
F4 - 07	Wet alarm for compressor M2C (Slave 2)	
F4 - 08	Wet error for compressor M1C (Master)	
F4 - 09	Wet error for compressor M2C (Master)	
F4 - 10	Wet error for compressor M1C (Slave 1)	
F4 - 11	Wet error for compressor M2C (Slave 1)	
F4 - 12	Wet error for compressor M1C (Slave 2)	
F4 - 13	Wet error for compressor M2C (Slave 2)	
F4 - 14	Indoor unit failure alarm	
F6 - 02	Refrigerant overcharged	Refrigerant overcharge was detected during test operation.
H3 - 02	Harness abnormality (Main & inverter PCB (A3P)) - Master unit	Refer to the H3 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
H3 - 03	Harness abnormality (Main & inverter PCB (A6P)) - Master unit	
H3 - 04	Harness abnormality (Main & inverter PCB (A3P)) - Slave unit 1	
H3 - 05	Harness abnormality (Main & inverter PCB (A6P)) - Slave unit 1	
H3 - 06	Harness abnormality (Main & inverter PCB (A3P)) - Slave unit 2	
H3 - 07	Harness abnormality (Main & inverter PCB (A6P)) - Slave unit 2	
H7 - 01	Motor position signal abnormality (Master): M1F	Refer to the H7 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
H7 - 02	Motor position signal abnormality (Master): M2F	
H7 - 05	Motor position signal abnormality (Slave 1): M1F	
H7 - 06	Motor position signal abnormality (Slave 1): M2F	
H7 - 09	Motor position signal abnormality (Slave 2): M1F	
H7 - 10	Motor position signal abnormality (Slave 2): M2F	
H9 - 01	Defective outdoor air thermistor (R1T) (Master)	Refer to the H9 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
H9 - 02	Defective outdoor air thermistor (R1T) (Slave 1)	
H9 - 03	Defective outdoor air thermistor (R1T) (Slave 2)	

Error code	Troubleshooting		
	Description of error	Diagnosis	
J3 - 16	Defective discharge pipe thermistor (R21T): Open (Master)	Refer to the J3 flowchart and make a diagnosis of the relevant thermistor of the relevant unit based on the Error code shown to the left.	
J3 - 17	Defective discharge pipe thermistor (R21T): Short (Master)		
J3 - 18	Defective discharge pipe thermistor (R22T): Open (Master)		
J3 - 19	Defective discharge pipe thermistor (R22T): Short (Master)		
J3 - 22	Defective discharge pipe thermistor (R21T): Open (Slave 1)		
J3 - 23	Defective discharge pipe thermistor (R21T): Short (Slave 1)		
J3 - 24	Defective discharge pipe thermistor (R22T): Open (Slave 1)		
J3 - 25	Defective discharge pipe thermistor (R22T): Short (Slave 1)		
J3 - 28	Defective discharge pipe thermistor (R21T): Open (Slave 2)		
J3 - 29	Defective discharge pipe thermistor (R21T): Short (Slave 2)		
J3 - 30	Defective discharge pipe thermistor (R22T): Open (Slave 2)		
J3 - 31	Defective discharge pipe thermistor (R22T): Short (Slave 2)		
J3 - 47	Defective compressor body thermistor (R8T): Open (Master)		
J3 - 48	Defective compressor body thermistor (R8T): Short (Master)		
J3 - 49	Defective compressor body thermistor (R8T): Open (Slave 1)		
J3 - 50	Defective compressor body thermistor (R8T): Short (Slave 1)		
J3 - 51	Defective compressor body thermistor (R8T): Open (Slave 2)		
J3 - 52	Defective compressor body thermistor (R8T): Short (Slave 2)		
J3 - 56	Discharge pipe warning (Master)		
J3 - 57	Discharge pipe warning (Slave 1)		
J3 - 58	Discharge pipe warning (Slave 2)		
J5 - 01	Defective accumulator inlet thermistor (R3T) (Master)		Refer to the J5 flowchart and make a diagnosis of the relevant thermistor of the relevant unit based on the Error code shown to the left.
J5 - 03	Defective accumulator inlet thermistor (R3T) (Slave 1)		
J5 - 05	Defective accumulator inlet thermistor (R3T) (Slave 2)		
J5 - 15	Error detection of accumulator inlet thermistor (R3T) (Master)		
J5 - 16	Error detection of accumulator inlet thermistor (R3T) (Slave 1)		
J5 - 17	Error detection of accumulator inlet thermistor (R3T) (Slave 2)		
J6 - 01	Defective heat exchanger deicer thermistor (R7T) (Master)		Refer to the J6 flowchart and make a diagnosis of the relevant thermistor of the relevant unit based on the Error code shown to the left.
J6 - 02	Defective heat exchanger deicer thermistor (R7T) (Slave 1)		
J6 - 03	Defective heat exchanger deicer thermistor (R7T) (Slave 2)		

Error code	Troubleshooting	
	Description of error	Diagnosis
J7 - 06	Defective subcooling heat exchanger liquid pipe thermistor (R5T) (Master)	Refer to the J7 flowchart and make a diagnosis of the relevant thermistor of the relevant unit based on the Error code shown to the left.
J7 - 07	Defective subcooling heat exchanger liquid pipe thermistor (R5T) (Slave 1)	
J7 - 08	Defective subcooling heat exchanger liquid pipe thermistor (R5T) (Slave 2)	
J8 - 01	Defective heat exchanger liquid pipe thermistor (R4T) (Master)	Refer to the J8 flowchart and make a diagnosis of the relevant thermistor of the relevant unit based on the Error code shown to the left.
J8 - 02	Defective heat exchanger liquid pipe thermistor (R4T) (Slave 1)	
J8 - 03	Defective heat exchanger liquid pipe thermistor (R4T) (Slave 2)	
J9 - 01	Defective subcooling heat exchanger gas pipe thermistor (R6T) (Master)	Refer to the J9 flowchart and make a diagnosis of the relevant thermistor of the relevant unit based on the Error code shown to the left.
J9 - 02	Defective subcooling heat exchanger gas pipe thermistor (R6T) (Slave 1)	
J9 - 03	Defective subcooling heat exchanger gas pipe thermistor (R6T) (Slave 2)	
J9 - 08	Error detection of subcooling heat exchanger gas pipe thermistor (R6T) (Master)	
J9 - 09	Error detection of subcooling heat exchanger gas pipe thermistor (R6T) (Slave 1)	
J9 - 10	Error detection of subcooling heat exchanger gas pipe thermistor (R6T) (Slave 2)	
JA - 06	Defective high pressure sensor (S1NPH): Open (Master)	Refer to the JA flowchart and make a diagnosis of the relevant sensor based on the Error code shown to the left.
JA - 07	Defective high pressure sensor (S1NPH): Short (Master)	
JA - 08	Defective high pressure sensor (S1NPH): Open (Slave 1)	
JA - 09	Defective high pressure sensor (S1NPH): Short (Slave 1)	
JA - 10	Defective high pressure sensor (S1NPH): Open (Slave 2)	
JA - 11	Defective high pressure sensor (S1NPH): Short (Slave 2)	
JC - 06	Defective low pressure sensor (S1NPL): Open (Master)	Refer to the JC flowchart and make a diagnosis of the relevant sensor based on the Error code shown to the left.
JC - 07	Defective low pressure sensor (S1NPL): Short (Master)	
JC - 08	Defective low pressure sensor (S1NPL): Open (Slave 1)	
JC - 09	Defective low pressure sensor (S1NPL): Short (Slave 1)	
JC - 10	Defective low pressure sensor (S1NPL): Open (Slave 2)	
JC - 11	Defective low pressure sensor (S1NPL): Short (Slave 2)	

Error code	Troubleshooting	
	Description of error	Diagnosis
L1 - 01	Instantaneous overcurrent - Compressor M1C (Master)	Refer to the L1 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
L1 - 02	Defective current sensor 1 - Compressor M1C (Master)	
L1 - 03	Defective current sensor 2 - Compressor M1C (Master)	
L1 - 04	Defective power transistors - Compressor M1C (Master)	
L1 - 05	Jumper settings Inverter - Compressor M1C (Master)	
L1 - 07	Instantaneous overcurrent - Compressor M1C (Slave 1)	
L1 - 08	Defective current sensor 1 - Compressor M1C (Slave 1)	
L1 - 09	Defective current sensor 2 - Compressor M1C (Slave 1)	
L1 - 10	Defective power transistors - Compressor M1C (Slave 1)	
L1 - 11	Instantaneous overcurrent - Compressor M1C (Slave 2)	
L1 - 12	Defective current sensor 1 - Compressor M1C (Slave 2)	
L1 - 13	Defective current sensor 2 - Compressor M1C (Slave 2)	
L1 - 14	Defective power transistors - Compressor M1C (Slave 2)	
L1 - 15	Jumper settings inverter - Compressor M1C (Slave 1)	
L1 - 16	Jumper settings inverter - Compressor M1C (Slave 2)	
L1 - 17	Instantaneous overcurrent - Compressor M2C (Master)	
L1 - 18	Defective current sensor 1 - Compressor M2C (Master)	
L1 - 19	Defective current sensor 2 - Compressor M2C (Master)	
L1 - 20	Defective power transistors - Compressor M2C (Master)	
L1 - 21	Jumper settings Inverter - Compressor M2C (Master)	
L1 - 22	Instantaneous overcurrent - Compressor M2C (Slave 1)	
L1 - 23	Defective current sensor 1 - Compressor M2C (Slave 1)	
L1 - 24	Defective current sensor 2 - Compressor M2C (Slave 1)	
L1 - 25	Defective power transistors - Compressor M2C (Slave 1)	
L1 - 26	Jumper settings inverter - Compressor M2C (Slave 1)	
L1 - 28	Defective inverter fan motor M1F ROM (Master)	
L1 - 29	Defective inverter fan motor M2F ROM (Master)	
L1 - 32	Defective inverter fan motor M1F ROM (Slave 1)	
L1 - 33	Defective inverter fan motor M2F ROM (Slave 1)	
L1 - 34	Defective inverter fan motor M1F ROM (Slave 2)	
L1 - 35	Defective inverter fan motor M2F ROM (Slave 2)	
L1 - 36	Defective compressor M1C ROM (Master)	
L1 - 37	Defective compressor M2C ROM (Master)	
L1 - 38	Defective compressor M1C ROM (Slave 1)	
L1 - 39	Defective compressor M2C ROM (Slave 1)	
L1 - 40	Defective compressor M1C ROM (Slave 2)	
L1 - 41	Defective compressor M2C ROM (Slave 2)	
L1 - 42	Instantaneous overcurrent - Compressor M2C (Slave 2)	
L1 - 43	Defective current sensor 1 - Compressor M2C (Slave 2)	
L1 - 44	Defective current sensor 2 - Compressor M2C (Slave 2)	
L1 - 45	Defective power transistors - Compressor M2C (Slave 2)	
L1 - 46	Jumper settings inverter - Compressor M2C (Slave 2)	
L1 - 47	Power supply compressor M1C error (Master)	
L1 - 48	Power supply compressor M2C error (Master)	
L1 - 49	Power supply compressor M1C error (Slave 1)	
L1 - 50	Power supply compressor M2C error (Slave 1)	
L1 - 51	Power supply compressor M1C error (Slave 2)	
L1 - 52	Power supply compressor M2C error (Slave 2)	

Error code	Troubleshooting	
	Description of error	Diagnosis
L4 - 01	Radiation fin temperature rise: Inverter PCB (A3P) (Master)	Refer to the L4 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
L4 - 02	Radiation fin temperature rise: Inverter PCB (A3P) (Slave 1)	
L4 - 03	Radiation fin temperature rise: Inverter PCB (A3P) (Slave 2)	
L4 - 09	Radiation fin temperature rise: Inverter PCB (A6P) (Master)	
L4 - 10	Radiation fin temperature rise: Inverter PCB (A6P) (Slave 1)	
L4 - 11	Radiation fin temperature rise: Inverter PCB (A6P) (Slave 2)	
L5 - 03	Compressor M1C momentary overcurrent (Master)	Refer to the L5 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
L5 - 05	Compressor M1C momentary overcurrent (Slave 1)	
L5 - 07	Compressor M1C momentary overcurrent (Slave 2)	
L5 - 14	Compressor M2C momentary overcurrent (Master)	
L5 - 15	Compressor M2C momentary overcurrent (Slave 1)	
L5 - 16	Compressor M2C momentary overcurrent (Slave 2)	
L8 - 03	Compressor M1C overcurrent (Master)	Refer to the L8 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
L8 - 06	Compressor M1C overcurrent (Slave 1)	
L8 - 07	Compressor M1C overcurrent (Slave 2)	
L8 - 11	Compressor M2C overcurrent (Master)	
L8 - 12	Compressor M2C overcurrent (Slave 1)	
L8 - 13	Compressor M2C overcurrent (Slave 2)	
L9 - 01	Compressor M1C startup error (Master)	Refer to the L9 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
L9 - 05	Compressor M1C startup error (Slave 1)	
L9 - 06	Compressor M1C startup error (Slave 2)	
L9 - 10	Compressor M2C startup error (Master)	
L9 - 11	Compressor M2C startup error (Slave 1)	
L9 - 12	Compressor M2C startup error (Slave 2)	

Error code	Troubleshooting	
	Description of error	Diagnosis
LC - 14	Transmission error (Between outdoor units, inverter PCB (A3P)) (Master)	Refer to the LC flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
LC - 15	Transmission error (Between outdoor units, inverter PCB (A3P)) (Slave 1)	
LC - 16	Transmission error (Between outdoor units, inverter PCB (A3P)) (Slave 2)	
LC - 19	Transmission error (Between outdoor units, fan PCB) (Master): M1F	
LC - 20	Transmission error (Between outdoor units, fan PCB) (Slave 1): M1F	
LC - 21	Transmission error (Between outdoor units, fan PCB) (Slave 2): M1F	
LC - 24	Transmission error (Between outdoor units, fan PCB) (Master): M2F	
LC - 25	Transmission error (Between outdoor units, fan PCB) (Slave 1): M2F	
LC - 26	Transmission error (Between outdoor units, fan PCB) (Slave 2): M2F	
LC - 30	Transmission error (Between outdoor units, inverter PCB (A6P)) (Master)	
LC - 31	Transmission error (Between outdoor units, inverter PCB (A6P)) (Slave 1)	
LC - 32	Transmission error (Between outdoor units, inverter PCB (A6P)) (Slave 2)	
LC - 33	Transmission error (Between outdoor units, sub PCB) "EKBPBPCBT7" (Master) or set 2-52-2 without sub PCB	
LC - 34	Transmission error (Between outdoor units, sub PCB) "EKBPBPCBT7" (Slave 1) or set 2-52-2 without sub PCB	
LC - 35	Transmission error (Between outdoor units, sub PCB) "EKBPBPCBT7" (Slave 2) or set 2-52-2 without sub PCB	
P1 - 01	Inverter 1 power supply unbalanced voltage (Master)	Refer to the P1 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
P1 - 02	Inverter 1 power supply unbalanced voltage (Slave 1)	
P1 - 03	Inverter 1 power supply unbalanced voltage (Slave 2)	
P1 - 07	Inverter 2 power supply unbalanced voltage (Master)	
P1 - 08	Inverter 2 power supply unbalanced voltage (Slave 1)	
P1 - 09	Inverter 2 power supply unbalanced voltage (Slave 2)	
P3 - 01	Defective reactor thermistor 1 (Master: Inverter PCB (A3P))	Refer to the P3 flowchart and make a diagnosis of the relevant thermistor based on the Error code shown to the left.
P3 - 02	Defective reactor thermistor 1 (Slave 1: Inverter PCB (A3P))	
P3 - 03	Defective reactor thermistor 1 (Slave 2: Inverter PCB (A3P))	
P3 - 04	Defective reactor thermistor 2 (Master: Inverter PCB (A3P))	
P3 - 05	Defective reactor thermistor 2 (Slave 1: Inverter PCB (A3P))	
P3 - 06	Defective reactor thermistor 2 (Slave 2: Inverter PCB (A3P))	
P3 - 07	Defective reactor thermistor 1 (Master: Inverter PCB (A6P))	
P3 - 08	Defective reactor thermistor 1 (Slave 1: Inverter PCB (A6P))	
P3 - 09	Defective reactor thermistor 1 (Slave 2: Inverter PCB (A6P))	
P3 - 10	Defective reactor thermistor 2 (Master: Inverter PCB (A6P))	
P3 - 11	Defective reactor thermistor 2 (Slave 1: Inverter PCB (A6P))	
P3 - 12	Defective reactor thermistor 2 (Slave 2: Inverter PCB (A6P))	

Error code	Troubleshooting	
	Description of error	Diagnosis
P4 - 01	Defective Radiation fin thermistor (Master: Inverter PCB (A3P))	Refer to the P4 flowchart and make a diagnosis of the relevant sensor based on the Error code shown to the left.
P4 - 04	Defective Radiation fin thermistor (Slave 1: Inverter PCB (A3P))	
P4 - 05	Defective Radiation fin thermistor (Slave 2: Inverter PCB (A3P))	
P4 - 06	Defective Radiation fin thermistor (Master: Inverter PCB (A6P))	
P4 - 07	Defective Radiation fin thermistor (Slave 1: Inverter PCB (A6P))	
P4 - 08	Defective Radiation fin thermistor (Slave 2: Inverter PCB (A6P))	
PJ - 04	Incorrect type of inverter PCB (A3P) (Master)	Refer to the PJ flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
PJ - 05	Incorrect type of inverter PCB (A3P) (Slave 1)	
PJ - 06	Incorrect type of inverter PCB (A3P) (Slave 2)	
PJ - 09	Incorrect type of fan PCB 1 (Master)	
PJ - 10	Incorrect type of fan PCB 2 (Master)	
PJ - 12	Incorrect type of inverter PCB (A6P) (Master)	
PJ - 13	Incorrect type of inverter PCB (A6P) (Slave 1)	
PJ - 14	Incorrect type of inverter PCB (A6P) (Slave 2)	
PJ - 15	Incorrect type of fan PCB 1 (Slave 1)	
PJ - 16	Incorrect type of fan PCB 1 (Slave 2)	
PJ - 17	Incorrect type of fan PCB 2 (Slave 1)	
PJ - 18	Incorrect type of fan PCB 2 (Slave 2)	
U0 - 05	Refrigerant shortage warning (cooling)	Refer to the U0 flowchart and make a diagnosis based on the Error code shown to the left.
U0 - 06	Refrigerant shortage warning (heating)	
U0 - 08	Refrigerant shortage (Master)	
U0 - 09	Refrigerant shortage (Slave 1)	
U0 - 10	Refrigerant shortage (Slave 2)	
U1 - 01	Reverse phase/open phase of power supply (Master)	Refer to the U1 flowchart and make a diagnosis of the relevant unit based on the Error code shown to the left.
U1 - 04	Reverse phase/open phase of power supply (when power ON) (Master)	
U1 - 05	Reverse phase/open phase of power supply (Slave 1)	
U1 - 06	Reverse phase/open phase of power supply (when power ON) (Slave 1)	
U1 - 07	Reverse phase/open phase of power supply (Slave 2)	
U1 - 08	Reverse phase/open phase of power supply (when power ON) (Slave 2)	

Error code	Troubleshooting		
	Description of error	Diagnosis	
U2 - 01	Shortage of inverter 1 power supply voltage (Master)	<p>Make a diagnosis of the relevant unit based on the following.</p> <p>Shortage of power supply voltage If the other units detect shortage of power supply voltage, power supply voltage during operation may be unstable. Check the power supply condition. If a particular unit detects the error, operation of 52C may be defective. Follow the U2 flowchart.</p> <p>Open phase of power supply The wiring between power supply and inverter PCB may be disconnected. Check that power supply is connected to terminal block, terminal block is connected to PCB without broken wire or disconnection, and reactor wiring is secured. If no abnormality is found, follow the U2 flowchart.</p> <p>Defective capacitor in main circuit P-N on the inverter PCB (electrolytic capacitor, power module) may be damaged and short circuited. Operation of current limiting relay may be defective or the wiring between the reactor and PCB may be disconnected. Measure the resistance between P-N on the inverter PCB and check for short circuit. If no abnormality is found, follow the U2 flowchart.</p>	
U2 - 02	Open phase of inverter 1 power supply (Master)		
U2 - 03	Defective capacitor in inverter 1 main circuit (Master)		
U2 - 08	Shortage of inverter 1 power supply voltage (Slave 1)		
U2 - 09	Open phase of inverter 1 power supply (Slave 1)		
U2 - 10	Defective capacitor in inverter 1 main circuit (Slave 1)		
U2 - 11	Shortage of inverter 1 power supply voltage (Slave 2)		
U2 - 12	Open phase of inverter 1 power supply (Slave 2)		
U2 - 13	Defective capacitor in inverter 1 main circuit (Slave 2)		
U2 - 22	Shortage of inverter 2 power supply voltage (Master)		
U2 - 23	Open phase of inverter 2 power supply (Master)		
U2 - 24	Defective capacitor in inverter 2 main circuit (Master)		
U2 - 25	Shortage of inverter 2 power supply voltage (Slave 1)		
U2 - 26	Open phase of inverter 2 power supply (Slave 1)		
U2 - 27	Defective capacitor in inverter 2 main circuit (Slave 1)		
U2 - 28	Shortage of inverter 2 power supply voltage (Slave 2)		
U2 - 29	Open phase of inverter 2 power supply (Slave 2)		
U2 - 30	Defective capacitor in inverter 2 main circuit (Slave 2)		
U3 - 02	Initial installation warning		<p>Refer to the U3 flowchart and make a diagnosis based on the Error code shown to the left.</p>
U3 - 03	Test operation not conducted		
U3 - 04	Abnormal end of test operation		
U3 - 05	Premature end of test operation during initial transmission error		
U3 - 06	Premature end of test operation during normal transmission error		
U3 - 07	Premature end of test operation due to transmission error of either unit		
U3 - 08	Premature end of test operation due to transmission error of all units		
U4 - 01	Transmission error between indoor unit and outdoor unit		
U4 - 03	Transmission error between indoor unit and system		
U7 - 01	Error when external control adaptor for outdoor unit is installed		<p>Refer to the U7 flowchart and make a diagnosis based on the Error code shown to the left.</p>
U7 - 02	Warning when external control adaptor for outdoor unit is installed		
U7 - 03	Transmission error between master and slave 1 units		
U7 - 04	Transmission error between master and slave 2 units		
U7 - 05	Multi system error		
U7 - 06	Error in address settings of slave 1 and 2		
U7 - 07	Connection of four or more outdoor units in the same system		
U7 - 11	Error in indoor unit connection capacity for test operation		
U9 - 01	Other indoor units abnormality	<p>Refer to the U9 flowchart and make a diagnosis based on the Error code shown to the left.</p>	

Error code	Troubleshooting	
	Description of error	Diagnosis
UA - 17	Incorrect electric heater capacity setting (FXTQ-TA)	Refer to page 328. Refer to the UA flowchart and make a diagnosis based on the Error code shown to the left.
UA - 18	Connection of excessive indoor units	
UA - 20	Connection of wrong models of indoor units	
UA - 21	Improper combination of outdoor units	
UA - 29	Connection error	
UA - 38	Branch selector unit connected	
UA - 39	Daikin Altherma indoor unit detected	
UA - 50	Other hydrobox type than HXY-A unit detected	
UA - 51	RA connected to BP units and HXY-A unit detected	
UA - 51	Only HXY-A unit(s) connected, minimum 50% DX indoor need	
UF - 01	Wrong wiring check error	Refer to the UF flowchart and make a diagnosis based on the Error code shown to the left.
UF - 05	Defective stop valve for test operation	
UH - 01	Wiring error	Refer to the UH flowchart and make a diagnosis based on the Error code shown to the left.

Caution code	Description of caution
P2	Auto charge more than 5 minutes t03 blinking
P8	Auto charge abnormal end freeze up indoor
PE	Auto charge nearly terminated
P9	Auto charge normal terminated
E-1	Conditions not met to perform leak test
E-2	Indoor air average below 10°C (50°F) or above 32°C (90°F) for leak test Indoor air average below 20°C (68°F) or above 32°C (90°F) for test operation
E-3	Outdoor air below 0°C (32°F) or above 43°C (109°F) for leak test or test operation
E-4	Abnormal low pressure during leak test
E-5	Some indoor not compatible for leak test

3.3 External Protection Device Abnormality


3.3.1 External Protection Device Abnormality (All Indoor Unit Models)

Error Code	A0
Applicable Models	All indoor unit models
Method of Error Detection	Detect open or short circuit between external input terminals in indoor unit.
Error Decision Conditions	When an open circuit occurs between external input terminals with the remote controller set to "external ON/OFF terminal".
Supposed Causes	<ul style="list-style-type: none"> ■ Activation of external protection device ■ Improper field setting ■ Defective indoor unit PCB

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.3.2 External Protection Device Abnormality (FXTQ-TA and CXTQ-TA Only)

Error Code	A0-01
Applicable Models	FXTQ-TA, CXTQ-TA
Method of Error Detection	Detect open or short circuit between external input terminals in indoor unit.
Error Decision Conditions	When an open circuit occurs between external input terminals.
Supposed Causes	<ul style="list-style-type: none"> ■ Activation of external protection device ■ Defective indoor unit PCB ■ Indoor unit fuse blown ■ 24 VAC power is not supplied to TH2 and TR2 terminals (FXTQ-TA) or R and C terminals (CXTQ-TA) on the indoor unit PCB.

Troubleshooting


Caution


Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



3.4 Indoor Unit PCB Abnormality

Error Code	A1
Applicable Models	All indoor unit models
Method of Error Detection	Check data from EEPROM.
Error Decision Conditions	When data could not be correctly received from the EEPROM EEPROM : Type of nonvolatile memory. Maintains memory contents even when the power supply is turned OFF.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective indoor unit PCB ■ External factor (Noise etc.)

Troubleshooting



3.5 Drain Level Control System Abnormality

Error Code

A3

Applicable Models

FXFQ-T, FXZQ-TA, FXUQ-P, FXEQ-P, FXDQ-M, FXSQ-TA, FXMQ-PB

Method of Error Detection

By float switch OFF detection

Error Decision Conditions

When rise of water level is not a condition and the float switch goes OFF.

Supposed Causes


- 208~230 V power supply is not provided
- Defective float switch or short circuit connector
- Defective drain pump
- Drain clogging, upward slope, etc.
- Defective indoor unit PCB
- Loose connection of connector


Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





i Note:

Model	*1: Float switch (S1L) / short circuit connector	*2: Drain pump (M1P) connector	*3: Drain pump (M1P) voltage
FXFQ-T	X15A	X10A	13 VDC
FXZQ-TA	X15A	X102A	13 VDC
FXUQ-P	X15A	X25A	13 VDC
FXEQ-P	X15A	X25A	13 VDC
FXDQ-M	X8A	X25A	220-240 VAC
FXSQ-TA	X15A	X25A	13 VDC
FXMQ-PB	X15A	X25A	220-240 VAC


3.6 Fan Motor Lock, Overload

Error Code	A6
Applicable Models	FXFQ-T, FXZQ-TA, FXUQ-P, FXEQ-P, FXSQ05-48TA, FXMQ07-12PB, FXAQ-P
Method of Error Detection	Abnormal fan revolutions are detected by a signal output from the fan motor.
Error Decision Conditions	When the fan revolutions do not increase
Supposed Causes	<ul style="list-style-type: none"> ■ Broken wires in, short circuit of, or disconnection of connectors from the fan motor harness ■ Defective fan motor (Broken wires or defective insulation) ■ Abnormal signal output from the fan motor (defective circuit) ■ Defective indoor unit control PCB ■ Instantaneous disturbance in the power supply voltage ■ Fan motor lock (Due to motor or external causes) ■ The fan does not rotate due to foreign matter blocking the fan. ■ Disconnection of the connector between the high-power PCB (A1P) and the low-power PCB (A2P) (FXSQ05-48TA, FXMQ07-12PB only)

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Note: *1: Check the following connectors.

Model	Connector
FXFQ-T	X20A, Relay connector
FXZQ-TA	X20A, Relay connector
FXUQ-P	X20A, Relay connector
FXEQ-P	X20A
FXSQ05-48TA	X8A
FXMQ07-12PB	X8A
FXAQ-P	X20A



CHECK 17 Refer to page 354.


3.7 Indoor Fan Motor Abnormality

3.7.1 Indoor Fan Motor Abnormality (FXDQ-M, FXHQ-M Models)

Error Code	A6
Applicable Models	FXDQ-M, FXHQ-M
Method of Error Detection	This error is detected if there is no revolutions detection signal output from the fan motor.
Error Decision Conditions	When no revolutions can be detected even at the maximum output voltage to the fan
Supposed Causes	<ul style="list-style-type: none"> ■ Defective indoor fan motor ■ Broken wires ■ Defective contact
Troubleshooting	


Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



CHECK 16 Refer to page 353.

3.7.2 Indoor Fan Motor Abnormality (FXSQ54TA, FXMQ15-54PB Models)


Error Code	A6
Applicable Models	FXSQ54TA, FXMQ15-54PB
Method of Error Detection	Error from the current flow on the fan PCB Error from the rotation speed of the fan motor in operation Error from the position signal of the fan motor Error from the current flow on the fan PCB when the fan motor starting operation
Error Decision Conditions	<ul style="list-style-type: none"> ■ An overcurrent flows. ■ The rotation speed is less than a certain level for 6 seconds. ■ A position error in the fan rotor continues for 5 seconds or more.
Supposed Causes	<ul style="list-style-type: none"> ■ The clogging of a foreign matter ■ The disconnection of the fan motor connectors (X1A and X2A) ■ The disconnection of the connectors between the indoor unit PCB (A1P) and fan PCB (A2P) ■ Defective fan PCB (A2P) ■ Defective fan motor


Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





CHECK 16 Refer to page 353.



CHECK 17 Refer to page 354.


3.8 Overload/Overcurrent/Lock of Indoor Fan Motor

Error Code	A6
Applicable Models	FXMQ-M
Method of Error Detection	This error is detected by detecting that the individual power supply for the fan turns OFF.
Error Decision Conditions	When it is not detected that the individual power supply for the indoor fan turns ON while in operation.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective power supply for the indoor fan motor ■ Clogged drain piping ■ Activation of the indoor unit safety device ■ Defective contact in the fan wiring circuit

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



3.9 Blower Motor Not Running

Error Code	A6
Applicable Models	FXTQ-TA
Outline	Error is issued if the indoor unit determines that the indoor fan motor cannot rotate.
Error Decision Conditions	<ul style="list-style-type: none"> ■ Determining successive abnormalities Checks the rotation speed at 5-second intervals using the feedback of the fan motor. If that figure falls below 50 rpm 5 times successively, it is deemed abnormal operation. If, during operation, the rotation command is stopped, the 5-second interval check is halted and the counted number will be cleared. ■ Determining long-term abnormalities Checks the rotation speed at 5-second intervals using the feedback of the fan motor. Performs rotation sampling 720 times (takes approx. one hour), and if the rotation speed falls below 50 rpm over 100 times, it is deemed abnormal operation. When the sampling reaches 720 times, the counted number will be cleared and the 720 times sampling restarts. If, during this, the rotation command is stopped, the 5-second interval check is halted, but the counted number will be kept. When the rotation command is restarted, the checks will resume.
Error Reset Conditions	Reset by remote controller
Supposed Causes	<ul style="list-style-type: none"> ■ Fan or motor obstruction ■ Power interruption (low voltage) ■ Incorrect or loose wiring
Corrective Actions	<ul style="list-style-type: none"> ■ Check for obstruction on the fan or motor. ■ Verify the input voltage at the motor. ■ Check wiring or tighten wiring connections if needed. ■ Replace the indoor unit PCB or motor.



CHECK 19 Refer to page 358.

3.10 Indoor Fan Motor Status Abnormality

Error Code	A6-20
Applicable Models	FXTQ-TA
Outline	The indoor unit periodically receives control status information from the fan motor. Error is issued when the information shows abnormality.
Error Decision Conditions	If the information shows Power Limit or Temp Limit status, it will be deemed a MOTOR LIMIT abnormal operation. (The system can keep operating.) If the information shows Motor Lost Control or Current Trip status, it will be deemed a MOTOR TRIP abnormal operation. (The system stops operating.)
Error Reset Conditions	If the indoor unit stops receiving abnormal information, the error will be cleared.
Supposed Causes	<ul style="list-style-type: none"> ■ Fan or motor obstruction ■ Blocked filters ■ Power interruption (low voltage) ■ Incorrect wiring ■ Blockage in the airflow (ductwork) or ductwork undersized ■ High loading conditions
Corrective Actions	<ul style="list-style-type: none"> ■ Check for obstruction on the fan, motor, or ductwork. ■ Clean filters. ■ Check filters, grille, duct system, heat exchanger air inlet/outlet for blockages. ■ Verify the input voltage at the motor. ■ Check wiring. ■ Replace motor.



CHECK 19 Refer to page 358.

3.11 Low Indoor Airflow

Error Code	A6-21
Applicable Models	FXTQ-TA
Outline	Error is issued if the indoor unit determines that the indoor fan motor rotation is insufficient, regardless of the rotation command from indoor unit.
Error Decision Conditions	<ul style="list-style-type: none"> ■ Determining successive abnormalities Checks the rotation speed at 5-second intervals using the feedback of the fan motor. If that figure exceeds 50 rpm and falls below 150 rpm 10 times successively, it is deemed abnormal operation. If, during operation, the rotation command is stopped, the 5-second interval check is halted and the counted number will be cleared. ■ Determining long-term abnormalities Checks the rotation speed at 5-second intervals using the feedback of the fan motor. Performs rotation sampling 720 times (takes approx. one hour), and if the rotation speed exceeds 50 rpm and falls below 150 rpm over 360 times, it is deemed abnormal operation. When the counter reaches 720 times, the counted number will be cleared and the 720 times sampling restarts. If, during this, the rotation command is stopped, the 5-second interval check is halted, but the counted number will be kept. When the rotation command is restarted, the checks will resume.
Error Reset Conditions	<ul style="list-style-type: none"> ■ Determining successive abnormalities Checks the rotation speed at 5-second intervals using the feedback of the fan motor. If that figure exceeds 150 rpm even once, the error will be cleared. ■ Determining long-term abnormalities Checks the rotation speed at 5-second intervals using the feedback of the fan motor. If that figure exceeds 150 rpm 36 times successively, the error will be cleared. At that point, the counted number and sampling number will be cleared, and the 720 times sampling starts again from the beginning.
Supposed Causes	<ul style="list-style-type: none"> ■ Fan or motor obstruction ■ Blocked filters ■ Restrictive ductwork or ductwork undersized ■ Wiring disconnected ■ Wrong outdoor and indoor combination ■ Indoor fan motor failure
Corrective Actions	<ul style="list-style-type: none"> ■ Check for obstruction on the fan or motor. ■ Check ductwork and filter for blockage. ■ Clean filters. ■ Remove obstruction. Verify all registers are fully open. ■ Check the connections and the rotation of the motor. ■ Verify the input voltage at the motor. ■ Verify ductwork is appropriately sized for system. Resize or replace ductwork if needed. ■ Replace motor.





CHECK 19 Refer to page 358.

3.12 Swing Flap Motor Abnormality

Error Code	A7
Applicable Models	FXHQ-M, FXAQ-P
Method of Error Detection	Utilizes ON/OFF of the limit switch when the motor turns.
Error Decision Conditions	When ON/OFF of the micro-switch for positioning cannot be reversed even though the swing flap motor is energized for a specified amount of time (about 30 seconds). * Error code is displayed but the system operates continuously.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective swing motor ■ Defective connection cable (power supply and limit switch) ■ Defective airflow direction adjusting flap-cam ■ Defective indoor unit control PCB

Troubleshooting






Model	*1: Swing motor connector	*2: Swing motor
FXHQ-M	X6A	M1S
FXAQ-P	X36A	M1S

3.13 Power Supply Voltage Abnormality

Error Code	A8
Applicable Models	FXSQ-TA, FXMQ-PB
Method of Error Detection	Error is detected by checking the input voltage of fan motor.
Error Decision Conditions	When the input voltage of fan motor is 150 V or less, or 386 V or more.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective power supply voltage ■ Defective connection on signal line ■ Defective wiring ■ Instantaneous power failure, others

Troubleshooting



3.14 Blower Motor Stops for Over/Under Voltage

Error Code	A8
Applicable Models	FXTQ-TA
Outline	The indoor unit periodically receives control status information from the fan motor. Error is issued when the information shows abnormality.
Error Decision Conditions	If the information shows Over/Under Voltage status, it will be deemed a MOTOR VOLTS abnormal operation.
Error Reset Conditions	If the information is normal, the error will be cleared.
Supposed Causes	<ul style="list-style-type: none"> ■ High AC line voltage to indoor blower motor ■ Low AC line voltage to indoor blower motor ■ Incorrect wiring
Corrective Actions	<ul style="list-style-type: none"> ■ Verify line voltage to indoor blower motor is within the range specified on the ID blower rating plate. ■ Check power to indoor blower motor. ■ Check wiring. ■ Replace motor.


3.15 Electronic Expansion Valve Coil Abnormality, Dust Clogging

Error Code	A9
Applicable Models	All indoor unit models
Method of Error Detection	Check coil condition of electronic expansion valve by using microcomputer. Check dust clogging condition of electronic expansion valve main body by using microcomputer.
Error Decision Conditions	Pin input for electronic expansion valve coil is abnormal when initializing microcomputer. Either of the following conditions is seen/caused/ occurs while the unit stops operation. <ul style="list-style-type: none"> ● R1T – R2T > 8°C (14.4°F) ● R2T shows fixed degrees or below. R1T: temperature of suction air R2T: temperature of liquid pipe of heat exchanger
Supposed Causes	<ul style="list-style-type: none"> ■ Defective electronic expansion valve coil ■ Defective indoor unit control PCB ■ Defective relay cables

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



CHECK 18 Refer to page 356.


3.16 Gas Furnace Abnormality

Error Code	AA-03
Applicable Models	CXTQ-TA
Method of Error Detection	Detects the error signal from the gas furnace when any error occurs on the gas furnace. The indoor unit displays AA-03 for any sort of gas furnace abnormality.
Error Decision Conditions	The error status differs depending on each error code of the gas furnace. Refer to the gas furnace manual for details.
Supposed Causes	The cause of the error differs depending on each error code of the gas furnace. Refer to the gas furnace manual for details.

Troubleshooting




Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




Note: *1. In some cases of gas furnace abnormality regarding gas combustion, once an error occurs, display indication of **AA-03** is retained even after the gas furnace recovered from the error to notify the occurrence of the error. The error indication disappears if you execute gas furnace combustion once or reset the indoor unit power supply.

3.17 Drain Level above Limit

Error Code	AF
Applicable Models	FXFQ-T, FXZQ-TA, FXUQ-P, FXEQ-P, FXDQ-M, FXSQ-TA, FXMQ-PB
Method of Error Detection	Water leakage is detected based on float switch ON/OFF operation while the compressor is not in operation.
Error Decision Conditions	When the float switch changes from ON to OFF while the compressor is not in operation. * Error code is displayed but the system operates continuously.
Supposed Causes	<ul style="list-style-type: none"> ■ Humidifier unit (optional accessory) leaking ■ Defective drain pipe (upward slope, etc.) ■ Defective indoor unit control PCB
Troubleshooting	<div style="text-align: center;">  <p>Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.</p> <pre> graph TD A{Field drain piping has a defect such as upward sloping.} -- YES --> B[Modify the drain piping.] A -- NO --> C{A humidifier unit (optional accessory) is installed on the indoor unit.} C -- YES --> D[Check if the humidifier unit is leaking.] C -- NO --> E[Defective indoor unit control PCB (A1P).] </pre> </div>



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.18 Capacity Determination Device Abnormality

Error Code	AJ
Applicable Models	All indoor unit models
Method of Error Detection	Capacity is determined according to resistance of the capacity setting adaptor and the memory inside the IC memory on the indoor unit PCB, and whether the value is normal or abnormal is determined.
Error Decision Conditions	When the capacity code is not saved to the PCB, and the capacity setting adaptor is not connected. When a capacity that does not exist for that unit is set.
Supposed Causes	<ul style="list-style-type: none"> ■ The capacity setting adaptor was not installed. ■ Defective indoor unit control PCB

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.19 Transmission Abnormality between Indoor Unit PCB and Fan PCB

Error Code	C1
Applicable Models	FXSQ-TA, FXMQ-PB
Method of Error Detection	Transmission conditions between the indoor unit control PCB (A1P) and fan PCB (A2P) are checked via microcomputer.
Error Decision Conditions	When normal transmission is not conducted for certain duration.
Supposed Causes	<ul style="list-style-type: none"> ■ Connection defective the connector between indoor unit control PCB (A1P) and fan PCB (A2P) ■ Defective indoor unit control PCB (A1P) ■ Defective fan PCB (A2P) ■ External factor, such as instantaneous power failure

Troubleshooting


Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





Notes:

- *1. Pull out and insert the connector once and check it is absolutely connected.
- *2. Method to check transmission part of indoor unit control PCB.
 - (1) Turn OFF the power and remove the connector X70A of indoor unit PCB (A1P).
 - (2) Short circuit X70A.
 - (3) After turning ON the power, check below numbers under field setting from remote controller.
 (Confirmation: Second code No. at the condition of first code No. 21 on mode No. 41)



Determination	01: Normal Other than 01: Transmission error on indoor unit control PCB
---------------	--

- * After confirmation, turn OFF the power, take off the short circuit and connect X70A back to original condition.


3.20 Blower Motor Communication Error

Error Code	C1-07
Applicable Models	FXTQ-TA
Outline	Error is issued if transmission abnormalities occur between indoor unit and fan motor.
Error Decision Conditions	If the response message from the fan motor is an abnormal message, and determined as such by the indoor unit, the indoor unit will execute a retry. If everything fails for 5 seconds, it is deemed to be a transmission abnormality.
Error Reset Conditions	If the indoor unit receives even a single normal response message from the fan motor, the error will be cleared.
Supposed Causes	<ul style="list-style-type: none">■ Incorrect or loose wiring■ Power interruption (low voltage)
Corrective Actions	<ul style="list-style-type: none">■ Check wiring or tighten wiring connections if needed.■ Verify the input voltage at the motor.■ Replace the indoor unit PCB or motor.

3.21 Climate Talk Communication Error

Error Code	C1-08
Applicable Models	CXTQ-TA
Method of Error Detection	Monitors the communication with the gas furnace connected to the Climate Talk Communication terminal.
Error Decision Conditions	The error decision is made when the communication with the gas furnace is lost after once the initial setting for communication with the gas furnace completes.
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of the communication wire between the CXTQ-TA and the gas furnace ■ Power supply to the gas furnace is cut.

Troubleshooting



3.22 Thermistor Abnormality

Error Code

C4, C5, C9, CA

Applicable Models

C4, C5: All indoor units
C9: except FXTQ-TA and CXTQ-TA models
CA: FXMQ-PB models only

Method of Error Detection

The error is detected by temperature detected by thermistor.

Error Decision Conditions

The thermistor becomes disconnected or shorted while the unit is running.

Supposed Causes


- Defective thermistor
- Defective indoor unit PCB
- Defective connector connection
- Broken or disconnected wire

Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Notes:

*1. Error code and thermistor

Error Code	Thermistor	Except FXMQ-PB, FXTQ-TA, CXTQ-TA	FXMQ-PB	FXTQ-TA, CXTQ-TA
C4	Heat exchanger liquid pipe thermistor	R2T	R2T	R2T
C5	Heat exchanger gas pipe thermistor	R3T	R3T	R3T
C9	Suction air thermistor	R1T	R1T	*2
CA	Discharge air thermistor	—	R4T	—

*2. Refer to page 250 for **C9** for FXTQ-TA and CXTQ-TA models.




CHECK 11 Refer to page 348.

3.23 Combination Error between Indoor Unit Control PCB and Fan PCB

Error Code	C6
Applicable Models	FXSQ-TA, FXMQ-PB
Method of Error Detection	Check the condition of transmission with fan PCB (A2P) using indoor unit control PCB (A1P).
Error Decision Conditions	When the communication data of fan PCB (A2P) is determined as incorrect.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective fan PCB (A2P) ■ Defective connection of capacity setting adaptor ■ Field setting error

Troubleshooting



3.24 Blower Motor HP Mismatch

Error Code	C6-01
Applicable Models	FXTQ-TA
Outline	Error is issued if the manufacturer ID and output of the connected fan motor do not match those recognized by the indoor unit.
Error Decision Conditions	Gathers information on the manufacturer ID and output of the fan motor when initializing the fan motor. If those figures are not the values recognized by the indoor unit, it will be deemed abnormal operation. If deemed abnormal operation, it will keep retrying until the figures match.
Error Reset Conditions	If the manufacturer ID and output match, the error will be cleared.
Supposed Causes	<ul style="list-style-type: none">■ Incorrect size motor■ Indoor unit capacity setting error
Corrective Actions	<ul style="list-style-type: none">■ Correct motor installation.■ Correct the indoor unit capacity setting.

3.25 Indoor Blower Does Not Have Required Parameters to Function

Error Code	C6-02
Applicable Models	FXTQ-TA
Outline	Indoor units perform required settings for control on the fan motor, but if the minimum required settings are not made then information indicating as such will be included among the periodic control status information. Error is issued when the information shows abnormality.
Error Decision Conditions	If the parameter information shows abnormality, it will be deemed abnormal operation. At that point, parameter settings when initializing the fan motor will be implemented from the beginning.
Error Reset Conditions	If the parameter information is normal, the error will be cleared.
Supposed Causes	<ul style="list-style-type: none"> ■ Locked motor rotor condition
Corrective Actions	<ul style="list-style-type: none"> ■ Check for locked rotor condition. ■ Replace the indoor unit PCB or motor.


3.26 Remote Sensor Abnormality

Error Code	C9
Applicable Models	FXTQ-TA, CXTQ-TA
Method of Error Detection	The error is detected by remote sensor temperature.
Error Decision Conditions	The remote sensor becomes disconnected or shorted while the unit is running.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective indoor unit thermistor (R1T) for room temperature ■ Defective indoor unit PCB

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Note: *1. Connector and indoor unit PCB

Connector for remote sensor	PCB
X4A	A1P




CHECK 11 Refer to page 348.

3.27 Humidity Sensor System Abnormality

Error Code	CC
Applicable Models	FXFQ-T
Method of Error Detection	Even if an error occurs, operation still continues. Error is detected according to the moisture (output voltage) detected by the moisture sensor.
Error Decision Conditions	When the moisture sensor is disconnected or short circuited
Supposed Causes	<ul style="list-style-type: none"> ■ Defective sensor ■ Disconnection

Troubleshooting



Notes:


- *1. To delete the history, the **ON/OFF** button of the remote controller must be pressed and held for 5 seconds in the check mode.
- *2. To display the code, the **INSPECTION/TEST** button of the remote controller must be pressed and held in the normal mode.
- *3. If **CC** is displayed even after replacing the humidity sensor PCB Assy (A2P) and taking the steps *1 and 2, replace the indoor unit PCB Assy (A1P).

3.28 Infrared Presence/Floor Sensor Error

Error Code	CE
Applicable Models	FXFQ-T, FXUQ-P
Method of Error Detection	The contents of a failure vary with the detailed error code. Check the code and proceed with the flowchart.
Error Decision Conditions	Error is detected based on sensor output signals
Supposed Causes	<ul style="list-style-type: none"> ■ Defective or disconnected infrared presence sensor connector: CE-01 ■ Defective infrared floor sensor (Temperature compensation circuit disconnection): CE-02 ■ Defective infrared floor sensor (Temperature compensation short circuit): CE-03 ■ Defective infrared floor sensor element: CE-04
Troubleshooting	



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Troubleshooting

Diagnosis procedure 1




Note: *1. Connector

Model	Connector
FXFQ-T	X2A (A2P)
FXUQ-P	X81A (A1P)

Troubleshooting

Diagnosis procedure 2




Note: *1. Connector

Model	Connector
FXFQ-T	X2A (A2P)
FXUQ-P	X81A (A1P)

Troubleshooting

Diagnosis procedure 3




Note: *1. Connector

Model	Connector
FXFQ-T	X2A (A2P)
FXUQ-P	X81A (A1P)

Troubleshooting

Diagnosis procedure 4




Note: *1. Connector


Model	Connector
FXFQ-T	X2A (A2P)
FXUQ-P	X81A (A1P)

3.29 Remote Controller Thermistor Abnormality

Error Code	CJ
Applicable Models	All indoor unit models
Method of Error Detection	Error detection is carried out by temperature detected by the remote controller thermistor.
Error Decision Conditions	The remote controller thermistor becomes disconnected or shorted while the unit is running. * Error code is displayed but the system operates continuously.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective remote controller thermistor ■ Defective remote controller PCB

Troubleshooting



 **Note:** *1. How to delete the history of error codes.
Press the **ON/OFF** button for 4 seconds and more while the error code is displayed in the inspection mode.

3.30 Outdoor Unit Main PCB Abnormality

Error Code

E1

Applicable Models

All outdoor unit models

Method of Error Detection

Abnormality is detected under the communication conditions in the hardware section between the indoor unit and outdoor unit.

Error Decision Conditions

When the communication conditions in the hardware section between the indoor unit and the outdoor unit are not normal

Supposed Causes


- Defective outdoor unit main PCB (A1P)
- Disconnection of the inside/outside relay wires

Troubleshooting



Caution


Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



3.31 Current Leakage Detection

Error Code	E2 Sub code: -01 to -03
Applicable Models	All outdoor unit models
Method of Error Detection	Current leakage is detected in the ground leakage detection circuit. Error is detected on the outdoor unit main PCB.
Error Decision Conditions	When leakage current is detected.
Supposed Causes	<ul style="list-style-type: none"> ■ Ground fault ■ Defective wiring with the current sensor ■ Temporary liquid back or refrigerant stagnation

Troubleshooting




3.32 Missing of Leakage Detection Core

Error Code	E2 Sub code: -06 to -08
Applicable Models	All outdoor unit models
Method of Error Detection	Detect error according to whether or not there is continuity across the connector (X101A).
Error Decision Conditions	When no current flows at the time of turning ON the power supply.
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of connector (X101A) ■ Wiring disconnection ■ Defective outdoor unit main PCB
Troubleshooting	

**Caution**


Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.33 Activation of High Pressure Switch

Error Code	E3
Applicable Models	All outdoor unit models
Method of Error Detection	Detect continuity across the high pressure switch in the protection device circuit.
Error Decision Conditions	When part of the protection device circuit opens. (Reference) Operating pressure of the high pressure switch: <ul style="list-style-type: none"> ■ Operating pressure: 4.0 MPa (580 psi) ■ Resetting pressure: 3.0 MPa (435 psi)
Supposed Causes	<ul style="list-style-type: none"> ■ Activation of high pressure switch ■ Defective high pressure switch ■ Defective outdoor unit main PCB (A1P) ■ Momentary power failure ■ Defective high pressure sensor

Troubleshooting





CHECK 1 Refer to page 339.





CHECK 12 Refer to page 351.

3.34 Activation of Low Pressure Sensor

Error Code	E4
Applicable Models	All outdoor unit models
Method of Error Detection	Make judgment of pressure detected by the low pressure sensor with the outdoor unit main PCB.
Error Decision Conditions	When low pressure caused a drop while the compressor is in operation: <ul style="list-style-type: none"> ■ Operating pressure: 0.07 MPa (10.2 psi)
Supposed Causes	<ul style="list-style-type: none"> ■ Abnormally drop in low pressure ■ Defective low pressure sensor ■ Defective outdoor unit main PCB ■ The stop valve is not opened

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



CHECK 2 Refer to page 340.



CHECK 12 Refer to page 351.

3.35 Compressor Motor Lock

Error Code

E5

Applicable Models

All outdoor unit models

Method of Error Detection

Inverter PCB takes the position signal from UVW line connected between the inverter and compressor, and the error is detected when any abnormality is observed in the phase-current waveform.

Error Decision Conditions

When the compressor motor does not operate even by starting it in forced startup mode.

Supposed Causes


- Compressor lock
- High differential pressure (0.5 MPa (72.5 psi) or more)
- UVW connection error
- Defective inverter PCB
- The stop valve is not opened


Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





CHECK 4 Refer to page 344.


3.36 Compressor Damage Alarm


Error Code	E6
Applicable Models	All outdoor unit models
Method of Error Detection	Determine the symptom to be error by detecting the revolutions of the compressor and pressure values detected by the high and low pressure sensors, and further making a comparison between a theoretical current value of the compressor calculated from parameters detected and an actual current value detected by the power transistor.
Error Decision Conditions	When a state in which the actual current value of the compressor is abnormally high (by 130% or more) compared to the theoretical current value continues for a period of 30 minutes. * In case of a system with multi outdoor units, the system will return an alarm if there is any operational unit other than that applicable to E6 or determine to be error if not.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective compressor ■ Defective high pressure sensor ■ Defective low pressure sensor ■ Defective outdoor unit main PCB ■ Defective inverter PCB

Troubleshooting


Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





CHECK 4 Refer to page 344.





CHECK 12 Refer to page 351.

3.37 Outdoor Fan Motor Abnormality

Error Code	E7
Applicable Models	All outdoor unit models
Method of Error Detection	<ul style="list-style-type: none"> ■ Detect according to the value of current flowing through the inverter PCB (or fan PCB in case of Fan Motor 2). ■ Detect error of the fan motor system according to the fan revolutions detected by the hall IC during the fan motor runs.
Error Decision Conditions	<ul style="list-style-type: none"> ■ Overcurrent is detected from the inverter PCB or the fan PCB (Detecting overcurrent 4 times will shut down the system). ■ The fan revolutions fall below a given level for a period of 6 seconds while in fan motor rotation mode (Detecting shortage of revolutions will shut down the system).
Supposed Causes	<ul style="list-style-type: none"> ■ Fan motor failure ■ Neglect to connect or defective connection of harness/connector between the fan motor and the PCB ■ Fan does not rotate due to foreign matter caught in it. ■ Clearing condition: fan motor performs normal operation for a period of 5 minutes

Troubleshooting





CHECK 16 Refer to page 353.



CHECK 17 Refer to page 354.

3.38 Electronic Expansion Valve Coil Abnormality


Error Code	E9
Applicable Models	All outdoor unit models
Method of Error Detection	Detect according to whether or not there is continuity across the electronic expansion valve coils.
Error Decision Conditions	When no current flows through common (COM[+]) at the time of turning ON the power supply.
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of connectors from electronic expansion valves ■ Defective electronic expansion valve coil ■ Defective outdoor unit main PCB

Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





CHECK 18 Refer to page 356.


3.39 Discharge Pipe Temperature Abnormality

Error Code	F3
Applicable Models	All outdoor unit models
Method of Error Detection	Detect according to temperature detected with the discharge pipe or compressor body thermistor.
Error Decision Conditions	<ul style="list-style-type: none"> ■ When discharge pipe temperature becomes abnormally high (i.e., 135°C (275°F) or more) ■ When discharge pipe temperature sharply rises (remains at 120°C (248°F) or more for a period of consecutive 10 minutes) ■ When compressor surface temperature becomes abnormally high (i.e., 120°C (248°F) or more) ■ When compressor surface temperature sharply rises (remains at 110°C (230°F) or more for a period of consecutive 10 minutes)
Supposed Causes	<ul style="list-style-type: none"> ■ Abnormal discharge pipe temperature ■ Defective discharge pipe thermistor ■ Abnormal compressor surface temperature ■ Defective compressor body thermistor ■ Defective outdoor unit main PCB

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



 **Note:** *1. Thermistors

Applicable Thermistor	RXYQ72XA		RXYQ96/120XA		RXYQ144/168XA	
	Electric symbol	Connector	Electric symbol	Connector	Electric symbol	Connector
Discharge pipe (M1C) thermistor	R21T	X29A	R21T	X29A (Group connector)	R21T	X29A (Group connector)
Discharge pipe (M2C) thermistor	—	—	—		R22T	
Compressor body thermistor	—	—	R8T		—	



CHECK 3 Refer to page 342.



CHECK 11 Refer to page 348.

3.40 Wet Alarm

Error Code	F4
Applicable Models	All outdoor unit models
Method of Error Detection	In cooling operation, detect the condition under which liquid refrigerant returns to the compressor, according to the temperature and pressure of each part.
Error Decision Conditions	<p>When the following wet state continues for a period of 90 minutes, an alert is issued. An error is defined for 120 minutes.</p> <ul style="list-style-type: none"> ■ Wet state in outdoor units <p>When the following wet state continues for a period of 45 minutes, an alert is issued.</p> <ul style="list-style-type: none"> ■ Wet state in some of indoor units
Supposed Causes	<ul style="list-style-type: none"> ■ Defective suction pipe thermistor ■ Defective discharge pipe thermistor ■ Defective high pressure sensor ■ Defective indoor unit electronic expansion valve ■ Dirty air filter

Troubleshooting

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

Connect the Service Checker.
Mount a pressure gauge on the high pressure service port.
Reset the operation, and then restart the operation.

Are the characteristics of the accumulator inlet thermistor and the suction pipe thermistor normal?

NO

Replace the relevant thermistor.

YES

Are the discharge pipe thermistor characteristics normal?

NO

Replace the discharge pipe thermistor.

YES

Are the high pressure sensor characteristics normal?

NO

Replace the high pressure sensor.

YES

Service Checker

Use the Service Checker to find indoor units operating under the following conditions:

- Gas pipe temperature (R6T) - Liquid pipe temperature (R4T) < 2.5°C (4.5°F)
- & • Electronic expansion valve opening < 300 pulses

Stop the relevant indoor units while the system is in cooling operation, and then check for the liquid pipe temperature of these indoor units after the system is stabilized.

The liquid pipe temperature is low (equivalent to the evaporating temperature).

YES

Replace the indoor unit electronic expansion valve.

NO

Clean the air filters of the indoor units.

3.41 Refrigerant Overcharged


Error Code	F6
Applicable Models	All outdoor unit models
Method of Error Detection	Detect overcharged refrigerant according to outdoor air temperature, heat exchanger deicer temperature, and liquid pipe temperature during check operation.
Error Decision Conditions	When the amount of refrigerant, which is calculated using outdoor air temperature, heat exchanger deicer temperature, and liquid pipe temperature during check operation, exceeds the regular charge amount by 30% or more (If refrigerant is charged slightly over the regular charge amount, F6 may be displayed on the remote controller.)
Supposed Causes	<ul style="list-style-type: none"> ■ Refrigerant overcharged ■ Disconnection of outdoor air thermistor ■ Disconnection of heat exchanger deicer thermistor ■ Disconnection of liquid pipe temperature thermistor

Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



CHECK 11 Refer to page 348.


3.42 Harness Abnormality (between Outdoor Unit Main PCB and Inverter PCB)

Error Code	H3
Applicable Models	All outdoor unit models
Method of Error Detection	Check for the transmission conditions of the harnesses between the PCBs using microcomputer.
Error Decision Conditions	When normal transmission between PCB is disabled during the compressor stops running.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective connection of jumpers between PCB ■ Defective outdoor unit main PCB (A1P) ■ Defective inverter PCB

Troubleshooting


Caution


Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.43 Outdoor Fan Motor Signal Abnormality

Error Code	H7
Applicable Models	All outdoor unit models
Method of Error Detection	Detect of abnormal signal from fan motor.
Error Decision Conditions	An abnormal signal is detected at startup of the fan motor operation.
Supposed Causes	<ul style="list-style-type: none"> ■ Abnormal signal from fan motor (Circuit failure) ■ Disconnection/Short circuit in fan motor leads or disconnection of connector ■ Defective inverter PCB (A3P, A6P)

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

Check for fan motor applicable to the error code **H7** while in monitor mode.
 • Sub code
 Fan motor 1 (M1F): H07-01 (Master), H7-05 (Slave 1), H7-09 (Slave 2)
 Fan motor 2 (M2F): H07-02 (Master), H7-06 (Slave 1), H7-10 (Slave 2)



CHECK 17 Refer to page 354.

3.44 Thermistor Abnormality

Error Code

H9, J3, J5, J6, J7, J8, J9

Applicable Models

All outdoor unit models

Method of Error Detection

Detect according to temperature detected with individual thermistors.

Error Decision Conditions

The system is in operation and the thermistor causes wiring disconnection or short circuit in it.

Supposed Causes


- Defective connection of thermistor
- Defective thermistor
- Defective outdoor unit main PCB

Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





Note: *1. Error codes and thermistors

Error Code	Applicable Thermistor	RXYQ72XA		RXYQ96/120XA		RXYQ144/168XA	
		Electric symbol	Connector	Electric symbol	Connector	Electric symbol	Connector
H9	Outdoor air thermistor	R1T	X18A	R1T	X18A	R1T	X18A
J3	Discharge pipe (M1C) thermistor	R21T	X29A	R21T	X29A (Group connector)	R21T	X29A (Group connector)
	Discharge pipe (M2C) thermistor	—	—	—		R22T	
	Compressor body thermistor	—	—	R8T		—	
J5	Accumulator inlet thermistor	R3T	X30A (Group connector)	R3T	X30A (Group connector)	R3T	X30A (Group connector)
J6	Heat exchanger deicer thermistor	R7T		R7T		R7T	
J7	Subcooling heat exchanger liquid pipe thermistor	R5T		R5T		R5T	
J8	Heat exchanger liquid pipe thermistor	R4T		R4T		R4T	
J9	Subcooling heat exchanger gas pipe thermistor	R6T		R6T		R6T	





CHECK 11 Refer to page 348.

3.45 High Pressure Sensor Abnormality

Error Code	JA
Applicable Models	All outdoor unit models
Method of Error Detection	Detect according to temperature detected with the high pressure sensor.
Error Decision Conditions	The high pressure sensor is short circuit or open circuit. (Pressure range: 0-4.3 MPa (0-624 psi))
Supposed Causes	<ul style="list-style-type: none">■ Defective high pressure sensor■ Connection of low pressure sensor in mistake for high pressure sensor■ Defective outdoor unit main PCB■ Defective connection of high pressure sensor

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





CHECK 12 Refer to page 351.

3.46 Low Pressure Sensor Abnormality

Error Code	JC
Applicable Models	All outdoor unit models
Method of Error Detection	Detect according to temperature detected with the low pressure sensor.
Error Decision Conditions	The low pressure sensor is short circuit or open circuit. (Pressure range: 0-1.7 MPa (0-247 psi))
Supposed Causes	<ul style="list-style-type: none">■ Defective low pressure sensor■ Connection of high pressure sensor in mistake for low pressure sensor■ Defective outdoor unit main PCB■ Defective connection of low pressure sensor

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





CHECK 12 Refer to page 351.

3.47 Inverter PCB Abnormality

Error Code	L1
Applicable Models	All outdoor unit models
Method of Error Detection	<ul style="list-style-type: none">■ Detect according to current value detected during the output of waveform before compressor startup■ Detect according to current value detected with the current sensor during synchronous operation for startup
Error Decision Conditions	<ul style="list-style-type: none">■ When overcurrent (OCP) flows during the output of waveform■ When the current sensor error during synchronous operation■ When IPM error occurs
Supposed Causes	<ul style="list-style-type: none">■ Inverter PCB<ul style="list-style-type: none">■ IPM failure■ Current sensor failure■ Drive circuit failure

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




★1
 RXYQ72-120XA: A3P
 RXYQ144/168XA: A3P, A6P

★2
 RXYQ72XA: A4P
 RXYQ96/120XA: A4P, A5P
 RXYQ144/168XA: A4P, A7P



CHECK 4 Refer to page 344.


3.48 Reactor Temperature Rise Abnormality

Error Code	L3
Applicable Models	All outdoor unit models
Method of Error Detection	Detect according to the value detected with the reactor surface thermistor.
Error Decision Conditions	When the temperature detected with the reactor surface thermistor is more than the specified temperature.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective connection of harness ■ Defective reactor surface thermistor ■ Defective inverter PCB
Troubleshooting	<div style="text-align: center;">  <p>Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.</p> </div> <pre> graph TD Q1{Is reactor harness connected to the terminal strip correctly?} Q2{Is the wiring disconnection in the reactor thermistor?} A1[Connect the harness correctly.] A2[Replace the thermistor.] A3["Replace the inverter PCB. RXYQ72-120XA: A3P RXYQ144/168XA: A3P, A6P"] Q1 -- NO --> A1 Q1 -- YES --> Q2 Q2 -- YES --> A2 Q2 -- NO --> A3 </pre>



Caution


Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.49 Inverter Radiation Fin Temperature Rise Abnormality

Error Code	L4
Applicable Models	All outdoor unit models
Method of Error Detection	Detect temperature of power module of the inverter PCB.
Error Decision Conditions	Thermistor located inside the power module of the inverter PCB for compressor and fan motor. Cooling tube plate poor heat-exchange.
Supposed Causes	<ul style="list-style-type: none"> ■ Cooling tube plate not fixed with screws ■ U0 error ■ Defective inverter PCB ■ High outdoor air temperature

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



3.50 Compressor Instantaneous Overcurrent

Error Code

L5

Applicable Models

All outdoor unit models

Method of Error Detection

Detect current flowing through the power transistor.

Error Decision Conditions

When overcurrent flows instantaneously through the power transistor (*1)

Supposed Causes


- Defective compressor coil (such as wiring disconnection or insulation failure)
- Compressor startup failure (mechanical lock)
- Defective inverter PCB


Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





i Note: *1.

Model	RXYQ72XA	RXYQ96/120XA	RXYQ144/168XA	
	M1C	M1C	M1C	M2C
XATJA	63.2 A	85.6 A	63.2 A	63.2 A
XAYDA	32.4 A	53.7 A	63.2 A	63.2 A




CHECK 4 Refer to page 344.


3.51 Compressor Overcurrent

Error Code	L8
Applicable Models	All outdoor unit models
Method of Error Detection	Detect current flowing through the power transistor.
Error Decision Conditions	When the secondary-side inverter current exceeds: *1
Supposed Causes	<ul style="list-style-type: none"> ■ Compressor overloaded ■ Wiring disconnection in compressor coil ■ Disconnection of compressor wiring ■ Defective inverter PCB
Troubleshooting	

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





i Note: *Trigger point

Model	RXYQ72XA	RXYQ96/120XA	RXYQ144/168XA	
	M1C	M1C	M1C	M2C
XATJA	33.5 A	45.0 A	33.5 A	33.5 A
XAYDA	13.0 A	13.0 A	13.0 A	13.0 A



CHECK 4 Refer to page 344.

3.52 Compressor Startup Abnormality

Error Code**L9****Applicable Models**

All outdoor unit models

Method of Error Detection

Detect error according to the signal waveform of compressor.

Error Decision Conditions

When compressor startup operation has not been completed.


Supposed Causes


- The stop valve is not opened
- Defective compressor
- Error in wire connections to compressor
- Large differential pressure before compressor startup
- Defective inverter PCB

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.







CHECK 4 Refer to page 344.


3.53 Transmission Error between Inverter PCB and Outdoor Unit Main PCB

Error Code	LC
Applicable Models	All outdoor unit models
Method of Error Detection	Check for the transmission conditions between the inverter PCB and the outdoor unit main PCB using a microcomputer.
Error Decision Conditions	When normal transmission is disabled for a given period of time or more.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective connection between the inverter PCB and the outdoor unit main PCB ■ Defective outdoor unit main PCB (transmission block) ■ Defective noise filter ■ External factors (e.g. noise) ■ Defective compressor ■ Defective fan motor

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





Note: *1. Connect and disconnect the connector once to ensure that it is securely connected.

3.54 Power Supply Voltage Imbalance

Error Code**P1****Applicable Models**

All outdoor unit models

Method of Error Detection

Detect voltage imbalance through PCB.

Error Decision Conditions

When power supply voltage imbalance exceeds approximately 12 V.

Error is not decided while the unit operation is continued.


P1 will be displayed by pressing the inspection button.**Supposed Causes**

- Open phase
- Interphase voltage imbalance
- Defective capacitor in the main circuit
- Defective inverter PCB
- Defective K1M, K2M (inverter PCB)
- Defective wiring in the main circuit

Troubleshooting

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.


**Notes:**


- *1. Make measurement of voltage at the power supply terminal block (X1M).
- *2. Make measurement of voltage at the L1, L2 and L3 terminals of diode module located on the inverter PCB during the compressor is in operation.

3.55 Reactor Temperature Abnormality

Error Code	P3
Applicable Models	All outdoor unit models
Method of Error Detection	Detect according to the value detected with the reactor surface thermistor.
Error Decision Conditions	The system is in operation and the thermistor causes wiring disconnection or short circuit in it.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective connection of thermistor ■ Defective reactor thermistor ■ Defective inverter PCB

Troubleshooting

 **Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.56 Inverter Radiation Fin Temperature Abnormality

Error Code	P4
Applicable Models	All outdoor unit models
Method of Error Detection	Detect the resistance of the following thermistors during the compressor stops running: (1) Radiation fin thermistor. (2) Thermistor located in PCB circuit. (3) Heat sink thermistor.
Error Decision Conditions	When the resistance of the thermistor comes to a value equivalent to open or short circuit. Error is not decided while the unit operation is continued. P4 will be displayed by pressing the inspection button.
Supposed Causes	<ul style="list-style-type: none">■ Defective radiation fin temperature thermistor■ Defective inverter PCB■ Defective compressor■ Defective fan motor

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.57 Field Setting after Replacing Outdoor Unit Main PCB Abnormality or Combination of PCB Abnormality

Error Code	PJ
Applicable Models	All outdoor unit models
Method of Error Detection	This error is detected according to communications with the inverter PCB.
Error Decision Conditions	Make judgment according to communication data on whether or not the type of the inverter PCB is correct.
Supposed Causes	<ul style="list-style-type: none"> ■ Mismatching of type of PCB ■ Improper (or no) field setting after replacing outdoor unit main PCB
Troubleshooting	

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.58 Refrigerant Shortage

Error Code	U0
Applicable Models	All outdoor unit models
Method of Error Detection	Detect refrigerant shortage according to a low pressure level or a difference in heat exchanger temperature from the suction pipe.
Error Decision Conditions	Low pressure becomes 0.1 MPa (14.5 psi) or less. * Error is not determined. The unit continues the operation.
Supposed Causes	<ul style="list-style-type: none"> ■ Refrigerant shortage and refrigerant clogging (wrong piping) ■ Defective thermistor ■ Defective low pressure sensor ■ Defective outdoor unit main PCB

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Notes:

- *1. Check the low pressure value by using pressure gauge in operation.
- *2. Compare the actual measurement value by pressure sensor with the value by the pressure gauge.
(To gain actual measurement value by pressure sensor, measure the voltage at the connector [between (2)-(3)] and then convert the value into pressure. **CHECK 12**)



CHECK 2 Refer to page 340.



CHECK 12 Refer to page 351.

3.59 Reverse Phase, Open Phase

Error Code

U1

Applicable Models

All outdoor unit models

Method of Error Detection

The phase of each phase are detected by reverse phase detection circuit and right phase or reverse phase are judged.

Error Decision Conditions

When a power supply is reverse phase, or T phase is open phase.

Supposed Causes


- Power supply reverse phase
- T phase open phase
- Defective outdoor unit main PCB

Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



3.60 Power Supply Insufficient or Instantaneous Abnormality


Error Code	U2
Applicable Models	All outdoor unit models
Method of Error Detection	Detect the voltage of capacitor of the main circuit in the inverter PCB.
Error Decision Conditions	When the voltage in the DC circuit (between diode module and power module) falls below specified voltage.
Supposed Causes	<ul style="list-style-type: none"> ■ Abnormal power supply voltage ■ Instantaneous power failure ■ Open phase ■ Defective inverter PCB ■ Defective outdoor unit main PCB ■ Defective compressor ■ Defective main circuit wiring ■ Defective fan motor ■ Defective connection of signal cable


Troubleshooting



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





CHECK 4 Refer to page 344.

3.61 Check Operation not Executed


Error Code	U3
Applicable Models	All outdoor unit models
Method of Error Detection	The check operation has not been executed
Error Decision Conditions	Error is decided when the unit starts operation without check operation.
Supposed Causes	Check operation not executed

Troubleshooting


Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

The contents of individual failures vary with sub code. Ensure the sub code, and then go to the following:



3.62 Transmission Error between Indoor Units and Outdoor Units


Error Code	U4
Applicable Models	All indoor unit models All outdoor unit models
Method of Error Detection	Microcomputer checks if transmission between indoor and outdoor units is normal.
Error Decision Conditions	When transmission is not carried out normally for a certain amount of time
Supposed Causes	<ul style="list-style-type: none"> ■ Short circuit in indoor-outdoor or outdoor-outdoor transmission wiring (F1 / F2), or wrong wiring ■ Outdoor unit power supply is OFF. ■ System address does not match. ■ Defective indoor unit PCB ■ Defective outdoor unit PCB ■ Multi-tenant function is ON.


Troubleshooting




Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.








3.63 Transmission Error between Remote Controller and Indoor Unit

Error Code	U5
Applicable Models	All indoor unit models
Method of Error Detection	Microcomputer checks if transmission between indoor unit and remote controller is normal.
Error Decision Conditions	Transmission is not carried out normally for a certain amount of time.
Supposed Causes	<ul style="list-style-type: none"> ■ Transmission error between indoor unit and remote controller ■ Connection of 2 main remote controllers (when using 2 remote controllers) ■ Defective indoor unit PCB ■ Defective remote controller PCB ■ Transmission error caused by noise

Troubleshooting


Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Refer to page 72 for Main/Sub setting.

3.64 Transmission Error between Outdoor Units


Error Code	U7
Applicable Models	All outdoor unit models
Method of Error Detection	Microcomputer checks if transmission between outdoor units is normal.
Error Decision Conditions	When transmission is not carried out normally for a certain amount of time
Supposed Causes	<ul style="list-style-type: none"> ■ Connection error of transmission wirings between outdoor unit and external control adaptor for outdoor unit ■ Connection error of transmission wirings between outdoor units ■ Cool/Heat selection setting error ■ Cool/Heat unified address setting error (functional unit, external control adaptor for outdoor unit) ■ Defective outdoor unit main PCB ■ Defective external control adaptor for outdoor unit


Troubleshooting




Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Ensure the sub code or the lamp display of monitor mode, and then go to the following:









Diagnosis Flow-3



Replace the outdoor unit main PCB (A1P) for multi slave 1.

Modify the outdoor unit multi transmission wirings, and then reset the power supply.



Diagnosis Flow-4



Replace the outdoor unit main PCB (A1P) for multi slave 2.

Modify the outdoor unit multi transmission wirings, and then reset the power supply.

Diagnosis Flowchart-5





Replace the outdoor unit main PCB (A1P).


Disconnect the outdoor unit multi transmission wirings, and then reset the power supply.

Diagnosis Flow-6

U7-06



Error code	Sub code
	

(Manual address setting error for slave 1, 2)




Diagnosis Flow-7

U7-07



Error code	Sub code
	

(Connection 4 or more outdoor units to the same system)




Diagnosis Flow-8

U7-11

Error code	Sub code
	


(Connection of excess indoor units for test operation)



3.65 Transmission Error between Main and Sub Remote Controllers

Error Code	U8
Applicable Models	All indoor unit models
Method of Error Detection	In case of controlling with 2 remote controller, check the system using microcomputer if signal transmission between indoor unit and remote controller (main and sub remote controller) is normal.
Error Decision Conditions	When transmission is not carried out normally for a certain amount of time.
Supposed Causes	<ul style="list-style-type: none"> ■ Transmission error between main and sub remote controller ■ Connection between sub remote controllers ■ Defective remote controller PCB

Troubleshooting



Refer to page 72 for Main/Sub setting.


3.66 Transmission Error between Indoor Unit and Outdoor Unit in the Same System

Error Code	U9
Applicable Models	All indoor unit models All outdoor unit models
Method of Error Detection	Detect the error signal for the other indoor unit within the circuit by outdoor unit main PCB.
Error Decision Conditions	When the error decision is made on any other indoor unit within the system concerned
Supposed Causes	<ul style="list-style-type: none"> ■ Transmission error between other indoor and outdoor units ■ Defective electronic expansion valve of other indoor unit ■ Defective indoor unit control PCB of other indoor unit ■ Improper connection of transmission wiring between indoor and outdoor unit ■ Multi-tenant function is ON.

Troubleshooting


Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



3.67 Improper Combination of Indoor Unit and Outdoor Unit, Indoor Unit and Remote Controller


Error Code	UA
Applicable Models	All indoor unit models All outdoor unit models
Method of Error Detection	A difference occurs in data by the type of refrigerant between indoor and outdoor units. The number of indoor units connected is out of the allowable range.
Error Decision Conditions	The error decision is made as soon as either of the abnormalities aforementioned is detected.
Supposed Causes	<ul style="list-style-type: none"> ■ Excess of connected indoor units ■ Defective outdoor unit main PCB ■ Mismatch of the refrigerant type of indoor and outdoor unit. ■ Setting of outdoor unit main PCB was not carried out after replacing to spare PCB.


Troubleshooting




Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.







i Note: *1. Refer to page 328.




Diagnosis Flowchart-3



Diagnosis Flowchart-4





3.68 Incorrect Gas Furnace Connecting Number

Error Code	UA
Applicable Models	CXTQ-TA
Outline	Two or more "CXTQ-TA + gas furnace" and other indoor units other than CXTQ-TA are connected.
Error Decision Conditions	Check that two or more "CXTQ-TA + gas furnace" and other indoor units other than CXTQ-TA are not connected.
Operation After Error Codes Decided	<ul style="list-style-type: none">■ The error code UA is displayed on the remote controller.■ Change to be the system that one "CXTQ-TA + gas furnace" and other indoor units other than CXTQ-TA are connected.

3.69 Incorrect Electric Heater Capacity Setting

Error Code	UA-17
Applicable Models	FXTQ-TA
Outline	<p>After attaching optional electric heater, if the electric heater capacity setting (11(21)-5) is made mistakenly for heaters not featured in the lineup, heating via unintended levels of airflow will be prevented.</p> <p>However, the electric heater will be operable for convenience.</p>
Error Decision Conditions	Checks when the capacity setting (11(21)-5) of the electric heater has been set to a non-applicable value.
Operation After Error Codes Decided	<ul style="list-style-type: none"> ■ The error code UA-17 is displayed on the remote controller. ■ Indoor units can operate continuously. ■ Incorrect setting is kept. ■ Even if the ON condition for electric heater 2 is established, only electric heater 1 will be set to ON. (Electric heater 1 set to ON, electric heater 2 set to OFF) (In order to deliver in terms of user-friendliness and safety, the electric heater can operate at the lowest possible power levels.) ■ The airflow of the fan during operation of the electric heater will be set to the largest value within the CFM dictated by the capacity of each of the electric heaters (electric heater 1, electric heater 2 both set to ON). ■ All other operations are the same as during normal operation.

3.70 Address Duplication of Centralized Controller

Error Code	UC
Applicable Models	All indoor unit models Centralized controller
Method of Error Detection	The principal indoor unit detects the same address as that of its own on any other indoor unit.
Error Decision Conditions	The error decision is made as soon as the abnormality aforementioned is detected.
Supposed Causes	<ul style="list-style-type: none"> ■ Address duplication of centralized controller ■ Defective indoor unit PCB

Troubleshooting


Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

The centralized address is duplicated.

Make setting change so that the centralized address will not be duplicated.


3.71 Transmission Error between Centralized Controller and Indoor Unit


Error Code	UE
Applicable Models	All indoor unit models Central remote controller Schedule timer intelligent Touch Controller
Method of Error Detection	Microcomputer checks if transmission between indoor unit and centralized controller is normal.
Error Decision Conditions	When transmission is not carried out normally for a certain amount of time
Supposed Causes	<ul style="list-style-type: none"> ■ Transmission error between optional controllers for centralized controller and indoor unit ■ Connector for setting main controller is disconnected. (or disconnection of connector for independent / combined use changeover switch.) ■ Defective PCB for central remote controller ■ Defective indoor unit PCB

Troubleshooting

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





CHECK 15 Refer to page 352.


3.72 System Not Set Yet

Error Code	UF
Applicable Models	All indoor unit models All outdoor unit models
Method of Error Detection	On check operation, the number of indoor units in terms of transmission is not corresponding to that of indoor units that have made changes in temperature.
Error Decision Conditions	The error is determined as soon as the abnormality aforementioned is detected through checking the system for any erroneous connection of units on the check operation.
Supposed Causes	<ul style="list-style-type: none"> ■ Improper connection of transmission wiring between indoor-outdoor units and outdoor-outdoor units ■ Failure to execute check operation ■ Defective indoor unit PCB ■ Stop valve is not opened

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




3.73 System Abnormality, Refrigerant System Address Undefined

Error Code	UH
Applicable Models	All indoor unit models All outdoor unit models
Method of Error Detection	System detects an indoor unit whose address is not defined by automatic address function. *Automatic address refers to the automatic designated address of indoor unit and outdoor unit when connected to the power after installation or wiring replacement (with the RETURN (BS3) button pressed for more than 5 seconds).
Error Decision Conditions	The error decision is made as soon as the abnormality aforementioned is detected.
Supposed Causes	<ul style="list-style-type: none"> ■ Improper connection of transmission wiring between indoor-outdoor units and outdoor-outdoor units ■ Defective indoor unit PCB ■ Defective outdoor unit main PCB

Troubleshooting

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




Note: *1. Refer to installation manual for correct "indoor unit and outdoor unit connection wiring".

3.74 Climate Talk Communication System Combination Error (Before Initial Setting for Communication Completes)

Error Code	UH-05
Applicable Models	CXTQ-TA
Method of Error Detection	Detects the type of the devices constituted in Climate Talk Communication.
Error Decision Conditions	<p>The error decision is made when any of the following conditions is established before elapsing 4 minutes after the power is turned ON.</p> <ul style="list-style-type: none"> ■ Two or more gas furnaces are detected. ■ Any unit other than the gas furnace is detected. ■ The initial setting for communication does not complete.
Supposed Causes	<ul style="list-style-type: none"> ■ Connection of wrong devices ■ The power of the gas furnace is not turned ON, or the power of the gas furnace is turned ON after a certain period of time has been elapsed after the power of the CXTQ-TA was turned ON. ■ Disconnection of the communication wire between the CXTQ-TA and the gas furnace ■ Two or more gas furnaces are connected to one CXTQ-TA. ■ No gas furnace is connected.

Troubleshooting




3.75 Climate Talk Communication System Combination Error (After Initial Setting for Communication Completes)

Error Code	UH-06
Applicable Models	CXTQ-TA
Method of Error Detection	Detects the type of the devices constituted in Climate Talk Communication.
Error Decision Conditions	<p>The error decision is made when any of the following conditions is established once the initial setting for communication with the gas furnace completes and after elapsing 4 minutes after the power is turned ON.</p> <ul style="list-style-type: none"> ■ Two or more gas furnaces are detected. ■ Any unit other than the gas furnace is detected.
Supposed Causes	<ul style="list-style-type: none"> ■ Connection of wrong devices ■ Two or more gas furnaces are connected to one CXTQ-TA.
Troubleshooting	

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




4. Check

4.1 High Pressure Check

CHECK 1

Referring to the Fault Tree Analysis (FTA) shown below, probe the defective points.



Notes:

- *1. In cooling, it is normal if the outdoor unit electronic expansion valve (main) is fully open.
- *2. In heating, the indoor unit electronic expansion valve is used for “subcooling degree control”.




CHECK 6 Refer to page 345.

4.2 Low Pressure Check

CHECK 2

Referring to the Fault Tree Analysis (FTA) shown below, probe the defective points.



Notes:

- *1. For details of compressor capacity control while in cooling.
- *2. The low pressure protection control includes low pressure protection control and hot gas bypass control.
- *3. In cooling, the indoor unit electronic expansion valve is used for superheating degree control.
- *4. In heating, the outdoor unit electronic expansion valve (main) is used for superheating degree control of outdoor heat exchanger.



CHECK 7 Refer to page 346.




CHECK 8 Refer to page 347.

4.3 Superheat Operation Check

CHECK 3

Identify the defective points referring to the failure factor analysis (FTA) as follows.



**Notes:**

- *1: Refer to Low pressure protection control for hot gas bypass control.
- *2: Superheating temperature control in cooling is conducted by indoor unit electronic expansion valve.
- *3: Superheating temperature control in heating is conducted by outdoor unit electronic expansion valve (main).
- *4: Judgment criteria of superheat operation:
 - (1) Suction gas superheating degree: 10°C (18°F) and over. (2) Discharge gas superheating degree: 45°C (81°F) and over, except immediately after compressor starts up or is running under dropping control.
 - (Use the above values as a guide. Depending on the other conditions, the unit may be normal despite the values within the above range.)



CHECK 7 Refer to page 346.



CHECK 8 Refer to page 347.


4.4 Power Transistor Check

CHECK 4

Perform the following procedures prior to check.

- (1) Power OFF.
- (2) Remove all the wiring connected to the PCB where power transistors are mounted on.

Preparation Multimeter



* Prepare the analog type of multimeter.
For the digital type of multimeter, those with diode check function are available for the checking.

Point of Measurement and Judgement Criteria

Turn OFF the power supply. Then, after a lapse of 10 minutes or more, make measurement of resistance.



When using the analog type of multimeter, make measurement in resistance measurement mode in the x1kΩ range.

No.	Measuring point		Judgement Criteria	Remarks
	+	-		
1	P2	U	2 ~ 15 kΩ	Due to condenser charge and so on, resistance measurement may require some time.
2	P2	V		
3	P2	W		
4	U	P2	15 kΩ and more (including ∞)	
5	V	P2		
6	W	P2		
7	N3	U		
8	N3	V		
9	N3	W		
10	U	N3	2 ~ 15 kΩ	
11	V	N3		
12	W	N3		

When using the digital type of multimeter, make measurement in diode check mode (→|←).

No.	Measuring point		Judgement Criteria	Remarks
	+	-		
1	P2	U	1.2 V and more	Due to condenser charge and so on, resistance measurement may require some time.
2	P2	V		
3	P2	W		
4	U	P2	0.3 ~ 0.7 V	
5	V	P2		
6	W	P2		
7	N3	U		
8	N3	V		
9	N3	W		
10	U	N3	1.2 V and more	
11	V	N3		
12	W	N3		

PCB and Circuit Diagram



Since the appearance of PCB shown in this outline drawing is different from the actual appearance, use it as a reference drawing.


4.5 Refrigerant Overcharge Check

CHECK 6

In case of **VRV** Systems, the only way to judge as the overcharge of refrigerant is with operating conditions due to the relationship to pressure control and electronic expansion valve control. As information for making a judgment, refer to the information below.

Diagnosis of overcharge of refrigerant

1. High pressure rises. Consequently, overload control is conducted to cause insufficient cooling capacity.
2. The superheating degree of suction gas lowers (or the wet operation is performed). Consequently, the compressor becomes lower in discharge pipe temperature despite of pressure loads.
3. The subcooling degree of condensate rises. Consequently, in heating, the temperature of discharge air through the subcooled section becomes lower.






4.6 Refrigerant Shortage Check

CHECK 7

In case of **VRV** Systems, the only way to judge as the shortage of refrigerant is with operating conditions due to the relationship to pressure control and electronic expansion valve control. As information for making a judgment, refer to the information below.

Diagnosis of shortage of refrigerant

1. The superheating degree of suction gas rises. Consequently, the compressor discharge gas temperature becomes higher.
2. The superheating degree of suction gas rises. Consequently, the electronic expansion valve turns open.
3. Low pressure drops to cause the unit not to demonstrate cooling capacity (heating capacity).



4.7 Vacuuming and Dehydration Procedure

CHECK 8

Conduct vacuuming and dehydration in the piping system following the procedure for <Normal vacuuming and dehydration> described below.

Furthermore, if moisture may get mixed in the piping system, follow the procedure for <Special vacuuming and dehydration> described below.

<Normal vacuuming and dehydration>

(1) Vacuuming and dehydration

- Use a vacuum pump that enables vacuuming up to -100.7 kPa (-14.6 psi) (5 torr, -755 mmHg).
- Connect manifold gauges to the service ports of liquid pipe and gas pipe and run the vacuum pump for a period of 2 or more hours to conduct evacuation to -100.7 kPa (-14.6 psi) or less.
- If the degree of vacuum does not reach -100.7 kPa (-14.6 psi) or less even though evacuation is conducted for a period of 2 hours, moisture will have entered the system or refrigerant leakage will have been caused. In this case, conduct evacuation for a period of another 1 hour.
- If the degree of vacuum does not reach -100.7 kPa (-14.6 psi) or less even though evacuation is conducted for a period of 3 hours, conduct the leak tests.

(2) Leaving in vacuum state

- Leave the compressor at the degree of vacuum of -100.7 kPa (-14.6 psi) or less for a period of 1 hour or more, and then check to be sure that the vacuum gauge reading does not rise. (If the reading rises, moisture may have remained in the system or refrigerant leakage may have been caused.)

(3) Additional refrigerant charge

- Purge air from the manifold gauge connection hoses, and then charge a necessary amount of refrigerant.

Special vacuuming and dehydration

Use this procedure if moisture may get into the piping, such as construction during the rainy season (dew condensation may occur, or rainwater may enter the piping during construction work).

(1) Vacuuming and dehydration

- Follow the same procedure as that for 1) Normal vacuuming and dehydration described above.

(2) Vacuum break

- Pressurize with nitrogen gas up to 0.05 MPa (7.25 psi).

(3) Vacuuming and dehydration

- Conduct vacuuming and dehydration for a period of 1 hour or more. If the degree of vacuum does not reach -100.7 kPa (-14.6 psi) or less even though evacuation is conducted for a period of 2 hours or more, repeat vacuum break - vacuuming and dehydration.

(4) Leaving in vacuum state

- Leave the compressor at the degree of vacuum of -100.7 kPa (-14.6 psi) or less for a period of 1 hour or more, and then check to be sure that the vacuum gauge reading does not rise.

(5) Additional refrigerant charge

- Purge air from the manifold gauge connection hoses, and then charge a necessary amount of refrigerant.

4.8 Thermistor Check

CHECK 11

Thermistor type of indoor units

Model	Suction air thermistor	Indoor heat exchanger (liquid) thermistor	Indoor heat exchanger (gas) thermistor	Discharge air thermistor
	R1T	R2T	R3T	R4T
FXFQ-T	Type C	Type A	Type J	–
FXZQ-TA	Type B		Type A	–
FXUQ-P	Type C		Type J	–
FXEQ-P	Type B		Type A	–
FXDQ-M			Type J	–
FXSQ-TA			Type A	–
FXMQ-PB			Type J	Type J
FXMQ-M			–	
FXHQ-M			–	
FXAQ-P			–	
FXLQ-M			–	
FXNQ-M			–	
FXTQ-TA			–	Type A
CXTQ-TA	–		Type J	–
FXMQ-MF	Type B		Type J	Type J

Thermistor type of outdoor units

Model	Thermistor		Type
RXYQ72XA	R1T	Outdoor air	E
	R21T	Discharge pipe	H
	R3T	Accumulator inlet	A
	R4T	Heat exchanger liquid pipe	A
	R5T	Subcooling heat exchanger liquid pipe	A
	R6T	Subcooling heat exchanger gas pipe	A
	R7T	Heat exchanger deicer	A
RXYQ96/120XA	R1T	Outdoor air	E
	R21T	Discharge pipe	H
	R3T	Accumulator inlet	A
	R4T	Heat exchanger liquid pipe	A
	R5T	Subcooling heat exchanger liquid pipe	A
	R6T	Subcooling heat exchanger gas pipe	A
	R7T	Heat exchanger deicer	A
	R8T	M1C body	H
RXYQ144/168XA	R1T	Outdoor air (A1P)	E
	R1T	Radiation fin (A3P) (XATJA only)	F
	R21T R22T	Discharge pipe	H
	R3T	Accumulator inlet	A
	R4T	Heat exchanger liquid pipe	A
	R5T	Subcooling heat exchanger liquid pipe	A
	R6T	Subcooling heat exchanger gas pipe	A
	R7T	Heat exchanger deicer	A

Table 2

Thermistor temperature		Resistance (kΩ)		
(°C)	(°F)	Type A	Type B	Type C
-30	-22	363.8	361.7719	-
-25	-13	266.8	265.4704	-
-20	-4	197.8	196.9198	-
-15	5	148.2	147.5687	-
-10	14	112.0	111.6578	111.8
-5	23	85.52	85.2610	85.42
0	32	65.84	65.6705	65.80
5	41	51.05	50.9947	51.07
10	50	39.91	39.9149	39.97
15	59	31.44	31.4796	31.51
20	68	24.95	25.0060	25.02
25	77	19.94	20.0000	20.00
30	86	16.04	16.1008	16.10
35	95	12.99	13.0426	13.04
40	104	10.58	10.6281	10.63
45	113	8.669	8.7097	8.711
50	122	7.143	7.1764	7.179
55	131	5.918	5.9407	-
60	140	4.928	4.9439	-
65	149	4.123	4.1352	-
70	158	3.467	3.4757	-
75	167	-	2.9349	-
80	176	-	2.4894	-
85	185	-	2.1205	-
90	194	-	1.8138	-
95	203	-	1.5575	-
100	212	-	1.3425	-
105	221	-	1.1614	-
Drawing No.		3SA48002 3SA48004 3SA48018 3SA48019 (AD94A045) 3SA48013 (AD100026)	3SA48001 (AD87A001)	3SA48016 (AD100008)


*The data is for reference purpose only.

Thermistor temperature		Resistance (k Ω)			
($^{\circ}$ C)	($^{\circ}$ F)	Type E	Type F	Type H	Type J
-30	-22	362.4862	354.1	3257.371	359.8518
-25	-13	265.9943	259.7	2429.222	265.0699
-20	-4	197.3083	192.6	1827.883	197.1476
-15	5	147.8597	144.2	1387.099	147.7348
-10	14	111.8780	109.1	1061.098	111.7984
-5	23	85.4291	83.25	817.9329	85.3927
0	32	65.8000	64.10	635.0831	65.8000
5	41	51.0954	49.70	496.5712	51.1273
10	50	39.9938	38.85	391.0070	40.0423
15	59	31.5417	30.61	309.9511	31.5974
20	68	25.0554	24.29	247.2696	25.1125
25	77	20.0395	19.41	198.4674	20.0949
30	86	16.1326	15.61	160.2244	16.1860
35	95	13.0683	12.64	130.0697	13.1222
40	104	10.6490	10.30	106.1517	10.7042
45	113	8.7269	8.439	87.0725	8.7834
50	122	7.1905	6.954	71.7703	7.2479
55	131	5.9524	5.761	59.4735	6.0131
60	140	4.9536	4.797	49.5180	5.0144
65	149	4.1434	4.014	41.4168	4.2021
70	158	3.4825	3.375	34.7923	3.5381
75	167	2.9407	2.851	29.3499	2.9925
80	176	2.4943	2.418	24.8586	2.5420
85	185	2.1247	2.060	21.1360	2.1671
90	194	1.8173	1.762	18.0377	1.8554
95	203	1.5605	1.513	15.4487	1.5949
100	212	1.3451	1.304	13.2768	1.3764
105	221	1.1636	1.128	11.4395	1.1923
110	230	-	0.9790	9.8902	1.0365
115	239	-	0.8527	8.5788	0.9042
120	248	-	0.7450	7.4650	0.7914
125	257	-	0.6530	6.5156	0.6950
130	266	-	0.5741	5.7038	0.6121
135	275	-	-	5.0073	0.5408
140	284	-	-	4.4080	0.4791
145	293	-	-	3.8907	0.4257
150	302	-	-	3.4429	0.3792
Drawing No.		3SA48003 (AD87A001)	3PA61998 (AD92A057)	3SA48006 (AD87A001)	3SA48005 (AD87A001)

*The data is for reference purpose only.

4.9 Pressure Sensor Check

CHECK 12



$$P_H \text{ (MPa)} = \frac{4.15}{3.0} \times V_H - \frac{4.15}{3.0} \times 0.5$$

$$P_L \text{ (MPa)} = \frac{1.7}{3.0} \times V_L - \frac{1.7}{3.0} \times 0.5$$

1 MPa = 145 psi


P_H : High pressure (MPa)

P_L : Low pressure (MPa)


V_H : Output Voltage (High Side) (VDC)

V_L : Output Voltage (Low Side) (VDC)

Voltage Measurement Point of the High Pressure Sensor



Voltage Measurement Point of the Low Pressure Sensor



4.10 Broken Wire Check of the Relay Wires

CHECK 15

- Procedure for checking outdoor-outdoor unit transmission wiring for broken wires

On the system shown below, turn OFF the power supply to all equipment, short circuit between the outdoor-outdoor unit terminal F1 and F2 in the "Outdoor Unit A" that is farthest from the central remote controller, and then conduct continuity checks between the transmission wiring terminal blocks F1 and F2 of the central remote controller using a multimeter. If there is continuity between the said terminal blocks, the outdoor-outdoor unit transmission wiring has no broken wires in it.


If there is no continuity, the transmission wiring may have broken wires. With the outdoor-outdoor unit terminal of the "Outdoor Unit A" short circuited, conduct continuity checks between the transmission wiring terminal blocks F1 and F2 of the unified ON/OFF controller. If there is no continuity as well, conduct continuity checks between the outdoor-outdoor unit terminal of the "Outdoor Unit E", between the outdoor-outdoor unit terminal of the "Outdoor Unit D", between the outdoor-outdoor unit terminal of the "Outdoor Unit C", ... in the order described, thus identifying the place with continuity.

If the place with continuity can be identified, there may be broken wires in places before the said place with continuity.
- Procedure for checking indoor-outdoor unit transmission wiring for broken wires (for checking the indoor-outdoor unit transmission wiring of the "Outdoor Unit C" for broken wires)

Turn OFF the power supply to all equipment, short circuit between the indoor-outdoor unit terminal F1 and F2 in the "Outdoor Unit C, and then conduct continuity checks between the transmission wirings F1 and F2 of the "Indoor Unit a" that is farthest from the "Outdoor Unit C" using a multimeter. If there is continuity between the said transmission wirings, the indoor-outdoor unit transmission wiring has no broken wires in it.

If there is no continuity, the transmission wiring may have broken wires. With the indoor-outdoor unit terminal of the "Outdoor Unit C" short circuited, identify the place with continuity in the transmission wiring of the "Indoor Unit b", transmission wiring of the "Indoor Unit c", and transmission wiring of the "Indoor Unit d" in the order described.

If the place with continuity can be identified, there may be broken wires in places before the said place with continuity.




4.11 Fan Motor Connector Check (Power Supply Cable)

CHECK 16

Indoor unit

- (1) Turn OFF the power supply.
- (2) Measure the resistance between phases of U, V, W at the motor side connectors (3-core wire) to check that the values are balanced and there is no short circuiting, while connector or relay connector is disconnected.

FXDQ-M, FXHQ-M




Model	Judgment	
	Black-Red	Black-White
FXDQ07-12M	71.0 Ω ± 10%	73.5 Ω ± 10%
FXDQ18/24M	39.2 Ω ± 10%	41.3 Ω ± 10%
FXHQ12M	71.0 Ω ± 10%	73.5 Ω ± 10%
FXHQ24/36M	53.5 Ω ± 10%	31.6 Ω ± 10%

FXSQ54TA, FXMQ15-54PB


Remove the X1A connector from the fan PCB (A2P) and measure the resistance between the U and V, V and W, and W and U phases of the motor connector (with five conductors) and check that each phase are balanced (within a permissible dispersion range of ±20%).

Connector power wire use (X1A)



Outdoor unit

- (1) Turn OFF the power supply.
- Measure the resistance between phases of U, V, W at the motor side connectors (3-core wire) to check that the values are balanced and there is no short circuiting, while connector or relay connector is disconnected.




4.12 Fan Motor Connector Check (Signal Cable)

CHECK 17

Indoor unit

Resistance measuring points and judgment criteria


FXFQ-T, FXZQ-TA, FXUQ-P, FXSQ05-48TA, FXMQ07-12PB



Judgment criteria

Measuring point	Criteria
1 - 4	1 Ω
2 - 4	1 Ω
3 - 4	1 Ω
7 - 4	1 Ω


FXEQ-P



Judgment criteria

Measuring point	Criteria
2 - 5	1 Ω
3 - 5	1 Ω
4 - 5	1 Ω
8 - 5	1 Ω


FXAQ-P



Judgment criteria

Measuring point	Criteria
6 - 3	1 Ω
5 - 3	1 Ω
4 - 3	1 Ω
1 - 3	1 Ω

FXSQ54TA, FXMQ15-54PB




Judgment criteria

Measuring point	Criteria
5 - 4	1 Ω
5 - 3	1 Ω
5 - 2	1 Ω
5 - 1	1 Ω

Outdoor unit

- (1) Turn OFF the power supply.
- (2) Measure the resistance between Vcc and each phase of U, V, W, and GND and each phase at the motor side connectors (5-core wire) to check that the values are balanced within the range of $\pm 20\%$, while connector or relay connector is disconnected.
Furthermore, to use a multimeter for measurement, connect the probe of negative pole to Vcc and that of positive pole to GND.



4.13 Electronic Expansion Valve Coil Check


CHECK 18

Measure the connector pin-to-pin resistance and make sure that the resistance value is within the range listed in the table below.

Determine the type according to the connector wire color and measure the resistance.



Outdoor unit

Y1E



Measuring points	Judgment criteria
	Y1E
1 - 6	120-180 Ω
2 - 6	
3 - 6	
4 - 6	


Y2E



Measuring points	Judgment criteria
1 - 6	35-55 Ω
2 - 6	
3 - 6	
4 - 6	

Indoor unit

FXFQ-T, FXZQ-TA, FXUQ-P, FXEQ-P, FXSQ-TA, FXTQ-TA, CXTQ-TA




Measuring points	Judgment criteria
1 - 6	35-55 Ω
2 - 6	
3 - 6	
4 - 6	

FXMQ-PB, FXAQ-P



Measuring points	Judgment criteria
1 - 3	300 Ω
1 - 5	150 Ω
2 - 4	300 Ω
2 - 6	150 Ω

FXDQ-M, FXMQ-M, FXHQ-M, FXLQ-M, FXNQ-M, FXMQ-MF



Measuring points	Judgment criteria
1 - 3	300 Ω
1 - 5	150 Ω
2 - 4	300 Ω
2 - 6	150 Ω

4.14 Fan Motor Connector Check for FXTQ-TA

CHECK 19

CHECKING EMERSON ULTRATECH™ ECM MOTORS

The FXTQ-TA models utilize an Emerson, 4-wire variable speed ECM blower motor. The ECM blower motor provides constant CFM.

The motor is a serially communicating variable speed motor. Only four wires are required to control the motor: +Vdc, Common, Receive, and Transmit.

The +Vdc and Common wires provide power to the motor's low voltage control circuits.

General Checks / Considerations

1. Check power supply to the air handler or modular blower. Ensure power supply is within the range specified on rating plate.
2. Check motor power harness. Ensure wires are continuous and make good contact when seated in the connectors. Repair or replace as needed.
3. Check motor control harness. Ensure wires are continuous and make good contact when seated in the connectors. Repair or replace as needed.
4. Check blower wheel. Confirm wheel is properly seated on motor shaft. Set screw must be on shaft flat and torqued to 165 in-lbs minimum. Confirm wheel has no broken or loose blades. Repair or replace as needed.
5. Ensure motor and wheel turn freely. Check for interference between wheel and housing or wheel and motor. Repair or replace as needed.
6. Check housing for cracks and/or corrosion. Repair or replace as needed.
7. Check motor mounting bracket. Ensure mounting bracket is tightly secured to the housing. Ensure bracket is not cracked or broken.

Emerson UltraCheck-EZ™ Diagnostic Tool

The Emerson UltraCheck-EZ™ diagnostic tool may be used to diagnose the ECM motor.



Warning

HIGH VOLTAGE!

Disconnect ALL power before servicing or installing. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.

To use the diagnostic tool, perform the following steps:

1. Disconnect power to the air handler.
2. Disconnect the 4-circuit control harness from the motor.
3. Plug the 4-circuit connector from the diagnostic tool into the motor control connector.
4. Connect one alligator clip from the diagnostic tool to a ground source.
5. Connect the other alligator clip to a 24VAC source.

NOTE: The alligator clips are NOT polarized.

NOTE: The UltraCheck-EZ™ diagnostic tool is equipped with a nonreplaceable fuse.

Connecting the tool to a source other than 24VAC could damage the tool and cause the fuse to open. Doing so will render the diagnostic tool inoperable.

6. Turn on power to air handler or modular blower.



Warning

Line Voltage now present.

7. Depress the orange power button on the diagnostic tool to send a run signal to the motor. Allow up to 5 seconds for the motor to start.

NOTE: If the orange power button does not illuminate when depressed, the tool either has an open fuse or is not properly connected to a 24VAC source.

8. The green LED on the diagnostic tool will blink indicating communications between the tool and motor. See table below for indications of tool indicators and motor actions. Replace or repair as needed.

Power Button	Green LED	Motor Action	Indication(s)
OFF	OFF	Not Rotating	Confirm 24VAC to UltraCheck-EZ™ tool. If 24VAC is confirmed, diagnostic tool is inoperable.
ON	Blinking	Rotating	Motor and control/end bell are functioning properly.
ON	OFF	Rotating	Replace motor control/end bell.
ON	Blinking	Not Rotating	Check motor (refer to Motor Checks on page 361).
ON	OFF	Not Rotating	Replace motor control/end bell; verify motor (refer to Motor Checks on page 361).

9. Depress the orange power button to turn off motor.

10. Disconnect power. Disconnect diagnostic tool.

11. Reconnect the 4-wire harness from control board to motor.

Electrical Checks - High Voltage Power Circuits



Warning

HIGH VOLTAGE!

Disconnect ALL power before servicing or installing. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.


1. Disconnect power to air handler or modular blower.
2. Disconnect the 5-circuit power connector to the ECM motor.
3. Turn on power to air handler or modular.



Warning

Line Voltage now present.

4. Measure voltage between pins 4 and 5 on the 5-circuit connector. Measured voltage should be the same as the supply voltage to the air handler or modular.



5. Measure voltage between pins 4 and 3. Voltage should be approximately half of the voltage measured in step 4.
6. Measure voltage between pins 5 and 3. Voltage should be approximately half of the voltage measured in step 4.
7. If no voltage is present, check supply voltage to air handler or modular blower.
8. Disconnect power to air handler or modular blower. Reconnect the 5-circuit power harness disconnected in step 2.

Electrical Checks - Low Voltage Control Circuits

1. Turn on power to air handler or modular.

**Warning**

Line Voltage now present.


2. Check voltage between pins on the 4-wire motor control harness between the motor and control board.
3. Voltage on pins should read:
 - Pins 1 to 4 = 3.3vdc
 - Pins 1 to 2 = 3.3vdc
 - Pins 3 to 4 = 15vdc

Motor Control/End Bell Checks**Warning**


HIGH VOLTAGE!

Disconnect ALL power before servicing or installing. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.

1. Disconnect power to air handler or modular blower.
 - NOTE:** Motor contains capacitors that can hold a charge for several minutes after disconnecting power. Wait 5 minutes after removing power to allow capacitors to discharge.
2. Disconnect the motor control harness and motor power harness.
3. Remove the blower assembly from the air handler or modular blower.
4. Remove the (3) screws securing the control/end bell to the motor. Separate the control/end bell. Disconnect the 3-circuit harness from the control/end bell to remove the control/end bell from the motor.
5. Inspect the NTC thermistor inside the control/end bell. Replace control/end bell if thermistor is cracked or broken.



6. Inspect the large capacitors inside the control/end bell. Replace the control/end bell if any of the capacitors are bulging or swollen.



7. Locate the 3-circuit connector in the control/end bell. Using an ohmmeter, check the resistance between each terminal in the connector. If the resistance is 1 M Ω or greater, the control/end bell is functioning properly. Replace the control/end bell if the resistance is lower than 1 M Ω .
8. Reassemble motor and control/end bell in reverse of disassembly. Replace blower assembly into air handler or modular blower.

Motor Checks



Warning

HIGH VOLTAGE!

Disconnect ALL power before servicing or installing. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.

1. Disconnect power to air handler or modular blower.
NOTE: Motor contains capacitors that can hold a charge for several minutes after disconnecting power. Wait 5 minutes after removing power to allow capacitors to discharge.
2. Disassemble motor as described in steps 2 through 4 above.
3. Locate the 3-circuit harness from the motor. Using an ohmmeter, measure the resistance between each motor phase winding. The resistance levels should be equal. Replace the motor if the resistance levels are unequal, open circuited or short circuited.
4. Measure the resistance between each motor phase winding and the motor shell. Replace the motor if any phase winding is short circuited to the motor shell.
5. Reassemble motor and control/end bell in reverse of disassembly. Replace blower assembly into air handler or modular blower.


Part 7 Appendix

1. Wiring Diagrams.....	363
1.1 Outdoor Unit.....	363
1.2 Indoor Unit.....	369
1.3 Air Treatment Equipment	383

1. Wiring Diagrams


1.1 Outdoor Unit

RXYQ72XATJA




RXYQ96/120XATJA

2D121953



RXYQ144/168XATJA




2D121954-1

RXYQ144, 168XATJ*

2D121954


RXYQ72XAYDA



3D121955


RXYQ96/120XAYDA

2D121956



RXYQ144/168XAYDA


2D121957



2D121957-1

1.2 Indoor Unit

FXFQ07/09/12/15/18/24/30/36/48TVJU




FXFQ07-09-12-15-18-24-30-36-48TVJU


3D086460B

3D086460B

BYCQ125BGW1 (Self-Cleaning Decoration Panel for FXFQ-TVJU)




BS1	PUSH BUTTON(FILTER AUTO CLEANING TEST)	HAP	LIGHT EMITTING DIODE(SERVICE MONITOR GREEN)
BS2	PUSH BUTTON(RESET OF ABNORMALITY INDICATION)	S1C	LIMIT SWITCH(FILTER)
DS1	DIP SWITCH(ON:FILTER CLEANING PROHIBITION MODE)	S2C	LIMIT SWITCH(DAMPER)
H1P	INDICATOR LAMP(GREEN)	M1	MOTOR(FILTER)
H2P	INDICATOR LAMP(RED)	M2	MOTOR(BRUSH)
		M3	MOTOR(DAMPER)
		X35A	CONNECTER(GROUP CONTROL ADAPTOR)




NOTE) 1. THESE SYMBOLS SHOW CONNECTORS.
 2. WHEN DS1-1, -2 ARE TURNED ON, THEY WILL BE SET TO FILTER CLEANING PROHIBITION MODE AND INCREASE OF DUST DETECTION SENSOR LIGHT QUANTITY.
 3. H1P AND H3P ARE NOT SET TO LIGHT WHEN SHIPPED FROM THE FACTORY.
 4. POWER SUPPLY TO THE ADAPTOR WILL BE CONNECTED TO THE CONNECTOR(X35A) OF A1P.

3D076375A

FXZQ05/07/09/12/15/18TAVJU




FXDQ07/09/12/18/24MVJU



C: 3D050501C


FXDQ07 • 09 • 12 • 18 • 24MVJU

FXSQ05/07/09/12/15/18/24/30/36/48/54TAVJU



C: 3D110467C


FXMQ07/09/12/15/18/24/30/36/48/54PBVJU



3D093209B

FXMQ72/96MVJU

INDOOR UNIT		R1T	THERMISTOR (AIR)
A1P	PRINTED CIRCUIT BOARD	R2T+R3T	THERMISTOR (COIL)
C1+C2	CAPACITOR (M1F+2F)	SS	SELECTOR SWITCH
F1U	FUSE (⑤, 5A, 250V)	T1R	TRANSFORMER (208V/230V 25VA)
HAP	LIGHT EMITTING DIODE (SERVICE MONITOR-GREEN)	X1M	TERMINAL BLOCK (POWER)
K1M	MAGNETIC CONTACTOR (M1F+2F)	X2M-X3M	TERMINAL BLOCK
K2M	MAGNETIC CONTACTOR (M1F+2F)	X4M	TERMINAL BLOCK (CONTROL)
K3M	MAGNETIC CONTACTOR (M1F+2F)	Y1E	ELECTRONIC EXPANSION VALVE
K1R-K3R	MAGNETIC RELAY (M1F+2F)		CONNECTOR FOR OPTIONAL PARTS
KPR	MAGNETIC RELAY (M1P)	X8A	CONNECTOR (FLOAT SWITCH)
M1F+M2F	MOTOR (INDOOR FAN)	X18A	CONNECTOR (WIRING ADAPTOR FOR ELECTRICAL APPENDICES)
Q1M+Q2M	THERMO. SWITCH (M1F+2F EMBEDDED)		




NOTES

1. □ : TERMINAL BLOCK
 ⊞, ⊞ : CONNECTOR
 ⊞ : SHORT CIRCUIT CONNECTOR
 ○ : TERMINAL
 ⊞ : FIELD WIRING
2. IN CASE USING CENTRAL REMOTE CONTROLLER, CONNECT IT TO THE UNIT IN ACCORDANCE WITH THE ATTACHED INSTALLATION MANUAL.
3. IN CASE CONNECTING THE INPUT WIRES FROM OUTSIDE, FORCED OFF OR ON/OFF CONTROL OPERATION CAN BE SELECTED BY REMOTE CONTROLLER. IN DETAILS, REFER TO THE INSTALLATION MANUAL ATTACHED THE UNIT.
4. SYMBOLS SHOW AS FOLLOWS. (PNK: PINK WHT: WHITE YLW: YELLOW ORG: ORANGE BLU: BLUE BLK: BLACK RED: RED BRN: BROWN)
5. USE COPPER CONDUCTORS ONLY.
6. IN CASE HIGH E.S.P. OPERATION, CHANGE THE SWITCH (SS) FOR "H".
7. CLASS 2 WIRE.

3D065414D

FXLQ07/09/12/18/24MVJU, FXNQ07/09/12/18/24MVJU




INDOOR UNIT	X2M	TERMINAL BLOCK (CONTROL)
A1P	Y1E	ELECTRONIC EXPANSION VALVE
C1	X18A	CONNECTOR FOR OPTIONAL PARTS
F1U		CONNECTOR (WIRING ADAPTOR FOR ELECTRICAL APPENDICES)
HAP		
K1R-K3R		
M1F		
Q1M		
R1T		
R2T-R3T		
T1R		
X1M		

NOTES

1. □ □ □ □ : TERMINAL BLOCK, □ □ □ □ : CONNECTOR, ∅ - TERMINAL
2. ■ ■ ■ ■ : FIELD WIRING, □ □ □ □ : SHORT CIRCUIT CONNECTOR
3. IN CASE USING CENTRAL REMOTE CONTROLLER, CONNECT IT TO THE UNIT IN ACCORDANCE WITH THE ATTACHED INSTALLATION MANUAL.
4. WHEN CONNECTING THE INPUT WIRES FROM OUTSIDE, FORCED OFF OR ON/OFF CONTROL OPERATION CAN BE SELECTED BY REMOTE CONTROLLER. IN DETAILS, REFER TO THE INSTALLATION MANUAL ATTACHED TO THE UNIT.
5. SYMBOLS SHOW AS FOLLOWS. (PNK: PINK WHT: WHITE YLW: YELLOW ORG: ORANGE BLU: BLUE BLK: BLACK RED: RED BRN: BROWN GRN: GREEN)
6. USE COPPER CONDUCTORS ONLY.
7. CLASS 2 WIRE.

3D045644C

FXTQ09/12/18/24/30/36/42/48/54/60TAVJUA(D)



NOTES:

1. PLACE RED WIRES ON 208 V TERMINAL OF 2-TRANSFORMER (TR1/TR2) FOR 208 VAC OPERATION.
2. MANUFACTURER'S SPECIFIED REPLACEMENT PARTS MUST BE USED WHEN SERVICING.
3. IF ANY OF THE ORIGINAL WIRES AS SUPPLIED WITH THIS UNIT MUST BE REPLACED, IT MUST BE REPLACED WITH WIRING MATERIAL HAVING A TEMPERATURE RATING OF AT LEAST 105°C. USE COPPER CONDUCTORS ONLY.
4. UNIT MUST BE PERMANENTLY GROUNDED AND CONFIRM TO N.E.C AND LOCAL CODES.
5. DISCARD CONNECTOR PL1 WHEN INSTALLING OPTIONAL HEAT KIT.
6. REMOVE SHORT RED CIRCUITING WIRE AND PUT AUX ALARM SWITCH WHEN INSTALLING AUX ALARM SWITCH.
7. USE N.E.C CLASS 2 WIRE.


- INTEGRATED CONTROL:
- LOW VOLTAGE ———
 - LOW VOLTAGE FIELD - - -
 - HIGH VOLTAGE ———
 - HIGH VOLTAGE FIELD - - -
 - JUNCTION ———
 - TERMINAL ———
 - PLUG CONNECTION ———/———
 - EQUIPMENT GND ———
 - FIELD GROUND ———

- COLOR CODES:
- BL - BLUE
 - RD - RED
 - YL - YELLOW
 - OR - ORANGE
 - BK - BLACK
 - GY - GREY
 - BR - BROWN
 - GR - GREEN
 - WH - WHITE
 - PU - PURPLE

- COMPONENT CODES:
- PL1, PL2 — POWER/HEATER KIT/DISCONNECT SWITCH CONNECTOR
 - TR1, TR2 — TRANSFORMER
 - F1U, F2U — FUSE LINK
 - PL3, PL4 — TRANSFORMER CONNECTOR

C: 0140A00500A


CXTQ24/36/48/60TASBLU



1.3 Air Treatment Equipment


1.3.1 Outdoor-air Processing Unit

FXMQ48/72/96MFVJU



3D065426D

VAM1200GVJU



VAM1200GVJU

3D073270-1D

3D073270D

Revision History

Month / Year	Version	Revised contents
12 / 2019	SiUS342003E	First edition

Warning

- Daikin products are manufactured for export to numerous countries throughout the world. Prior to purchase, please confirm with your local authorized importer, distributor and/or retailer whether this product conforms to the applicable standards, and is suitable for use, in the region where the product will be used. This statement does not purport to exclude, restrict or modify the application of any local legislation.
- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorized parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the user's manual carefully before using this product. The user's manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any inquiries, please contact your local importer, distributor and/or retailer.

Cautions on product corrosion

1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.

©All rights reserved

●Specifications, designs and other content appearing in this brochure are current as of December 2019 but subject to change without notice.