


Daikin One+ Smart Thermostat Proper Calibration




Unitary



Disclaimer


This material provides technical information that is to only be used by appropriately trained and certified HVAC-R installers and technicians who have agreed to the terms and conditions available here at <https://www.daikincity.com/DaikinCityB2BTermsOfUse.html>. If you have not agreed to these terms and conditions, you may not use or view this material, and you assume responsibility for any injury or property, system or equipment damage which may result. If you have agreed to these terms, you also agree, by viewing or using this material, that this material, by its nature, cannot include a discussion of everything necessary to effect a proper installation or repair of HVAC-R equipment, nor can it address every possible scenario or environment a technician or installer may encounter. Accordingly, this material should not be considered as recommendations for best practices and will not be considered installation or repair instructions to the extent of any conflict with Daikin- or Goodman-issued manuals and specifications, or industry standards and regulations. Each installer or technician remains fully responsible for ensuring proper installation or repair of the HVAC-R equipment being worked on, and you remain fully responsible for any injury or property, system or equipment damage which may result from your installation. ©2023 Daikin, all rights reserved; recording, copying, or distribution of this material is prohibited without express written permission from Daikin.

Daikin One+ Proper Calibration




- From the Home screen select the ***POWER*** icon

Daikin One+ Proper Calibration



- Select **OFF**

Daikin One+ Proper Calibration




- Select the **BACK** icon

Daikin One+ Proper Calibration




- Wait **30 MINUTES** for thermostat to read temperature.

Daikin One+ Proper Calibration




- Using a properly calibrated independent meter that reads temperature/humidity read the temperature **3 to 6** inches to the **RIGHT** of the thermostat, **NEVER** above or below the thermostat.
- Record the temperature

Daikin One+ Proper Calibration




- Select the ***MENU*** icon.

Daikin One+ Proper Calibration



- Select ***DEALER EDIT***


Daikin One+ Proper Calibration



- Select ***CONTINUE***

Daikin One+ Proper Calibration

- Select the **LEARN MORE** icon.
- The icon displays the installer code, giving you access to the installer set-up screens.



Daikin One+ Proper Calibration

- Select the **CLOSE** icon.
- Enter the code and select **UNLOCK THERMOSTAT**.

< dealer edit ⓘ

Enter your 4-digit PIN to unlock the thermostat:

unlock thermostat 🔒

q	w	e	r	t	y	u	i	o	p
a	s	d	f	g	h	j	k	l	
↶	z	x	c	v	b	n	m	↵	
123								done	


dealer edit ⓧ

Dealer edit accesses the advanced settings for the thermostat created during the initial setup process.

Each thermostat has a unique installer code used to unlock the thermostat's advanced settings — last four characters of the thermostat's MAC address.


This thermostat's installer code is:

c0fe




- Select #4 **SYSTEM OPTIMIZATION**

Daikin One+ Proper Calibration




- Select ***TEMPERATURE CALIBRATION***

Daikin One+ Proper Calibration



- From here you can slide the bar marked **0 Up** or **Down** to adjust the temperature reading to the correct temperature.

Daikin One+ Proper Calibration




- Select the **BACK** icon.

Daikin One+ Proper Calibration




- Using a properly calibrated independent meter that reads temperature/humidity read the temperature **3 to 6** inches to the **RIGHT** of the thermostat, **NEVER** above or below the thermostat.
- Record the humidity

Daikin One+ Proper Calibration




- Select ***HUMIDITY CALIBRATION***.

Daikin One+ Proper Calibration




- From here you can slide the bar marked **0%** to the **Left** or **Right** to adjust the humidity reading to the correct humidity.

Daikin One+ Proper Calibration




- Select the **BACK** icon.

Daikin One+ Proper Calibration




- Select the **BACK** icon.




- Select the **BACK** icon

Daikin One+ Proper Calibration




- Select the ***POWER*** icon.


Daikin One+ Proper Calibration



- Select ***AUTO (COOL & HEAT)***



- Select the **BACK** icon



- Now the system is **COOLING** in the **AUTO** mode.

- Congratulations! You have properly calibrated the Daikin *One+* Smart Thermostat!

