

## Accessory Parts

CONVOUTP1502  
CONVOUTP1507  
DSC060C50ND02FI  
DSC060C50YD02FI  
DSC100C50ND02FI  
DSC100C50YD02FI  
DSC200C50ND02FI  
DSC200C50YD02FI  
DSC250C50ND02FI  
DSC250C50YD02FI  
SDRK01FI15T20D  
SDRK01FI25D  
SDRKT01FI15T20  
SDRKT01FI25  
SDSK01FI15T20D  
SDSK01FI25D  
SDSK02FI15T20D  
SDSK02FI25D  
SDSKT01FI15T20  
SDSKT01FI25  
SDSKT02FI15T20  
SDSKT02FI25  
SDSRK01FI15T20D  
SDSRK01FI25D  
SDSRK02FI15T20D  
SDSRK02FI25D  
SDSRKT01FI15T20  
SDSRKT01FI25  
SDSRKT02FI15T20  
SDSRKT02FI25

## ACCESSORY PARTS LIST

## RP-FIOPLC



This manual is to be used by qualified technicians only.

This manual replaces RP-FIOPLC  
released in October 2021.

## Important Information

---

### Index

|                              |       |
|------------------------------|-------|
| Functional Parts List .....  | 3     |
| Illustration and Parts ..... | 4 - 9 |

*Views shown are for parts illustrations only, not servicing procedures.*

4-5-22: REMOVED NOMENCLATURE PAGE PER REQUEST FROM DAIKIN MARKETING GROUP

#### Text Codes:

AR - As Required

NA - Not Available

NS - Not Shown

00000000 - See Note

QTY - Quantity    Example (QTY 3) (If Quantity not shown, Quantity = 1)

M - Model        Example (M1) (If M Code not shown, then part is used on all Models)

#### Expanded Model Nomenclature:

|                                                         |
|---------------------------------------------------------|
| Example<br>M1 - Model#1<br>M2 - Model#2<br>M3 - Model#3 |
|---------------------------------------------------------|

Daikin Company, L.P. is not responsible for personal injury or property damage resulting from improper service. Review all service information before beginning repairs.

Warranty service must be performed by an authorized technician, using authorized factory parts. If service is required after the warranty expires, Daikin Company, L.P. also recommends contacting an authorized technician and using authorized factory parts.

Daikin Company, L.P. reserves the right to discontinue, or change at any time, specifications or designs without notice or without incurring obligations.

For assistance within the U.S.A. contact:

Equipment Support  
Daikin North America, LLC  
19001 Kermier Road  
Waller, Texas 77484  
855-770-5678-Telephone  
713-863-2382-Facsimile

For assistance outside the U.S.A. contact:

International Division  
Daikin North America, LLC  
19001 Kermier Road  
Waller, Texas 77484  
713-861-2500-Telephone  
713-863-2382-Facsimile

# Functional Parts

## Part

**No: Description:**

---

|            |                                  |
|------------|----------------------------------|
| 0130L00249 | BREAKER OPERATOR 250A (M9, M10)  |
| 0130L00027 | SWITCH-DISCONNECT 100A (M5, M6)  |
| 0130L00033 | SWITCH-DISCONNECT 200A (M7, M8)  |
| 0130L00245 | SWITCH-DISCONNECT 250A (M9, M10) |
| 0130L00046 | SWITCH-DISCONNECT 60A (M3, M4)   |
| 0130M00061 | TRANSFORMER (M1)                 |
| 0130M00034 | TRANSFORMER (M2)                 |


## SPECIAL PARTS

|           |                                                                                                                                |
|-----------|--------------------------------------------------------------------------------------------------------------------------------|
| IOD-7004B | INSTALLATION INSTRUCTIONS (M11, M12, M13, M14, M15, M16, M17, M18, M19, M20, M21, M22, M23, M24, M25, M26, M27, M28, M29, M30) |
| IOD-7002B | INSTALLATION INSTRUCTIONS (M3, M4, M5, M6, M7, M8, M9, M10)                                                                    |
| IOD-7001B | INSTALLATION INSTRUCTIONS (M1, M2)                                                                                             |


## Expanded Model Nomenclature

|                       |
|-----------------------|
| M1 - CONVOUTP1502     |
| M2 - CONVOUTP1507     |
| M3 - DSC060C50ND02FI  |
| M4 - DSC060C50YD02FI  |
| M5 - DSC100C50ND02FI  |
| M6 - DSC100C50YD02FI  |
| M7 - DSC200C50ND02FI  |
| M8 - DSC200C50YD02FI  |
| M9 - DSC250C50ND02FI  |
| M10 - DSC250C50YD02FI |
| M11 - SDRKT01FI15T20  |
| M12 - SDRKT01FI25     |
| M13 - SDRK01FI15T20D  |
| M14 - SDRK01FI25D     |
| M15 - SDSKT01FI15T20  |
| M16 - SDSKT01FI25     |
| M17 - SDSKT02FI15T20  |
| M18 - SDSKT02FI25     |
| M19 - SDSK01FI15T20D  |
| M20 - SDSK01FI25D     |
| M21 - SDSK02FI15T20D  |
| M22 - SDSK02FI25D     |
| M23 - SDSRKT01FI15T20 |
| M24 - SDSRKT01FI25    |
| M25 - SDSRKT02FI15T20 |
| M26 - SDSRKT02FI25    |
| M27 - SDSRK01FI15T20D |
| M28 - SDSRK01FI25D    |
| M29 - SDSRK02FI15T20D |
| M30 - SDSRK02FI25D    |

## GFCI CONVENIENCE OUTLET



## USED IN POWERED CONVENIENCE OUTLETS



GFCI ASSEMBLY MAY DIFFER FROM WHAT IS SHOWN

| Ref. Part<br>No: No: | Description: | Ref. Part<br>No: No: | Description: |
|----------------------|--------------|----------------------|--------------|
|----------------------|--------------|----------------------|--------------|


**Image 1:**

|     |            |                                    |
|-----|------------|------------------------------------|
| 11  | 0130L00103 | RECEPTACLE-GFCI OUTLET (M1, M2)    |
| 21  | 0130L00012 | GANG BOX-GFCI OUTLET (M1, M2)      |
| 31  | 0161G00012 | POWER OUTLET BOX (M1, M2)          |
| 41  | 0121L00316 | BRACKET-CONV OUTLET MOUNT (M1, M2) |
| 51  | 0130M00065 | BREAKER CIRCUIT (M1, M2)           |
| 211 | 0130M00034 | TRANSFORMER (M2)                   |
| 211 | 0130M00061 | TRANSFORMER (M1)                   |
| NS  | IOD-7001B  | INSTALLATION INSTRUCTIONS (M1, M2) |

**Expanded Model Nomenclature**

M1 - CONVOUTP1502  
 M2 - CONVOUTP1507  
 M3 - DSC060C50ND02FI  
 M4 - DSC060C50YD02FI  
 M5 - DSC100C50ND02FI  
 M6 - DSC100C50YD02FI  
 M7 - DSC200C50ND02FI  
 M8 - DSC200C50YD02FI  
 M9 - DSC250C50ND02FI  
 M10 - DSC250C50YD02FI  
 M11 - SDRKT01FI15T20  
 M12 - SDRKT01FI25  
 M13 - SDRK01FI15T20D  
 M14 - SDRK01FI25D  
 M15 - SDSKT01FI15T20  
 M16 - SDSKT01FI25  
 M17 - SDSKT02FI15T20  
 M18 - SDSKT02FI25  
 M19 - SDSK01FI15T20D  
 M20 - SDSK01FI25D  
 M21 - SDSK02FI15T20D  
 M22 - SDSK02FI25D  
 M23 - SDSRKT01FI15T20  
 M24 - SDSRKT01FI25  
 M25 - SDSRKT02FI15T20  
 M26 - SDSRKT02FI25  
 M27 - SDSRK01FI15T20D  
 M28 - SDSRK01FI25D  
 M29 - SDSRK02FI15T20D  
 M30 - SDSRK02FI25D

DISCONNECT MODULE




DISCONNECT ASSEMBLY MAY DIFFER FROM WHAT IS SHOWN

| Ref. Part<br>No: No: | Description: | Ref. Part<br>No: No: | Description:                                                |
|----------------------|--------------|----------------------|-------------------------------------------------------------|
| <b>Image 1:</b>      |              |                      |                                                             |
| 11                   | 0130L00027   |                      | SWITCH-DISCONNECT 100A (M5, M6)                             |
| 11                   | 0130L00033   |                      | SWITCH-DISCONNECT 200A (M7, M8)                             |
| 11                   | 0130L00245   |                      | SWITCH-DISCONNECT 250A (M9, M10)                            |
| 11                   | 0130L00046   |                      | SWITCH-DISCONNECT 60A (M3, M4)                              |
| 31                   | 0130L00043   |                      | SHAFT, CUT (M7, M8)                                         |
| 31                   | 0130L00058   |                      | SHAFT, CUT (M5, M6)                                         |
| 31                   | 0130L00059   |                      | SHAFT, CUT (M3, M4)                                         |
| 31                   | 0130L00256   |                      | SHAFT, CUT (M9, M10)                                        |
| 41                   | 0130L00039   |                      | HANDLE, ROTARY (M3, M4, M5, M6, M7, M8)                     |
| 41                   | 0130L00247   |                      | HANDLE, ROTARY 250A (M9, M10)                               |
| NS                   | 0121L04185   |                      | BRACKET-DISCONNECT SW (M9, M10)                             |
| NS                   | 0121L04231   |                      | BRACKET-DISCONNECT SWITCH (M3, M4, M5, M6, M7, M8)          |
| NS                   | 0130L00249   |                      | BREAKER OPERATOR 250A (M9, M10)                             |
| NS                   | IOD-7002B    |                      | INSTALLATION INSTRUCTIONS (M3, M4, M5, M6, M7, M8, M9, M10) |
| NS                   | 0121L00839SB |                      | PNT, DISCONNECT COVER (M3, M4, M5, M6, M7, M8, M9, M10)     |

#### Expanded Model Nomenclature

M1 - CONVOUTP1502  
M2 - CONVOUTP1507  
M3 - DSC060C50ND02FI  
M4 - DSC060C50YD02FI  
M5 - DSC100C50ND02FI  
M6 - DSC100C50YD02FI  
M7 - DSC200C50ND02FI  
M8 - DSC200C50YD02FI  
M9 - DSC250C50ND02FI  
M10 - DSC250C50YD02FI  
M11 - SDRKT01FI15T20  
M12 - SDRKT01FI25  
M13 - SDRK01FI15T20D  
M14 - SDRK01FI25D  
M15 - SDSKT01FI15T20  
M16 - SDSKT01FI25  
M17 - SDSKT02FI15T20  
M18 - SDSKT02FI25  
M19 - SDSK01FI15T20D  
M20 - SDSK01FI25D  
M21 - SDSK02FI15T20D  
M22 - SDSK02FI25D  
M23 - SDSRKT01FI15T20  
M24 - SDSRKT01FI25  
M25 - SDSRKT02FI15T20  
M26 - SDSRKT02FI25  
M27 - SDSRK01FI15T20D  
M28 - SDSRK01FI25D  
M29 - SDSRK02FI15T20D  
M30 - SDSRK02FI25D

## SMOKE DETECTOR MODULE



SMOKE DETECTOR ASSEMBLY MAY DIFFER FROM WHAT IS SHOWN

| Ref. Part<br>No: No: | Description:                                                                                                                     | Ref. Part<br>No: No: | Description: |
|----------------------|----------------------------------------------------------------------------------------------------------------------------------|----------------------|--------------|
| <b>Image 1:</b>      |                                                                                                                                  |                      |              |
| 11 D4120             | SMOKE DETECTOR, PHOTO 4WIRE (M11, M12, M13, M14, M15, M16, M17, M18, M19, M20, M21, M22, M23, M24, M25, M26, M27, M28, M29, M30) |                      |              |
| 21 D4S               | SMOKE DETECTOR, SENSOR ONLY (M23, M24, M25, M26, M27, M28, M29, M30)                                                             |                      |              |
| NS 0121L01053        | BRKT, SMOKE DETECTOR (M11, M12, M13, M14, M15, M16, M17, M18, M19, M20, M21, M22, M23, M24, M25, M26, M27, M28, M29, M30)        |                      |              |
| NS 0121L00321        | COVER-SMOKE DETECTOR (M15, M16, M17, M18, M19, M20, M21, M22, M23, M24, M25, M26, M27, M28, M29, M30)                            |                      |              |
| NS IOD-7004B         | INSTALLATION INSTRUCTIONS (M11, M12, M13, M14, M15, M16, M17, M18, M19, M20, M21, M22, M23, M24, M25, M26, M27, M28, M29, M30)   |                      |              |
| NS 0259L00090        | WIRE HARNESS-SMOKE DETECTOR (M11, M12, M15, M16, M17, M18, M23, M24, M25, M26)                                                   |                      |              |
| NS 0259L01660        | WIRE HARNESS-SMOKE DETECTOR (M13, M14, M19, M20, M21, M22, M27, M28, M29, M30)                                                   |                      |              |

#### Expanded Model Nomenclature

M1 - CONVOUTP1502  
M2 - CONVOUTP1507  
M3 - DSC060C50ND02FI  
M4 - DSC060C50YD02FI  
M5 - DSC100C50ND02FI  
M6 - DSC100C50YD02FI  
M7 - DSC200C50ND02FI  
M8 - DSC200C50YD02FI  
M9 - DSC250C50ND02FI  
M10 - DSC250C50YD02FI  
M11 - SDRKT01FI15T20  
M12 - SDRKT01FI25  
M13 - SDRK01FI15T20D  
M14 - SDRK01FI25D  
M15 - SDSKT01FI15T20  
M16 - SDSKT01FI25  
M17 - SDSKT02FI15T20  
M18 - SDSKT02FI25  
M19 - SDSK01FI15T20D  
M20 - SDSK01FI25D  
M21 - SDSK02FI15T20D  
M22 - SDSK02FI25D  
M23 - SDSRKT01FI15T20  
M24 - SDSRKT01FI25  
M25 - SDSRKT02FI15T20  
M26 - SDSRKT02FI25  
M27 - SDSRK01FI15T20D  
M28 - SDSRK01FI25D  
M29 - SDSRK02FI15T20D  
M30 - SDSRK02FI25D